

PPE for Cohorted COVID-19 patient's (aerosolizing)

Putting on (Donning) PPE	
1	Gather Supplies <ul style="list-style-type: none"> PAPR Assembly Blue Isolation Gown 1 Pair Nitrile Gloves
2	Perform Hand Hygiene
3	Clip Battery to Waist (Pocket, Pants or Belt)
4	Put Gown On (Leave Untied)
5	Feed PAPR cord down the Back of Gown <ul style="list-style-type: none"> Plug cord into battery Confirm air flow and lights (should be green)
6	Place PAPR on Head <ul style="list-style-type: none"> Leave Ears Exposed Adjust Ratchet to a Snug Fit
7	Tie Gown & Don Gloves

Removing (Doffing) PPE	
1	<ul style="list-style-type: none"> Remove Isolation Gown and Gloves Break Waist Tie and Neck of Gown Pull Forward From Shoulders to Remove Slide Gown Off Arms, Removing Gloves with Gown Turn Inside Out, Roll Into Ball and Discard
2	Perform Hand Hygiene
3	Exit Patient Room
4	Perform Hand Hygiene Outside Patient Room
5	Don Clean Gloves
6	Remove PAPR
7	Disinfect PAPR <ul style="list-style-type: none"> Use Grey Top Wipe (AF3) to Clean Surfaces Ensure Cleaning of Helmet and Protective Shield Clean Cord and battery and Unplug Charge battery if needed Place PAPR in Designated Area
8	Remove Gloves and Perform Hand Hygiene