
Cell Reports

Design principles to tailor Hsp104 therapeutics

Graphical abstract



Highlights

- ATP-specific NBD1-MD contacts in Hsp104 regulate collaboration with Hsp70
- ADP-specific NBD1-MD contacts in Hsp104 restrict activity
- Rational design to tune Hsp70 collaboration and safely enhance Hsp104 activity
- Safely enhanced Hsp104 variants reduce FUS and TDP-43 proteinopathies in human cells

Authors

JiaBei Lin, Peter J. Carman, Craig W. Gambogi, ..., Alexandrea N. Rizo, Daniel R. Southworth, James Shorter

Correspondence

jshorter@pennmedicine.upenn.edu

In brief

In this paper, Lin et al. establish design principles for therapeutic Hsp104 variants. By leveraging high-resolution structures of the Hsp104 disaggregase, they rationally engineer enhanced disaggregases with retuned Hsp70 collaboration and minimal off-target unfoldase activity. These safely enhanced Hsp104 variants effectively mitigate FUS and TDP-43 proteinopathies in human cells.





Cell Reports



Article

Design principles to tailor Hsp104 therapeutics

JiaBei Lin,¹ Peter J. Carman,^{1,2} Craig W. Gambogi,^{1,2} Nathan M. Kendsersky,^{1,3} Edward Chuang,^{1,3} Stephanie N. Gates,^{4,6} Adam L. Yokom,^{4,6} Alexandrea N. Rizo,⁴ Daniel R. Southworth,⁵ and James Shorter^{1,2,3,7,*}

¹Department of Biochemistry and Biophysics, Perelman School of Medicine, University of Pennsylvania, Philadelphia, PA 19104, USA ²Biochemistry and Molecular Biophysics Graduate Group, Perelman School of Medicine, University of Pennsylvania, Philadelphia, PA 19104, USA

³Pharmacology Graduate Group, Perelman School of Medicine, University of Pennsylvania, Philadelphia, PA 19104, USA

⁴Graduate Program in Chemical Biology, University of Michigan, Ann Arbor, MI 48109, USA

⁵Department of Biochemistry and Biophysics and the Institute for Neurodegenerative Diseases, University of California, San Francisco, San Francisco, CA 94158, USA

⁶Present address: Department of Biochemistry, University of Missouri, Columbia, MO 65211, USA ⁷Lead contact

*Correspondence: jshorter@pennmedicine.upenn.edu https://doi.org/10.1016/j.celrep.2024.115005

SUMMARY

The hexameric AAA+ disaggregase, Hsp104, collaborates with Hsp70 and Hsp40 via its autoregulatory middle domain (MD) to solubilize aggregated proteins. However, how ATP- or ADP-specific MD configurations regulate Hsp104 hexamers remains poorly understood. Here, we define an ATP-specific network of interprotomer contacts between nucleotide-binding domain 1 (NBD1) and MD helix L1, which tunes Hsp70 collaboration. Manipulating this network can (1) reduce Hsp70 collaboration without enhancing activity, (2) generate Hsp104 hypomorphs that collaborate selectively with class B Hsp40s, (3) produce Hsp70-independent potentiated variants, or (4) create species barriers between Hsp104 and Hsp70. Conversely, ADP-specific intraprotomer contacts between MD helix L2 and NBD1 restrict activity, and their perturbation frequently potentiates Hsp104. Importantly, adjusting an NBD1:MD helix L1 rheostat via rational design enables finely tuned collaboration with Hsp70 to safely potentiate Hsp104, minimize off-target toxicity, and counteract FUS and TDP-43 proteinopathies in human cells. Thus, we establish design principles to tailor Hsp104 therapeutics.

INTRODUCTION

Protein function requires high-fidelity protein folding.¹ However, in the cell, proteins are exposed to various stresses such as translational errors, heat or chemical shock, and aging, which can elicit protein misfolding and aggregation.² The accumulation of misfolded and aggregated proteins is problematic and can be toxic.^{3,4} Thus, cells possess sophisticated molecular chaperones, protein disaggregases, protein-degradation systems, and stress-response pathways to maintain protein quality control.^{5,6} However, chronic accumulation of misfolded protein conformers upon aging can yield aberrant protein fibrils that are intimately tied to fatal neurodegenerative proteinopathies, such as α -synuclein fibrils in Parkinson's disease or TAR DNA-binding protein 43 (TDP-43) and fused-in-sarcoma (FUS) fibrils in amyotrophic lateral sclerosis (ALS).^{7–12} There are no effective treatments for these devastating neurodegenerative disorders.

One strategy for these neurodegenerative diseases would be to develop therapeutic protein disaggregases that liberate proteins trapped in aberrant oligomeric and aggregated states and restore them to native solubility, form, and function.^{5,13–16} Such agents would eliminate two malicious problems associated with deleterious protein misfolding and aggregation: (1) the toxic

gain of function of aggregated conformers; and (2) the loss of protein function due to sequestration in aggregated conformers.¹³ Thus, we have focused on Hsp104, a ring-shaped, hexameric AAA+ (ATPase associated with diverse activities) protein disaggregase, which can suppress age-related protein aggregation.^{13,17–19} Notably, Hsp104 dissolves a diverse spectrum of aggregated structures, including preamyloid oligomers, disordered aggregates, phase-separated condensates, and stable amyloid or prion fibrils.²⁰⁻²⁹ However, no exact Hsp104 homolog is found in metazoa,^{13,30,31} although a related human mitochondrial AAA+ protein, Skd3, displays potent disaggregase activity.³²⁻³⁸ Another AAA+ protein, VCP/p97, may remodel ubiquitylated protein inclusions in the cytoplasm and promote clearance of intranuclear TDP-43 inclusions.^{39,40} Nonetheless, introduction of Hsp104 or engineered variants into metazoan systems is well tolerated and can antagonize aggregation and toxicity of neurodegenerative disease proteins.^{22,}

Hsp104 is composed of two nucleotide-binding domains (NBD1 and NBD2) per monomer, separated by a middle domain (MD) and flanked by an N-terminal domain (NTD) and C-terminal domain (CTD).¹⁸ The MD is an autoinhibitory domain that regulates Hsp104 disaggregase activity.¹⁸ Indeed, single mutations in the MD can relieve autoinhibition and enhance Hsp104

1



disaggregase activity.^{42,50–55} Precisely how the MD permits or restricts Hsp104 disaggregase activity is not completely understood.

Hsp70 and Hsp40 enable optimal Hsp104 disaggregase activity.^{21,24,56–59} Hsp70s, and their obligate cochaperones, Hsp40s, are highly conserved.⁶⁰ Hsp40 binds substrate proteins and transfers them to Hsp70 via activation of Hsp70 ATPase activity.61-63 Interactions between Hsp70 and the NTD and MD of Hsp104 appear to enable disaggregase activity.^{18,64-66} However, the precise mechanism by which Hsp104, Hsp70, and Hsp40 coordinate activity remains uncertain. Several studies have utilized prokaryotic homologs of Hsp104 and Hsp70, ClpB and DnaK, respectively.⁶⁷⁻⁷⁰ However, prokaryotic ClpB is unable to perform the complete repertoire of eukaryotic Hsp104 activities.^{20,23,44,71} Indeed, there are several key structural and mechanistic differences between Hsp104 and ClpB.^{20,65,72–75} Several interaction sites on the MD of ClpB are proposed to interact with DnaK,67,68 and the MD of Hsp104 has been proposed to interact with a fragment of human Hsp70 (HSPA1A).⁶⁴ However, the structural determination of the Hsp104-Hsp70 interaction has been difficult to resolve due to the weak and transient interactions between these two proteins.67,68

We have elucidated many Hsp104 variants bearing single missense mutations in NBD1, MD, or NBD2, which display enhanced disaggregase activity.^{42,43,50,72,76-79} However, some of these Hsp104 variants, particularly MD or NBD1 variants, can present with "off-target" toxicity.^{42,43,77} Specifically, over-expressing these Hsp104 variants in $\Delta hsp104$ yeast reduces growth at 37°C, likely by unfolding metastable, soluble proteins.^{42,50} It has been suggested that Hsp70 might direct Hsp104 to aggregated proteins rather than misfolded soluble substrates, which may prevent off-target toxicity.⁸⁰ However, the mechanism of Hsp104-Hsp70 cooperation and its connection to off-target toxicity is still poorly understood. Consequently, rational design of potentiated Hsp104 variants with no off-target toxicity remains a significant challenge.⁴³

Here, we address these challenges by exploring an intimate network of contacts between the MD and NBD1 resolved in high-resolution cryogenic electron microscopy (cryo-EM) structures of Hsp104.73 We find that the ATP-specific interactions between MD helix L1 and NBD1 of the adjacent clockwise protomer are critical for collaboration between Hsp104 and Hsp70 in protein disaggregation. Manipulating this network can: (1) reduce Hsp70 collaboration without enhancing activity; (2) generate Hsp104 hypomorphs that collaborate selectively with class B Hsp40s; (3) produce Hsp70-independent potentiated variants; or (4) create species barriers between Hsp104 and Hsp70. By contrast, the distinctive ADP-specific intraprotomer contacts between MD helix L2 and NBD1 restrict activity, and their perturbation frequently potentiates disaggregase activity. We establish that the off-target toxicity of specific potentiated Hsp104 variants is determined by reduced dependence on Hsp70 for protein disaggregation. By tuning the ATP-specific MD helix L1 and NBD1 interaction, we can specify a desired level of Hsp70 collaboration to yield potentiated Hsp104 variants with no off-target toxicity. Importantly, we establish that potentiated Hsp104 variants can mitigate FUS and TDP-43 proteinopathies



in human cells. Overall, our findings establish important design principles to tailor therapeutic Hsp104 variants.

RESULTS

The MD changes orientation as Hsp104 hexamers switch from ATP-bound to ADP-bound states, which alter NBD1:MD interactions

The MD plays a critical role in regulating Hsp104 activity.^{18,42,81–83} High-resolution structures of Hsp104 hexamers determined by cryo-EM establish a dramatic change in the orientation of the MD between the substrate-free adenylyl imidodiphosphate (AMP-PNP) state (hereafter referred to as the ATP state) and substrate-free ADP state (Figures 1A and 1B).^{73,84} Importantly, these two distinct states are also observed in substrate-bound Hsp104 hexamers in the corresponding protomers bound to ATP or ADP, indicating that these states are populated by distinct protomers during substrate translocation.⁷³ However, it has remained unclear precisely how Hsp104 activity is regulated by the distinct interactions between NBD1 and the MD in either state.

We surveyed the interactions between NBD1 and the MD for each nucleotide state (Figures 1A and 1B). Numerous contacts, including hydrophobic (red line), electrostatic (black line), and hydrogen bond (blue line) interactions, are observed in both nucleotide states (Figures 1A and 1B, right). All the interactions observed in protomer 3 (P3, in green) and protomer 4 (P4, in blue) are displayed for the ATP state (Figure 1A, right) and ADP state (Figure 1B, right). Notably, in the ATP state we find that helix L1 of the MD of protomer 4 makes several interprotomer contacts with NBD1 of the adjacent clockwise protomer 3 (Figure 1A).⁸⁴

By contrast, in the ADP state, we find that interactions between NBD1 and the MD are completely remodeled such that helix L2 of the MD now makes intraprotomer contacts with NBD1 (Figure 1B).⁷³ Moreover, in the ADP state, the precise NBD1:MD intraprotomer interactions are not completely identical in different subunits. Some interactions are only present in P3 (shown in green) or P4 (blue) (Figure 1B, right). Only a few interactions are the same in both protomers (Figure 1B, shown in green and blue stripes), indicating diverse intraprotomer interactions between the MD and NBD1 in this state. In addition to helix L2, helices L1 and L4 as well as the loops between helix L2 and L3 and helix L4 and NBD1 also make intraprotomer contacts with NBD1 (Figure 1B). Thus, the MD makes a radically different set of interactions with NBD1 in the presence of ADP versus ATP.

We hypothesized that the interprotomer interactions between NBD1 and the MD in the ATP state (Figure 1A) and intraprotomer interactions between NBD1 and the MD in the ADP state (Figure 1B) may play key roles in regulating Hsp104 activity. Thus, to investigate the mechanism by which the MD regulates Hsp104 activity, we performed mutagenesis analysis to perturb the interactions between NBD1 and the MD for each state. Remarkably, we find that perturbation of the interprotomer NBD1:MD interactions of the ATP state has different functional consequences for Hsp104 activity than perturbation of the intraprotomer NBD1:MD interaction of the ADP state.








Figure 1. The MD changes orientation as Hsp104 hexamers switch from ATP-bound to ADP-bound states, which alter NBD1:MD interactions

(A and B) Left: three out of six protomers (P3 in green, P4 in blue, and P5 in magenta) are shown for the ATP state (A) or ADP state (B). NBD1 is shown in ribbon, and MD is shown in cartoon. The four MD helices (L1, L2, L3, and L4) are indicated by arrows. However, MD helix L3 appears to be a loop in these structures. Right: the NBD1:MD interactions for protomers P3 (green) and P4 (blue) were analyzed using Discovery Studio Visualizer with a 4-Å cutoff distance for the ATP-bound state (AMP-PNP, PDB: 5KNE) (A) or the ADP-bound state (PDB: 5VY8) (B). Hydrophobic, electrostatic (salt bridge), and hydrogen-bond interactions are indicated by red, black, and blue lines, respectively. For the ATP-bound state (A), NBD1:MD interactions were observed between the NBD1 of P3 (green circles) and MD of P4 (blue circles). For the ADP-bound state (B), we show NBD1:MD interactions within P3 (green circles) or within P4 (blue circles) and a unique interaction between R366 and E521 within P5 (purple) for clarity. Intra-subunit NBD1:MD interactions conserved in P3 and P4 are shown in circles with blue and green stripes. Residues involved in intrasubunit NBD1:MD interactions for P3, P4, or P5 are shown in circles with blue and green stripes with an asterisk.

(C) NBD1:MD helix L1 interactions with NBD1 in the ATP state. Four major salt-bridge interactions, (1) E190:R419, (2) R194:E412, (3) R353:E427, and (4) R366:D434, are identified on the intersubunit NBD1:MD interface in the presence of AMP-PNP. E190, R194, R353, and R366 are in NBD1 of subunit P3, and R419, E412, E427, and D434 are in MD helix 1 1 of P4

(D) ATPase activity of Hsp104, Hsp104^{E190K}, and Hsp104 $^{\text{R419E}}$ (0.25 $\mu\text{M})$ in the presence of 1 mM ATP at 25°C. Bars represent means \pm SEM (n = 4); each replicate is shown as a dot. Ordinary one-way ANOVA Dunnett's test was performed to compare the ATPase activity of Hsp104 to Hsp104^{E190K} or Hsp104^{R419E}. ns, not significant; ***p = 0.0005.

(E) Hsp104 variants (1 µM, monomer) in the presence of ATP/ATP_YS (2.5 mM:2.5 mM; black bars) or with Hsc70 (0.167 µM) and DnaJA1 (0.167 µM; pink bars) were incubated with 100 nM (monomeric concentration) chemical-denatured luciferase aggregates for 90 min at 25°C. Buffer serves as the negative control. Bars represent means \pm SEM (n = 4); each replicate is shown as a dot. **** $p \leq 0.0001$.

(F) Survival (%) of Δhsp104 yeast transformed with empty vector (pRS313HSE), Hsp104, Hsp104^{E190K}, or Hsp104^{R419E} after 20 or 30 min of heat shock at 50°C following a pretreatment at 37°C for 30 min. Bars represent means \pm SEM (n = 4); each replicate is shown as a dot. ns, not significant; **** $p \leq 0.0001$. (G) Δhsp104 yeast from (F) were incubated at 37°C for 30 min to induce Hsp104 expression. Yeasts were then lysed and processed for western blot. 3-Phosphoglycerate kinase 1 (PGK1) serves as a loading control.

See also Figure S1.



Interprotomer NBD1:MD interactions of the ATP state are essential for Hsp104 collaboration with Hsp70

To alter interactions between NBD1 and MD helix L1 in the ATP state, we first modified the charges of four of the NBD1:MD saltbridge interactions: E190:R419, R194:E412, R353:E427, and R366:D434 (Figure 1C). Thus, we constructed the opposite charge variants to perturb the salt bridges: Hsp104^{E190K} Hsp104^{R419E}, Hsp104^{R194E}, Hsp104^{E412K}, Hsp104^{R353E}, Hsp104^{E427K}, Hsp104^{R366E}, and Hsp104^{D434K}. Previously, we purified and measured the ATPase activity of Hsp104^{R194E} Hsp104^{E412K}, Hsp104^{R353E}, Hsp104^{E427K}, Hsp104^{R366E}, and Hsp104^{D434K 73} We found that these Hsp104 variants display wild-type (WT) levels of ATPase activity, which is stimulated by the disordered substrate casein.73 However, these variants cannot work with human Hsp70 (Hsc70 [HSPA8]) and Hsp40 (DnaJA1) to disaggregate and reactivate firefly luciferase trapped in chemically denatured aggregates.⁷³ We have now purified the remaining variants, Hsp104^{E190K} and Hsp104^{R419E}, which possessed WT levels (Hsp104^{E190K}) or approaching WT levels (~70% for Hsp104^{R419E}) of ATPase activity (Figure 1D). Hsp104^{E190K} and Hsp104^{R419E} also displayed limited ability to work with human Hsc70 and DnaJA1 to disaggregate and reactivate luciferase (Figure 1E, pink bars). These findings suggest that perturbation of the MD helix L1 interactions with NBD1 of the adjacent clockwise protomer in the ATP state does not grossly affect ATPase activity but reduces disaggregase activity.

It remained unclear, however, whether disruption of these contacts prevents Hsp104 from coupling ATP hydrolysis to protein disaggregation or whether they specifically reduce collaboration with Hsp70 and Hsp40. To distinguish between these possibilities, we first established that these Hsp104 variants bind to a model disordered substrate, β -casein, with the same affinity as Hsp104 (Figure S1A). Thus, substrate engagement appears unaffected by these mutations. We next assessed the intrinsic disaggregase activity of the Hsp104 variants in the presence of a 1:1 ratio of ATP and the slowly hydrolyzable ATP analog. ATP γ S. Hsp104 disaggregates and reactivates luciferase trapped in chemically denatured aggregates in the presence of a 1:1 ratio of ATP:ATP_YS in the absence of Hsp70 and Hsp40,^{20,79,85} thereby allowing assessment of whether the mutations perturbed the ability of Hsp104 to couple ATP hydrolysis to protein disaggregation. We found that all the Hsp104 variants tested could disaggregate and reactivate luciferase as well as or better than WT Hsp104 under these conditions (Figure 1E, gray bars). Indeed, Hsp104^{R194E} and Hsp104^{D434K} were more effective than Hsp104 (Figure 1E, gray bars). However, unlike Hsp104, none of these Hsp104 variants could collaborate with human Hsc70 and DnaJA1 to disaggregate and reactivate luciferase (Figure 1E, pink bars). These findings suggest that perturbation of the MD helix L1 interactions with NBD1 of the adjacent clockwise protomer in the ATP state can specifically impair Hsp70 collaboration and do not affect the ability of Hsp104 to couple ATP hydrolysis to protein disaggregation.

We next tested the ability of these Hsp104 variants to confer induced thermotolerance (i.e., ability to survive at 50°C after a 37°C pretreatment⁸⁶) in $\Delta hsp104$ yeast. Previously, we tested Hsp104^{R194E}, Hsp104^{E412K}, Hsp104^{R353E}, Hsp104^{E427K}, Hsp104^{R366E}, or Hsp104^{D434K}, which were unable to confer

Cell Reports Article


induced thermotolerance.⁷³ Hsp104^{R366E} displayed some limited activity, which was greater than the other variants but was still largely ineffective.⁷³ These findings suggest that Hsp104 collaboration with Hsp70 and Hsp40 is critical for thermotolerance *in vivo*.⁸⁷ We now extend this analysis to Hsp104^{E190K} and Hsp104^{R419E}. Hsp104^{E190K} exhibited impaired activity as with other NBD1:MD variants⁷³ (Figure 1F) and was expressed at similar levels to Hsp104 (Figure 1G). Surprisingly, however, Hsp104^{R419E} could confer induced thermotolerance like Hsp104 after 20 min but displayed reduced activity at 30 min (Figure 1F). Hsp104, Hsp104^{E190K}, and Hsp104^{R419E} were all expressed at similar levels (Figure 1G). One possible explanation for the activity of Hsp104^{R419E} and the residual activity of Hsp104^{R366E} might be an ability to collaborate with a subset of Hsp70 or Hsp40 homologs in yeast.

Residues and salt-bridge interactions in the interprotomer NBD1:MD helix L1 interface regulate Hsp40 compatibility for Hsp104-Hsp70 disaggregase activity

To assess this possibility, we purified yeast Hsp70 homolog Ssa1, class A Hsp40 Ydj1, and class B Hsp40 Sis1 to test their ability to collaborate with the Hsp104 variants in luciferase disaggregation and reactivation *in vitro*. Hsp104^{E190K}, Hsp104^{R194E}, Hsp104^{R353E}, Hsp104^{E427K}, and Hsp104^{D434K} cannot disaggregate and refold luciferase in the presence of Ssa1 plus Sis1, Ssa1 plus Ydj1, or Ssa1 plus Sis1 and Ydj1 (Figure 2A). Thus, these Hsp104^{R366E} displayed some activity in the presence of Ssa1 plus Sis1 plus Sis1 or Ssa1 plus Sis1 and Ydj1, but not Ssa1 plus Ydj1 (Figure 2A). Thus, Hsp104^{R366E} are selectively defective in collaboration with the class A Hsp40, Ydj1.

We next asked whether Hsp104^{R419E} and Hsp104^{R366E} collaboration with Hsp70 was also impaired. Thus, we tested the Ssa1 dose-dependent disaggregation activity of Hsp104 (positive control), Hsp104^{R366E}, Hsp104^{R419E}, and Hsp104^{D434K} (negative control) in the absence of Hsp40. Hsp104^{D434K} is incapable of working with Ssa1 to disaggregate luciferase, whereas Hsp104^{R419E} and Hsp104^{R366E} remain partially active but have reduced activity compared to Hsp104 (Figure 2B). Together with the yeast thermotolerance results (Figure 1F),⁷³ our findings suggest that Hsp104^{E190K}, Hsp104^{R194E}, Hsp104^{E112K}, Hsp104^{R353E}, Hsp104^{E427K}, and Hsp104^{D434K} are completely impaired for collaboration with Hsp70, whereas Hsp104^{R419E} and Hsp104^{R366E} can partially work with Hsp70.

Next, we examined Hsp40 compatibility with Hsp104^{R419E} and Hsp104^{R366E} in more detail. Thus, we assessed luciferase disaggregation and reactivation at fixed Hsp104^{R419E} or Hsp104^{R366E} (1 μ M) and Ssa1 (0.167 μ M) concentrations with increasing amounts of Sis1 or Ydj1. Remarkably, Hsp104^{R419E} and Hsp104^{R366E} were unable to collaborate with Ydj1 (Figure 2C), whereas they could collaborate with Sis1 (Figure 2D). By contrast, Hsp104 and a canonical potentiated variant, Hsp104^{A503S,42} were active with Ydj1 or Sis1, although Ydj1 inhibited activity at high concentrations whereas Sis1 did not (Figure 2E and 2F). Notably, Hsp104^{A503S} is much more active



than Hsp104 at low Ydj1 concentrations (Figure S1B).⁴² However, at the optimal Sis1 or Ydj1 concentrations, the disaggregase activities of Hsp104 and Hsp104^{A503S} are similar (Figures 2E and 2F). Our findings suggest that Hsp104^{R419E} and Hsp104^{R366E} can partially work with Ssa1 (Figure 2B), but their luciferase reactivation activity is more sensitive to inhibition by Ydj1 (Figure 2C). Thus, Hsp104 collaboration with Ydj1 during luciferase disaggregation and reactivation requires R366 in NBD1 and R419 in MD helix L1.

Ydj1 but not Sis1 can dissociate substrates from Hsp104 and inhibit the spontaneous refolding of unfolded luciferase

Bell-shaped reactivation curves were observed for all Hsp104 variants as a function of Ydj1 concentration, indicating that the synergistic cooperativity of Hsp104-Ssa1-Ydj1 is regulated by the Ydj1 concentration (Figures 2C and 2E). In the tested concentration range, an inhibitory effect of Sis1 on luciferase disaggregation and reactivation activity was not observed (Figures 2D and 2F). The inhibition of protein disaggregation and reactivation by high Ydj1 concentrations could be due to substrate competition between Ydj1 and an Hsp104-Hsp70 complex, which may resemble the "hook effect" of proteolysis targeting chimera (PROTAC) molecules (i.e., high concentrations of a linker



Figure 2. Specific perturbation of ATP-specific NBD1:MD helix L1 contacts yields Hsp104 variants that collaborate selectively with class B Hsp40s

(A) Luciferase disaggregation and reactivation activity of the indicated Hsp104 variants (1 μ M, monomer) in the presence of: Hsc70 (0.167 μ M)) and DnaJA1 (0.167 μ M; black); Ssa1 (0.167 μ M), Ydj1 (0.083 μ M), and Sis1 (0.083 μ M; pink); Ssa1 (0.167 μ M) and Ydj1 (0.167 μ M; green); or Ssa1 (0.167 μ M) and Sis1 (0.167 μ M; purple). Bars represent means ± SEM (n = 2-4); each replicate is shown as a dot.

(B) Luciferase disaggregation and reactivation activity of Hsp104 (gray dots), Hsp104^{R366E} (black dots), Hsp104^{R419E} (red dots), or Hsp104^{D434K} (teal dots; 1 μ M, monomer) in the presence of various Ssa1 (Hsp70) concentrations in the absence of Hsp40. Curves were fit for absolute EC₅₀ (see STAR Methods and Table S1). Values represent means \pm SEM (*n* = 2).

(C and D) Luciferase disaggregation and reactivation activity of Hsp104^{R366E} (1 μ M monomer) plus Ssa1 (0.167 μ M; black) or Hsp104^{R419E} (1 μ M monomer) plus Ssa1 (0.167 μ M; red) as a function of Ydj1 (C) or Sis1 (D) concentration. Curves were fit for IC₅₀ of Ydj1 and EC₅₀ of Ydj1 or Sis1 (see STAR Methods and Table S1). Values represent means ± SEM (*n* = 2).

(E and F) Luciferase disaggregation and reactivation activity of Hsp104 (1 μ M, monomer) plus Ssa1 (0.167 μ M; gray) or Hsp104^{A503S} (1 μ M, monomer) plus Ssa1 (0.167 μ M; green) as a function of Ydj1 (E) or Sis1 (F) concentration. Curves were fit for IC₅₀ of Ydj1 and EC₅₀ of Ydj1 or Sis1 (see STAR Methods and Table S1). Values represent means ± SEM (n = 2).

See also Figures S1 and S2; Table S1.

[in this case Ydj1] suppresses formation of ternary complexes due to excessive formation of binary complexes).⁸⁸ Additionally or alternatively, this effect might be explained by excess Ydj1 binding to unfolded luciferase released by Hsp104 and preventing it from refolding.

The class A Hsp40, Ydj1, has six sites involved with substrate binding in each dimer.⁸⁹ These sites reside in client-binding domain 1 (CBD1), client-binding domain 2 (CBD2), and the zincfinger domain.⁸⁹ By contrast, the class B yeast Hsp40, Sis1, contains CBD1, but lacks CBD2.⁸⁹ Thus, Ydj1 may have a higher affinity for interacting with the substrate than Sis1, which might compete with Hsp104 for substrate binding. To test this idea, we preformed Hsp104: β -casein complexes in the presence of ATP γ S and titrated them in Ydj1 or Sis1. Hsp104^{R419E} and Hsp104^{R366E} bind to casein with similar affinity as Hsp104 (Figure S1). As predicted, Ydj1 can compete for β -casein (30 nM) from Hsp104^{R419É}, Hsp104^{R366É}, and Hsp104 at a half-maximal inhibitory concentration (IC₅₀) of ${\sim}20\text{--}40~\mu\text{M}$ (Figure S2A and Table S1), whereas Sis1 cannot (Figure S2B). This IC₅₀ value is similar to that of Ydj1 for inhibition of luciferase disaggregation and reactivation by Hsp104 at \sim 14 μ M (Figure 2E and Table S1). By contrast, Hsp104^{R419E} and Hsp104^{R366E} are inhibited by much lower concentrations of Ydj1 in luciferase disaggregation and reactivation (Figure 2C and Table S1). These results suggest






Figure 3. Rewiring the ATP-specific interprotomer NBD1:MD helix L1 interaction alters Hsp104 collaboration with Hsp70 and Hsp40 (A) Luciferase disaggregation and reactivation activity of the indicated Hsp104 variants (1 μ M, monomer) in the absence (gray bars) or presence (black bars) of Hsc70 (0.167 μ M) and DnaJA1 (0.167 μ M). Bars represent means \pm SEM (n = 2-4); each replicate is shown as a dot. One-way ANOVA Dunnett's test was performed to compare Hsp104 to Hsp104 variants at a 95% confidence interval (Cl). The luciferase disaggregation and reactivation activity of all tested Hsp104 variants with Hsc70 & DnaJA1 is significantly different from Hsp104 with Hsc70 & DnaJA1 with **** $p \leq 0.0001$ (statistics are omitted for clarity). (B) Left panels: spotting assay to evaluate the survival of $\Delta hsp104$ yeast transformed with empty vector (no Hsp104) or the indicated Hsp104 variants (WT, wild type) after a 30-min pretreatment at 37°C followed by a 30-min heat shock at 50°C. $\Delta hsp104$ yeast that were not heat shocked are shown on the left as a control. Right panels: yeast survival (percentage of WT Hsp104) was quantified. Bars represent means \pm SEM (n = 4), and each replicate is shown as a dot. One-way ANOVA Dunnett's tests were performed to compare Hsp104 variants to no-Hsp104 control (left) or WT (right) at 95% Cl. ns, not significant; *** $p \leq 0.0001$; **** $p \leq 0.0001$. One-way ANOVA Tukey tests were performed to make pairwise comparisons between specific Hsp104 variants as indicated (left), **** $p \leq 0.0001$.

that Ydj1 may compete for substrate binding to Hsp104, which may contribute to the inhibition of Hsp104-mediated luciferase disaggregation and reactivation at high Ydj1 concentrations. However, this mode of inhibition does not readily explain the inhibition of Hsp104^{R419E} and Hsp104^{R366E} by low Ydj1 concentrations.

We wondered whether Ydj1 might inhibit the refolding of the small amounts of luciferase released by Hsp104^{R419E} and Hsp104^{R366E}, which would severely restrict their luciferase reactivation activity. Thus, we next tested whether Ydj1 or Sis1 can inhibit spontaneous refolding of soluble unfolded luciferase. For this purpose, we unfolded native luciferase (at the luciferase concentrations indicated in Figure S2C) with 6 M urea on ice for 5 min. We then diluted the soluble unfolded luciferase into buffer and verified the spontaneous refolding of luciferase over 90 min (Figure S2C). At high concentrations, Ydj1 can inhibit this spontaneous refolding of soluble luciferase, but this inhibition is dependent on the luciferase concentration (Figure S2D). For low concentrations of unfolded luciferase (1 nM or 2 nM), Ydj1 inhibits spontaneous refolding with an IC₅₀ of \sim 3 μ M (Figure S2D). At higher concentrations of unfolded luciferase (10 nM or 20 nM), inhibition by Ydj1 is insignificant, and the IC₅₀ cannot be determined for the tested Yjd1 concentration range (Figure S2D). By contrast, Sis1 does not inhibit luciferase refolding at all tested luciferase concentrations (Figure S2E). These results indicate that when small amounts of luciferase are released from aggregates by Hsp104, its refolding can be inhibited by excess Ydi1. We suggest that Hsp104 releases more unfolded luciferase than Hsp104^{R419E} and Hsp104^{R366E}, and thus higher Ydj1 concentrations are needed to inhibit Hsp104 than Hsp104^{R419E} or Hsp104^{R366E}. Collectively, these findings suggest that reduced ability to collaborate with Ssa1 and inhibition by Ydi1 render Hsp104^{R419E} and Hsp104^{R366E} hypomorphic in vitro and in vivo. These findings also emphasize the importance of Hsp104 collaboration with Ssa1 and Ydj1 for thermotolerance in vivo, as the Hsp104 variants that can only work with Ssa1 and Sis1 are hypomorphic.^{87,90,91}

Rewiring the interprotomer NBD1:MD helix L1 interaction alters Hsp104 collaboration with Hsp70 and Hsp40

We next tested whether rewiring salt-bridge interactions between NBD1 and MD helix L1 could restore Hsp104 collaboration with Hsp70 and Hsp40. Thus, we generated



Hsp104^{E190K:R419E}, Hsp104^{E190R:R419E}, Hsp104^{R194E:E412K}, Hsp104^{R353E:E427K}, Hsp104^{R353E:E427R}, Hsp104^{R366E:D434K}, and Hsp104^{R366E:D434R}, which would be predicted to have reconstructed salt bridges between NBD1 and MD helix L1 in the ATP state (Figure 1C). However, in these variants the location of the acidic and basic partner residues is reversed compared to Hsp104.

We first assessed the activity of these Hsp104 variants in luciferase disaggregation and reactivation. To our surprise, Hsp104^{E190K:R419E} and Hsp104^{E190R:R419E} show enhanced activity compared to Hsp104 in the absence or presence of human Hsc70 and DnaJA1 (Figure 3A). Remarkably, Hsp104^{E190K:R419E} and Hsp104^{E190R:R419E} exhibited similar activity with or without Hsc70 and DnaJA1 (Figure 3A). The increased level of activity of Hsp104^{E190K:R419E'} and $\mathsf{Hsp104}^{\mathsf{E190R};\mathsf{R419E}}$ and their independence from Hsp70 is consistent with potentiated Hsp104 activity. 42,43,54,66,72,77,78 Indeed, these variants also exhibited increased ATPase activity, another indicator of potentiated activity (Figure S3A).^{42,43,54,66,72,77,78} Thus, altering the charge orientation of the salt bridge between position 190 of NBD1 and position 419 of MD helix L1 potentiates Hsp104 activity (Figure 3A). Intriguingly, this potentiated activity was only uncovered at this position of the NBD1:MD helix L1 interaction, which may pinpoint a precise location where Hsp70 activates Hsp104.

Indeed, Hsp104^{R194E:E412K}, Hsp104^{R353E:E427K}, Hsp104^{R353E:E427R}, Hsp104^{R366E:D434K}, and Hsp104^{R366E:D434R} were inactive for luciferase disaggregation and reactivation in the presence or absence of human Hsc70 and DnaJA1 (Figure 3A). These variants retained ATPase activity, but it was reduced in comparison to Hsp104 (Figure S3A). To determine activity in vivo, we assessed their ability to confer induced thermotolerance $\Delta hsp104$ yeast. As expected, Hsp104^{R194E:E412K}, in Hsp104^{R194E:E412R}, Hsp104^{R353E:E427K}, and Hsp104^{R366E:D434K} were unable to confer induced thermotolerance (Figure 3B). Hsp104^{R353E:E427R} surprise. however. and Τo our $Hsp104^{R366E:D434R}$ conferred induced thermotolerance to \sim 67% of the level conferred by Hsp104 (Figure 3B). These Hsp104 variants were expressed at similar levels (Figure S3B). Thus, Hsp104^{R353E:E427R} and Hsp104^{R366E:D434R} are functional in vivo but fail to collaborate with human Hsc70 and DnaJA1 in vitro (Figures 3A and 3B).

⁽C) Luciferase disaggregation and reactivation activity of the indicated Hsp104 variants (1 μ M, monomer) in the presence of ATP/ATP γ S (2.5 mM) and the absence of Hsp70 and Hsp40. Bars represent means \pm SEM (n = 2); each replicate is shown as a dot. One-way ANOVA Dunnett's test was performed to compare Hsp104 variants to Hsp104 at 95% Cl. ns, not significant.

⁽D) Luciferase disaggregation and reactivation activity of the indicated Hsp104 variants (1 μ M monomer) in the presence of Ssa1 (0.167 μ M) and absence of Hsp40. Bars represent means \pm SEM (n = 4); each replicate is shown as a dot. One-way ANOVA Dunnett's test was performed to compare Hsp104 variants to WT Hsp104 at 95% CI. All variants have significantly reduced activity to work with Ssa1 compared to WT Hsp104 with $p \le 0.0001$ (statistics are omitted for clarity). Alternatively, one-way ANOVA Dunnett's test was performed to compare Hsp104 variants to no Hsp104. ns, not significant; **** $p \le 0.0001$.

⁽E) Luciferase disaggregation and reactivation activity of the indicated Hsp104 variants (1 μ M, monomer) in the presence Ssa1 (0.167 μ M) and Sis1 (0.167 μ M). Bars represent means ± SEM (*n* = 4); each replicate is shown as a dot. One-way ANOVA Dunnett's test was performed to compare Hsp104 variants to WT Hsp104 at 95% Cl. ns, not significant. All other variants have reduced activity with *p* ≤ 0.0001 (statistics are omitted for clarity). Alternatively, one-way ANOVA Dunnett's test was performed to compare Hsp104 variants to no Hsp104. ns, not significant; *****p* ≤ 0.0001.

⁽F) Luciferase disaggregation and reactivation activity of the indicated Hsp104 variants (1 μ M, monomer) in the presence of Ssa1 (0.167 μ M) and Ydj1 (0.167 μ M). Bars represent means ± SEM (*n* = 4); each replicate is shown as a dot. One-way ANOVA Dunnett's test was performed to compare Hsp104 variants to WT Hsp104 at 95% CI. All Hsp104 variants have reduced activity with **** $p \le 0.0001$ (statistics are omitted for clarity). Alternatively, one-way ANOVA Dunnett's test was performed to compare Hsp104 variants to no Hsp104. ns, not significant; **** $p \le 0.0001$. See also Figure S3.



To understand the concordance (for Hsp104^{R194E:E412K}, Hsp104^{R353E:E427K}, and Hsp104^{R366E:D434K}) and discordance (for Hsp104^{R353E:E427R} and Hsp104^{R366E:D434R}) between the *in vitro* and *in vivo* observations, we further dissected the activity of these variants *in vitro*. First, we found that the intrinsic luciferase disaggregation and reactivation activity of Hsp104^{R194E:E412K}, Hsp104^{R353E:E427K}, and Hsp104^{R366E:D434K}) in the presence of ATP:ATP_YS and the absence of Hsp70 and Hsp40 was like Hsp104 (Figure 3C). Thus, these variants can couple ATP hydrolysis to protein disaggregation and reactivation, indicating a specific defect in collaboration with Hsp70 and Hsp40.

Next, we assessed whether the functional interaction with Ssa1 was affected. Thus, we assessed luciferase disaggregation and reactivation in the presence of ATP plus Ssa1, but in the absence of Hsp40. Here, none of the variants had levels of activity comparable to Hsp104 (Figure 3D). Indeed, Hsp104^{R194E:E412K} and Hsp104^{R366E:D434K} were inactive, whereas Hsp104^{R353E:E427K} and Hsp104^{R366E:D434R} exhibited limited activity (Figure 3D). Hsp104^{R353E:E427R} exhibited ~40% Hsp104 activity, which is consistent with the ability of this variant to confer some induced thermotolerance (Figure 3B). Nonetheless, these findings suggest that these Hsp104 variants have reduced ability to collaborate directly with Ssa1.

We then added the class B Hsp40, Sis1, or class A Hsp40, Ydj1, together with Ssa1 and assessed luciferase disaggregation and reactivation activity (Figures 3E and 3F). Here, Hsp104^{R194E:E412K} and Hsp104^{R366E:D434K} are inactive with Ssa1 plus Sis1 or Ydj1 (Figures 3E and 3F), which explains the inability of these Hsp104 variants to confer induced thermotolerance (Figure 3B). Hsp104^{R353E:E427K} and Hsp104^{R366E:D434R} both exhibited ~60% of Hsp104 activity with Ssa1 plus Sis1 (Figure 3E) and limited activity with Ssa1 and Ydj1 (Figure 3F). Hsp104^{R366E:D434R} (~24% of Hsp104) was slightly more active with Ssa1 and Ydj1 than Hsp104^{R353E:E427K} (~15% of Hsp104) (Figure 3F), which may help explain why Hsp104^{R366E:D434R} confers some induced thermotolerance in yeast, whereas Hsp104^{R353E:E427K} confers limited induced thermotolerance (Figure 3B).

Notably, Hsp104^{R353E:E427R} displayed WT levels of activity with Ssa1 and Sis1 (Figure 3E) and ~42% Hsp104 activity with Ssa1 and Ydj1 (Figure 3F), which helps explain why this variant confers induced thermotolerance in vivo (Figure 3B), despite limited activity with human Hsc70 and DnaJA1 (Figure 3A). Indeed, it appears that the reconfigured NBD1:MD helix L1 salt bridge of Hsp104^{R353E:E427K}, Hsp104^{R353E:E427R}, and Hsp104^{R366E D434R} creates a species barrier between yeast Hsp104 and human Hsc70 and DnaJA1, i.e., Hsp104^{R353E:E427K}, Hsp104^{R353E:E427R}, and Hsp104^{R366E:D434R} do not work well with human Hsc70 and DnaJA1 but are functional with yeast Ssa1 and Ydj1. Thus, it appears that the interprotomer interactions between NBD1 and MD helix L1 of the ATP state can be altered to establish species barriers between Hsp104 and Hsp70, which can occur naturally as with the barrier between yeast Hsp104 and bacterial Hsp70.^{21,81}

Cell Reports Article

Collectively, these results establish that the ATP-specific interprotomer interactions between NBD1 and MD helix L1 (Figure 1A) function to regulate Hsp104 collaboration with Hsp70 and Hsp40. Perturbation of these contacts can reduce Hsp70 and Hsp40 collaboration without potentiating activity (Figure 2A). Surprisingly, specific perturbation of this network yields hypomorphic Hsp104 variants that collaborate selectively with class B Hsp40s as with Hsp104^{R419E} and Hsp104^{R366E} (Figures 2A, 2C, and 2D). Additionally, specific rewiring of this network potentiates Hsp104 activity as with Hsp104^{E190K:R419E} and Hsp104^{E190R:R419E} (Figure 3A). Rewiring the network in other ways can greatly reduce collaboration with Hsp70 and Hsp40 without affecting the intrinsic disaggregase activity of Hsp104 as with Hsp104^{R194E:E412K} and Hsp104^{R366E:D434K} (Figures 3C-3F). Remarkably, reconfiguring the NBD1:MD helix L1 network in yet further ways can create species barriers with human Hsp70 as with Hsp104^{R353E:E427R} and Hsp104^{R366E:D434R} 3A, 3E, and 3F). Hsp104^{R353E:E427R} (Figures and Hsp104^{R366E:D434R} operate more similarly to Hsp104 with the class B Hsp40, Sis1, but exhibit reduced activity with class A Hsp40, Ydj1 (Figures 3E and 3F), and confer up to \sim 67% of WT Hsp104 levels of induced thermotolerance in vivo (Figure 3B). This finding suggests that collaboration with just Sis1 is insufficient for Hsp104 to confer induced thermotolerance in vivo.87,90,91 Indeed, collaboration with Sis1 and Ydj1 appears critical for WT levels of Hsp104 activity in vivo.^{87,90-92} Overall. we conclude that ATP-specific interprotomer interactions between NBD1 and MD helix L1 control several aspects of collaboration between Hsp104 and Hsp70 plus Hsp40.

Perturbing the intraprotomer NBD1:MD contacts of the ADP state frequently potentiates Hsp104 activity

In contrast to the ATP state, the MD primarily interacts with NBD1 within the same subunit of the hexamer in the presence of ADP (Figure 1B). The role of these intraprotomer contacts in comparison to the interprotomer NBD1:MD contacts of the ATP state has remained unclear. Therefore, we explored 31 interactions involving 14 NBD1 residues and 19 MD residues in the interaction surface presented in Figure 1B. We designed 46 mutations aiming to alter these interactions, of which 16 have been tested previously.^{42,43,53,72,73,77} Thus, we generated 30 additional single missense Hsp104 variants expected to alter the interactions of this interface (Table S2 and Figure 1B).

We then assessed these Hsp104 variants for the ability to suppress the toxicity of α -synuclein, FUS, and TDP-43 in $\Delta hsp104$ yeast.⁴² Here, Hsp104 and the vector control are unable to mitigate α -synuclein, FUS, and TDP-43 toxicity, whereas positive control potentiated Hsp104 variants, Hsp104^{A503V} or Hsp104^{A503S}, strongly suppress toxicity.⁴² We find that \sim 72% (33/46) of the Hsp104 variants designed to weaken the intraprotomer NBD1:MD interactions of the ADP state potentiate activity and enable mitigation of α -synuclein, FUS, and TDP-43 toxicity (Table S2). Among the 30 additional Hsp104 variants tested in this work, we found 18 variants that enhanced activity and 12 variants that did not (Figure 4 and Table S2). Among the 18 potentiated variants, only two variants (I361K and K470D) present off-target toxicity to yeast at 37°C (Figure S4A). Moreover, the expression level of Hsp104 variants in yeast is verified



Α	α -synu	clein	в	FUS	5	c .	TDP-4	3
Vec 👔		a a t	Vec 🛛			Vec 🕻	💧 🌢 🍈 🏶 🎘 🍯	
WT		3 3 4 A	WT		.*	WT 🕻	🕒 🔴 🗑 🗑 🖉 🧐	
A503S 🚺		 ●●● 律 4 	A503S			A503S		
R179D 🤇	••• •	🖣 🌑 🚳 😢 🧐	R179D) • • • • • • • •	D. @	R179D		3
R179V 🤇		18 18 A	R179V			R179V		
D231R		19	D231R		Cherry Cherry	D231R		
D232V 🧧		🖗 🖗 <u>' a - '</u>	D232V			D232V		
D233R		9 (V · · · · · · · · · · · · · · · · · ·	D233R			D233R		
I361K			I361K			I361K		
R407E			R407E		👹 🕅 · · ·	R407E		
D408K			D408K		🕘 🛞 3	D408K		
D408V			D408V		•	D408V		A (* •)
K410E K410V			K410E			K410E K410V		
L414K			K410V L414K		6 4 4 · · · · ·	L414K		
R463E			R463E			R463E		
R4635			R463E			R4635		
Y466C			Y466C		 (a) (b) (c) (c) (c) (c) (c) (c) (c) (c) (c) (c	Y466C		
Y466K			Y466K			Y466K		
E469R		3 4	E469R		0	E469R		
K470D		.	K470D		🔴 🚳 🍪 🍪 👘	K470D		0.0
H473F		\$	H473F	🕨 🔍 🕲 🕲 🗮 📢		H473F		
H4735) • • • • · · · ·	🕽 🚭 🏶 🍀 🌾	H473S	• • • • * *	🕐 🌚 🛞 🖉	H473S		
K480C			K480C	• • • • • • •	🔵 🚳 🍪 👘 👘	K480C		
K480L		🕽 🕲 🎯 🏦 🏤 🛸	K480L	● ● ● ● ♣ ÷•	🕘 🚳 🏶 👘 👘	K480L		🖗 🧐
K481C 🤇			K481C		1 A A A A A A A A A A A A A A A A A A A	K481C		
K481L 🕻			K481L			K481L		
K481E 🤇		🕒 🕘 🏟 🏟 🍇	K481E			K481E		
D492R 🚺) • • • • • • • •		D492R	🔵 🔵 🌒 🍪 💥 🐰		D492R) X & O O) 4
R496D			R496D			R496D		
R496V	·······························		R496V			R496V		9 SF
E521R			E521R			E521R		
1537A			1537A			1537A		
1537R 🤇			1537R			1537R		
	Glu (off)	Gal (on)		Glu (off)	Gal (on)		Glu (off)	Gal (on)

Figure 4. Perturbing the intraprotomer NBD1:MD contacts of the ADP state frequently potentiate Hsp104 activity

 $\Delta hsp104$ yeast integrated with α -synuclein-YFP (A), FUS (B), or TDP-43 (C) on a galactose-inducible promoter were transformed with the indicated Hsp104 variants that perturb the intraprotomer NBD1:MD contacts of the ADP state. Empty vector and WT Hsp104 are negative controls, and Hsp104^{A503S} is a positive control. Yeast were spotted onto glucose (induction is off) and galactose (induction is on) media in a 5-fold serial dilution. Potentiated Hsp104 variants are highlighted in red. Western blots were performed to evaluate Hsp104 expression. See also Figure S4 and Table S2.

(Figure S4B), and all 30 Hsp104 variants are expressed. These results suggest that the intraprotomer NBD1:MD interactions observed in the ADP state function to restrict Hsp104 activity. However, Hsp104 disaggregase activity can be unleashed by weakening these intraprotomer NBD1:MD interactions, resulting in potentiated variants with low off-target toxicity.

Among the 18 potentiated variants found in this work, Hsp104^{Y466C}, Hsp104^{K48C}, Hsp104^{K481E}, Hsp104^{R496D}, Hsp104^{I537A}, and Hsp104^{I537R} present strong activity in mitigating α -synuclein, FUS, and TDP-43 toxicity with minimal off-target toxicity, and resemble Hsp104^{A503S} (Figures 4 and S4A).⁴² By contrast, Hsp104^{I361K}, Hsp104^{Y466K}, Hsp104^{K470D}, Hsp104^{H473S}, Hsp104^{K480L}, Hsp104^{K481L}, and Hsp104^{E521R} show slightly reduced activity compared to Hsp104^{A503S} (Figure 4), whereas Hsp104^{R179D}, Hsp104^{R407E}, Hsp104^{D408K}, and Hsp104^{D408V} are further reduced but still can mitigate α -synuclein, FUS, and TDP-43 toxicity (Figure 4). Hsp104^{L414K} presents the lowest activity of the 18 potentiated Hsp104 variants (Figure 4). Hsp104^{L414K} mitigates α -synuclein and FUS toxicity but

is unable to reduce TDP-43 toxicity (Figure 4). Interestingly, a valine scan of the entire MD only identified Hsp104^{R496V} and Hsp104^{K480V} with potentiated activity among these same sites,⁵³ highlighting the power of making rational, targeted mutations to potentiate activity.

Restricting Hsp104 activity in the absence of Hsp70 reduces off-target toxicity of potentiated Hsp104 variants

Potentiated Hsp104 variants can exhibit unfavorable off-target toxicity, especially at 37°C in yeast.^{42,43,77} Hsp104 likely recognizes unfolded regions of proteins with a bias for peptides of a certain amino acid composition rather than any specific sequence.⁹³ Thus, it was proposed that potentiated Hsp104 variants may recognize and unfold metastable proteins, which results in toxicity.^{42,77} One concept is that Hsp70 may direct Hsp104 to aggregated structures and away from soluble misfolded polypeptides or naturally metastable proteins.⁸⁰ Since potentiated Hsp104 variants can function independently of






Figure 5. Restricting Hsp104 activity in the absence of Hsp70 reduces off-target toxicity of potentiated Hsp104 variants

(A) $\Delta hsp104$ yeast was transformed with the indicated galactose-inducible Hsp104 variants or an empty vector or Hsp104 control. Yeast was spotted onto glucose (induction off) and galactose (induction on) media in a 5-fold serial dilution. Yeast were incubated on a glucose plate at 37°C (left) or on a galactose plate at 30°C (middle) or 37°C (right). Note that Hsp104^{1187F} is more toxic than Hsp104^{E360R} or Hsp104^{S335E}. Hsp104^{E360R} and Hsp104^{S535E} are similar to Hsp104 at 37°C on galactose.

(B) RepA₁₋₁₅-GFP (0.7 μ M) unfolding activity of the indicated Hsp104 variant (6 μ M, monomer) in the presence of ATP (4 mM) and GroEL_{trap} (2.5 μ M). RepA₁₋₁₅-GFP unfolding (%) was assessed by the RepA₁₋₁₅-GFP fluorescence signal at the indicated time (F), divided by the RepA₁₋₁₅-GFP fluorescence signal at time 0 (F0). Left: kinetics of RepA₁₋₁₅-GFP unfolding. Results from a representative experiment are shown. Right: the half-time of RepA₁₋₁₅-GFP unfolding for each Hsp104 variant. Bars represent means \pm SEM (*n* = 2); each replicate is shown as a dot. One-way ANOVA Tukey test was performed to compare the half-time of Hsp104 variants at 95% CI. **p* = 0.0117, ***p* = 0.0012 for 1187F vs. E360R; ***p* = 0.0063 for E360R vs. S535E.

(C) Luciferase disaggregation and reactivation by Hsp104, Hsp104^{I187F}, Hsp104^{E360R}, or Hsp104^{S535E} in the absence of Hsp70 and Hsp40. The indicated Hsp104 variant (1 μ M, monomer) was incubated with chemically denatured luciferase aggregates (100 nM monomer concentration) for 90 min. Bars represent means \pm SEM (n = 4); each replicate is shown as a dot. One-way ANOVA Tukey test was performed to compare the level of reactivated luciferase aggregates by Hsp104 variants at 95% Cl. **** $p \leq 0.0001$.

(D–F) Luciferase disaggregation and reactivation by Hsp104 (black curve), Hsp104^{I187F} (D, red curve), Hsp104^{E360R} (E, green curve) and Hsp104^{S535E} (F, green curve) as a function of Ssa1 concentration as indicated on the x axis (log scale). The indicated Hsp104 variant (1 μ M, monomer) in the presence of various Ssa1 concentrations was incubated with chemically denatured luciferase aggregates (100 nM monomer concentration). Values represent means \pm SEM (n = 2). A bell-shaped dose-dependent curve is used to fit the data; see STAR Methods.

Hsp70 to varying extents, ^{42,43,77,78} this mechanism of substrate selection may become dysregulated such that excessive soluble polypeptide unfolding drives off-target toxicity. However, WT Hsp104 is too tightly regulated and is unable to overcome wide-spread aggregation by neurodegenerative disease proteins such as TDP-43, FUS, and α -synuclein in yeast. ^{42,43,77,78} Thus, we hypothesize that potentiated Hsp104 variants with reduced unfoldase activity for soluble proteins, and partial independence from Hsp70, may reside in an advantageous therapeutic window. These Hsp104 variants would preferentially target aggregated proteins without excessive and toxic unfolding of soluble proteins. Thus, we set out to test whether potentiated Hsp104

variants with greater off-target toxicity have stronger unfoldase activity against soluble proteins and less dependence on Hsp70 for protein disaggregation.

To test this concept, we selected several Hsp104 variants with a range of off-target toxicities: Hsp104 (no off-target toxicity), Hsp104^{S535E} (an MD variant with minimal off-target toxicity), Hsp104^{E360R} (an NBD1 variant with minimal off-target toxicity), and Hsp104^{I187F} (an NBD1 variant with significant off-target toxicity) (Figure 5A).^{42,77,78} We then assessed the ability of these Hsp104 variants to unfold the model substrate RepA₁₋₁₅-GFP, which is composed of the N-terminal 15 residues of RepA appended to the N terminus of GFP.⁹⁴ The RepA₁₋₁₅ tag






Figure 6. Rational design of potentiated Hsp104 variants with minimized off-target toxicity

(A) NBD1 (blue) residues E190, E191, and E192 (in red) form a rheostat-like interaction with R419 (black) in the MD (colored pink) of the adjacent subunit. Hsp104 variants are designed to alter these interactions like a rheostat (right panel) to tune Hsp104-Hsp70 interaction to a suitable level of potentiated activity without off-target toxicity.

(B–D) Spotting assay testing the ability of Hsp104 variants to mitigating α-synuclein, FUS, and TDP-43 toxicity in yeast. Δ*hsp104* yeast integrated with α-synuclein (B), FUS (C), and TDP-43 (D) on a galactose-inducible promoter were transformed with Hsp104 variants or an empty vector, WT Hsp104, or Hsp104^{A503S} controls.

(legend continued on next page)



is a short, unfolded region, which is sufficient to target RepA₁₋₁₅-GFP for unfolding by potentiated Hsp104 variants. By contrast, Hsp104 does not unfold RepA₁₋₁₅-GFP in the presence of ATP (Figure 5B). Strikingly, however, we find Hsp104^{I187F}, which has the most off-target toxicity, unfolds RepA₁₋₁₅-GFP the most rapidly, whereas the less toxic Hsp104 variants, Hsp104^{S535E} and Hsp104^{E360R}, unfold RepA₁₋₁₅-GFP less rapidly than Hsp104^{I187F} (Figure 5B). Hence, off-target toxicity correlates positively with stronger unfoldase activity against soluble protein.

To measure the Hsp70 dependence for Hsp104 disaggregase activity, we performed luciferase disaggregation and reactivation experiments in the absence of Hsp70 or Hsp40 (Figure 5C). Here, we find that Hsp104^{I187F} has the highest luciferase disaggregation and reactivation activity in the absence of Hsp70 or Hsp40 (Figure 5C). By contrast, Hsp104^{E360R} and Hsp104^{S535E} show significantly lower activity in the absence of Hsp70 and Hsp40, whereas Hsp104 is completely inactive as expected (Figure 5C).²¹ Thus, off-target toxicity correlates positively with stronger disaggregase activity in the absence of Hsp70 or Hsp40.

Next, we titrated Ssa1 (in the absence of Hsp40) into luciferase disaggregation and reactivation experiments with each potentiated Hsp104 variant versus Hsp104. Hsp104^{I187F} shows very little dependence on Ssa1 compared to Hsp104 (Figure 5D). By contrast, Hsp104^{E360R} shows stronger dependence on Ssa1 but outperforms Hsp104 at every Hsp70 concentration tested (Figure 5E). Intriguingly, Hsp104^{S535E} also shows Ssa1 dependence but is greatly stimulated at high Ssa1 concentrations (Figure 5F). Thus, potentiated Hsp104 variants with minimal off-target toxicity are also more dependent on Hsp70 for protein disaggregation.

Rationally designed potentiated Hsp104 with minimized off-target toxicity

Next, we developed Hsp104 variants with minimized off-target toxicity based on the design principles established above, i.e., reduced unfoldase activity for soluble proteins and partial independence from Hsp70 for protein disaggregation. Given that the ATP-specific interprotomer NBD1:MD helix L1 interface functions to regulate collaboration with Hsp70 and Hsp40 (Figures 2 and 3), we focused on this region to define modifications that tune Hsp70-Hsp40 collaboration to the desired level.

Cell Reports Article

Upon closer inspection of the ATP-specific NBD1:MD helix L1 interface, we observed that E190, E191, and E192 of NBD1 are positioned such that they could all potentially contact R419 (Figure 6A, left). E190, E191, and E192 are located at a loop between Helix B2 and B3 in NBD1 that forms a junction with MD helix L1 (Figure 6A, left). This loop may provide enough freedom for these residues to have a dynamic interaction with R419 and thus might function as a rheostat to finely tune collaboration with Hsp70. To test whether salt-bridge interactions between E190, E191, or E192 and R419 can regulate Hsp104 activity and collaboration with Hsp70 and Hsp40, we designed variants to rewire these interactions and modify MD orientation. Thus, we explored combinations of R419E with arginine substitutions at E190, E191, or E192. We tested whether these designed variants could mitigate α -synuclein, FUS, and TDP-43 toxicity in yeast and whether they exhibited off-target toxicity. All the Hsp104 variants were expressed at roughly similar levels and did not affect disease protein expression (Figure S5).

Previously, we found that Hsp104^{E190K:R419E} and Hsp104^{E190R:R419E} have enhanced disaggregase activity (Figure 3A). However, this activity was largely independent of Hsp70 and Hsp40, which predicts off-target toxicity (Figure 3A). In yeast, we found that these Hsp104 variants weakly suppressed α -synuclein toxicity (Figure 6B) but were unable to suppress FUS toxicity (Figure 6C) and very weakly suppressed TDP-43 toxicity (Figure 6D). This pattern of disease protein toxicity mitigation is unusual and has not been observed previously.^{42,43,51,72,77,78} Moreover, as predicted, these variants exhibited off-target toxicity at 37°C (Figure 6E). Hence, the E190 K/R:R419E variants have the rheostat dialed too far toward Hsp70 independence (Figure 6A, right).

By contrast, Hsp104^{E191R:R419E} and Hsp104^{E192R:R419E} strongly suppress α -synuclein, FUS, and TDP-43 toxicity (Figures 6B–6D). Importantly, these variants did not exhibit off-target toxicity (Figure 6E). Hence, the E191R:R419E and E192R:R419E variants have the rheostat dialed to an appropriate level of Hsp70 collaboration (Figure 6A, right).

Based on these observations, we would predict that Hsp104^{E190R:R419E} would unfold RepA₁₋₁₅-GFP more rapidly than Hsp104^{E191R:R419E} and Hsp104^{E192R:R419E}. We would also predict that Hsp104^{E190R:R419E} would be less dependent on Hsp70 than Hsp104^{E191R:R419E} and Hsp104^{E192R:R419E} for luciferase disaggregation and reactivation. These predictions were confirmed experimentally (Figures 6F and 6G). Collectively,


Yeast was spotted onto glucose (induction off) and galactose (induction on) media in a 5-fold serial dilution. The variants that have potentiated activity to mitigate disease protein toxicity in yeast are highlighted in bold.


⁽E) The toxicity of designed Hsp104 variants in yeast were evaluated at 37° C. $\Delta hsp104$ yeast was transformed with galactose-inducible Hsp104 variants or an empty vector, WT Hsp104, or Hsp104^{A503S} controls. The yeast was spotted onto glucose (induction off) and galactose (induction on) media in a 5-fold serial dilution. Yeast was incubated at 30° C (left) or 37° C (right) on galactose plates. The toxic variants are highlighted in red.

⁽F) RepA₁₋₁₅-GFP (0.7 μ M) unfolding kinetics by Hsp104^{E190R:R419E}, Hsp104^{E191R:R419E}, or Hsp104^{E192R:R419E} (6 μ M, monomer concentration) is measured in the presence of a GroEL_{trap} (2.5 μ M). RepA₁₋₁₅-GFP unfolding (%) was assessed by the RepA₁₋₁₅-GFP fluorescence signal at the indicated time (F) divided by the RepA₁₋₁₅-GFP fluorescence signal at time 0 (F0). Results from a representative experiment are shown. The half-time of RepA₁₋₁₅-GFP unfolding for each Hsp104 is shown on the right. Bars represent means \pm SEM (n = 2); each replicate is shown as a dot.

⁽G) Luciferase disaggregation and reactivation by Hsp104 (black curve), Hsp104^{E190R:R419E} (red curve, left), Hsp104^{E191R:R419E} (red curve, middle), and Hsp104^{E192R:R419E} (red curve, right) as a function of Ssa1 concentration. The indicated Hsp104 variant (1 μ M, monomer) in the presence of various Ssa1 concentrations as indicated on the x axis (log scale) was incubated with chemically denatured luciferase aggregates (100 nM monomer concentration) for 90 min. Error bars represent means ± SEM (*n* = 2). A bell-shaped dose-dependent curve is used to fit the data; see STAR Methods. See also Figure S5.







(legend on next page)



these findings suggest that interactions between NBD1 residues E190, E191, or E192 and MD helix L1 R419 function as a rheostat that can be adjusted to fine-tune collaboration with Hsp70.

Potentiated Hsp104 variants suppress FUS proteinopathy in human cells

A feature of degenerating neurons in various FUS proteinopathies, including ALS and frontotemporal dementia (FTD), is the depletion of FUS from the nucleus and the accumulation of FUS in cytoplasmic inclusions.¹⁰ Potentiated Hsp104 variants can mitigate cytoplasmic FUS aggregation and toxicity in yeast,⁴² but their activity in human cells has not been assessed. To this end, we utilized a human (HeLa) cell model by expressing mCherry-tagged Hsp104 and GFP-tagged FUS.⁹⁵ Importantly, elevated expression of WT FUS is connected with ALS.⁹⁶ Indeed, elevated expression of GFP-FUS elicited formation of cytoplasmic FUS aggregates in ~20% of cells (Figures 7A and 7B).⁹⁵ We selected a panel of potentiated variants with minimal off-target toxicity to assess in this system. Importantly, potentiated Hsp104 variants can significantly suppress FUS cytoplasmic mislocalization and aggregation, whereas Hsp104 cannot (Figure 7A). Indeed, Hsp104^{A503S}, Hsp104^{E191R:R419E} Hsp104^{E360R}, Hsp104^{K481E}, and Hsp104^{S535E} suppressed cytoplasmic FUS aggregation and maintained FUS in the nucleus (Figures 7A and 7B) without reducing FUS expression level (Figure S6A). Thus, enhanced Hsp104 variants provide a mechanism to mitigate aberrant cytoplasmic FUS aggregation in human cells.

Potentiated Hsp104 variants suppress TDP-43 proteinopathy in human cells

A unifying pathological feature of the TDP-43 proteinopathies, including ALS, FTD, Alzheimer's disease, limbic-predominant age-related TDP-43 encephalopathy, and chronic traumatic encephalopathy,^{97–104} is the aberrant cytoplasmic mislocalization and aggregation of TDP-43, an essential nuclear RNA-binding protein with a prion-like domain.^{105–113} Potentiated Hsp104 variants can antagonize cytoplasmic TDP-43 aggregation and restore TDP-43 to the nucleus in yeast.42,77 Moreover, Hsp104^{A503S} reduces cytoplasmic aggregation of mClover3-TDP-43^{ΔNLS} (i.e., mClover3-TDP-43 bearing K82A/R83A/K84A mutations in the nuclear localization signal [NLS] that promote cytoplasmic mislocalization¹¹⁴) in human cells,⁴⁴ but additional engineered Hsp104 variants have not been explored. Importantly, elevated expression of WT TDP-43 is connected with FTD,¹¹⁵ and disease-linked TDP-43 aggregation is proposed to increase TDP-43 expression due to loss of TDP-43 autoregula-

Cell Reports Article

tion.^{116,117} Here, we employed a human (HEK293) cell model expressing mCherry-tagged Hsp104 and YFP-tagged TDP- $43^{\Delta NLS}$. Elevated expression of YFP-tagged TDP- $43^{\Delta NLS}$ elicited formation of cytoplasmic TDP-43^{ΔNLS} aggregates in ~40% of cells (Figures 7C and 7D). Importantly, potentiated Hsp104 variants suppressed cytoplasmic TDP-43^{Δ NLS} aggregation, whereas Hsp104 did not (Figure 7C). Indeed, Hsp104^{A503S} Hsp104^{E191R:R419E}, Hsp104^{E360R}, Hsp104^{K481E}, and Hsp104^{S535E} suppressed cytoplasmic TDP-43^{△NLS} aggregation (Figures 7C and 7D) without reducing the TDP-43^{ΔNLS} expression level (Figure S6B). The effect of Hsp104^{E360R} was less pronounced than other potentiated Hsp104 variants (Figures 7C and 7D) but was statistically significant in comparison to Hsp104 but not the mCherry control (Figure 7D). By contrast, Hsp104^{A503S}, Hsp104^{E191R:R419E}, Hsp104^{K481E}, and Hsp104^{S535E} significantly reduced cytoplasmic TDP-43^{ΔNLS} aggregation in comparison to Hsp104 and the mCherry control (Figure 7D). Overall, these findings suggest that enhanced Hsp104 variants mitigate aberrant cytoplasmic TDP-43 aggregation in human cells.

DISCUSSION

In this work, we performed an intensive structure-function analysis of how ATP-specific or ADP-specific MD configurations regulate Hsp104 disaggregase activity. We determined that the ATP-specific interactions between MD helix L1 and NBD1 of the adjacent clockwise protomer are critical for Hsp104 to collaborate effectively with Hsp70 and Hsp40 during protein disaggregation. Specifically, salt-bridge interactions between NBD1 and MD helix L1 via E190:R419, R194:E412, R353:E427, and R366:D434 enable Hsp104 to collaborate with Hsp70 and Hsp40. Intriguingly, disrupting these interactions does not potentiate activity or affect the intrinsic disaggregase activity of Hsp104. Thus, Hsp104 can still couple ATP hydrolysis to substrate processing when these contacts are broken. However, the ability of Hsp104 to collaborate with Hsp70 and Hsp40 is specifically disrupted. These findings are surprising, as it was anticipated that these interactions would be important for intersubunit collaboration within the hexamer rather than collaboration with Hsp70 and Hsp40.

Intriguingly, we find that specific perturbations of the ATPspecific NBD1:MD helix L1 interactions (i.e., R419E or R366E) yielded hypomorphic Hsp104 variants. These Hsp104 hypomorphs confer some thermotolerance *in vivo*. In luciferase disaggregation and reactivation *in vitro*, Hsp104^{R419E} and Hsp104^{R366E} work selectively with Ssa1 and Sis1 and are unable to function with Ssa1 and Ydj1 or human Hsc70 and DnaJA1.

Figure 7. Potentiated Hsp104 variants suppress FUS and TDP-43 proteinopathies in human cells

(A) After 24 h, HeLa cells transfected with GFP-FUS (green) and mCherry, or Hsp104-mCherry (red), were fixed and imaged. DAPI is used to stain the nucleus. Representative images are shown. Scale bar, 20 μ m.

(D) Quantification of the percentage of cells with cytoplasmic TDP-43 foci. 810–2,580 cells were counted over 3–6 separate trials for each Hsp104 variant and mCherry control; data points represent independent transfections. Bars represent mean \pm SEM (n = 3–6). One-way ANOVA with correction for multiple comparisons to mCherry (left) or Hsp104^{WT} (right) by Dunnett's test was performed at 95% Cl. **** $p \le 0.0001$; ** $p \le 0.001$; ** $p \le 0.01$; * $p \le 0.05$.

⁽B) Quantification of the percentage of cells with cytoplasmic FUS foci. 500–800 cells were counted over four separate trials for each Hsp104 variant and mCherry control; data points represent independent transfections. Bars represent mean \pm SEM (n = 4). One-way ANOVA with correction for multiple comparisons by Dunnett's test was performed at 95% Cl. ** $p \le 0.01$; * $p \le 0.05$.

⁽C) After 24 h, HEK293 cells transfected with TDP-43^{ΔNLS}-YFP (green) and mCherry, or Hsp104-mCherry (red), were fixed and imaged. DAPI is used to stain the nucleus. Representative images are shown. Scale bar, 20 µm.

Thus, these Hsp104 variants displayed selectivity to function with the class B Hsp40, Sis1, but not class A Hsp40s, Ydj1 or DnaJA1. Hsp104^{R419E} and Hsp104^{R366E} were also less able to directly collaborate with Ssa1 directly (i.e., in the absence of Hsp40) and were inhibited by Ydj1. These findings emphasize the importance of ATP-specific NBD1:MD helix L1 interactions for productive collaboration with Hsp70 and class A Hsp40s. Moreover, they reinforce the importance of Hsp104 collaboration with Ssa1 and Ydj1 for thermotolerance *in vivo*.^{87,90,91}

Having identified the critical importance of ATP-specific NBD1:MD helix L1 interprotomer interactions, we next assessed the consequences of rewiring these connections. Notably, rebuilding the E190:R419 salt bridge to E190R:R419E or E190K:R419E yielded potentiated Hsp104 variants, which functioned independently of Hsp70. Remarkably, reconfiguring the NBD:MD helix L1 network in vet further ways can create species barriers with human Hsp70 as with Hsp104 R353E:E427R and Hsp104^{R366E:D434R}. Thus, manipulating the network of ATP-specific NBD1:MD helix L1 interprotomer interactions can: (1) reduce Hsp70 collaboration without enhancing activity; (2) generate hypomorphic Hsp104 variants that collaborate selectively with class B Hsp40s; (3) produce Hsp70-independent potentiated variants; or (4) create species barriers between Hsp104 and Hsp70. Collectively, these findings suggest that the ATP-specific NBD1:MD helix L1 interactions function to finely tune the level of collaboration with Hsp70 and Hsp40. Indeed, the ATP-specific network of interprotomer contacts between NBD1 and MD helix L1 appears to be poised as a capacitor that can release diverse phenotypes.

By contrast, the ADP-specific intraprotomer contacts between NBD1 and MD helix L2 function to restrict activity. When these contacts were disrupted (Figure 4 and Table S2), we observed enhanced Hsp104 activity in mitigating α -synuclein, FUS, and TDP-43 toxicity in yeast, indicating enhanced disaggregase activity of these variants. Indeed, we designed 46 variants to alter 31 ADP-specific intraprotomer contacts, and 33 variants exhibited potentiated activity (Figure 4 and Table S2). Disrupting these contacts likely increases the rate of ADP release from NBD1, which accelerates the Hsp104 motor.⁵⁴ Notably, many residues, such as D233, E360, E366, E412, and R419, are involved in both intraprotomer and interprotomer contacts between NBD1 and the MD, indicating a dynamic and highly regulated network of interactions, which likely enable communication within and between subunits during disaggregation.

Hsp104 adopts a dynamic structure, with each protomer rapidly switching between ATP and ADP states during functional processing of substrates.^{19,20,54,73,118} Our studies have identified important and distinct functions for NBD1:MD interactions for protomers in the ATP state versus the ADP state, which previously have not been fully appreciated. In the ATP state, interprotomer interactions between NBD1 and helix L1 of the MD are critical for collaboration with the Hsp70 system. Typically, breaking these contacts reduces collaboration with Hsp70 without potentiating Hsp104 activity. However, rewiring these contacts as in Hsp104^{E190K:R419E} and Hsp104^{E190R:R419E} can yield potentiated, Hsp70-independent variants. By contrast, in the ADP state, intraprotomer interactions between NBD1 and helix L2 are critical for restraining Hsp104 activity. Typically,



breaking these contacts potentiates Hsp104 activity. It is surprising that these functions are clearly partitioned between protomer nucleotide states. Nonetheless, this functional partitioning has now been elucidated by our detailed structure-function analysis.

A difficulty in developing potentiated Hsp104 variants as therapeutic agents lies in their off-target toxicity, which likely stems from their ability to unfold metastable soluble proteins or soluble proteins with partially unfolded regions.50 One solution to this problem is to increase the substrate specificity of potentiated Hsp104 variants for specific neurodegenerative disease proteins, which we have achieved with α -synuclein.⁴³ However, multiple proteins can aggregate in neurodegenerative disease, which may limit the utility of substrate-specific protein disaggregases. Another strategy would be to tune Hsp104 activity such that potentiated disaggregase activity is retained while unfolding of soluble proteins is minimized. Here, we establish that fine-tuning the level of Hsp70 collaboration provides a mechanism to achieve this goal. We reach this conclusion by first considering three potentiated Hsp104 variants: Hsp104^{I187F}, Hsp104^{E360R}, and Hsp104^{S535E,77,78} Hsp104^{I187F} exhibits more off-target toxicity than Hsp104^{E360R}, which in turn exhibits more off-target toxicity than Hsp104^{S535E}.^{77,78} Strikingly, Hsp104^{I187F} unfolds RepA₁₋₁₅-GFP (a model soluble protein with a partially unfolded region) more rapidly than Hsp104^{E360R}, which in turn unfolds RepA₁₋₁₅-GFP more rapidly than Hsp104^{S535E}. Furthermore. Hsp104^{1187F} displays less dependence on Hsp70 than Hsp104^{E360R} or Hsp104^{S535E} in luciferase disaggregation and reactivation. Thus, too much independence from Hsp70 may yield off-target toxicity, whereas too much dependence of Hsp70 (as with WT Hsp104) leads to a reduced ability to combat deleterious protein misfolding connected with neurodegenerative disease. Overall, our findings suggest rules for minimizing off-target toxicity: (1) minimize the ability of the Hsp104 variant to unfold soluble proteins with partially unfolded regions; and (2) tune the level of collaboration with Hsp70.

We then leveraged this knowledge to adjust an ATP-specific NBD1:MD helix L1 rheostat to the appropriate level of Hsp70 collaboration. We find that Hsp104^{E190R:R419E} displays increased off-target toxicity, enhanced ability to unfold RepA₁₋₁₅-GFP, and less dependence on Hsp70 in luciferase disaggregation and reactivation. By contrast, Hsp104^{E191R:R419E} and Hsp104^{E192R:R419E} display reduced off-target toxicity, reduced ability to unfold RepA₁₋₁₅-GFP, and more dependence on Hsp70 in luciferase disaggregation and reactivation. By contrast, Hsp104^{E191R:R419E} and Hsp104^{E192R:R419E} display reduced off-target toxicity, reduced ability to unfold RepA₁₋₁₅-GFP, and more dependence on Hsp70 in luciferase disaggregation and reactivation. Hence, these NBD1:MD helix L1 variants may set the ATP-specific MD configuration in a way that optimally tunes Hsp70 collaboration to yield potentiated Hsp104 variants with minimal off-target toxicity.

Finally, we establish that potentiated Hsp104 variants with minimal off-target effects can mitigate aberrant FUS and TDP-43 aggregation in human cells. Thus, a panel of potentiated Hsp104 variants can reduce cytoplasmic FUS and TDP-43 aggregation in human cells, whereas Hsp104 is ineffective. These findings suggest that Hsp104 and enhanced variants can be translated to reduce deleterious protein aggregation in human cells, which sets the stage for further developing Hsp104 as a therapeutic agent. Indeed, in this light, advances in





lipid-nanoparticle-mediated mRNA therapeutics are particularly exciting, as they provide a mechanism to introduce a transient dose of Hsp104 variants to where they are needed.^{119,120} In this way, potentiated Hsp104 variants could relieve toxic protein aggregation and then be downregulated such that potential off-target effects are minimized.

Limitations of the study

One limitation of our study is that we have not yet assessed potentiated Hsp104 variants with minimal off-target effects in more complex models of neurodegenerative disease, including optogenetic models, 121-123 human neurons, or mouse models. In future studies, it will be important to advance these safely potentiated Hsp104 variants to optogenetic neuronal models, induced-pluripotent-stem-cell-derived human neurons, including patient-derived neurons, and mouse models of FUS, TDP-43, α -synuclein,¹²⁴ and polyglutamine proteinopathies. We note that another limitation of our work is that we have not assessed the impact of safely enhanced Hsp104 variants on overall proteome solubility in human neurons subjected to diverse proteotoxic stresses (e.g., heat shock or sodium arsenite stress). Hence, in future studies it will be important to determine the effect of safely enhanced Hsp104 variants on protein aggregation in a proteome-wide manner in human neurons experiencing different types of stress. Finally, we have not addressed how safely enhanced Hsp104 variants would be delivered as therapeutics. In this regard, it will be of great interest to explore the latest mRNA, adeno-associated viruses, protein delivery, and precision medicine technology to deliver enhanced Hsp104 variants to degenerating neurons in mouse models of disease.^{120,125–133} Collectively, these future studies provide an actionable roadmap for the further development of Hsp104 therapeutics.

RESOURCE AVAILABILITY

Lead contact

Further information and requests for resources and reagents should be directed to and will be fulfilled by the lead contact, James Shorter (jshorter@pennmedicine.upenn.edu).

Materials availability

Plasmids newly generated in this study will be made readily available to the scientific community. We will honor requests in a timely fashion. Material transfers will be made with no more restrictive terms than in the Simple Letter Agreement or the Uniform Biological Materials Transfer Agreement and without reach through requirements.

Data and code availability

- The data supporting the findings of this study are available within the article, and source data are available from the corresponding author upon request.
- This paper does not report original code.
- Any additional information required to reanalyze the data reported in this paper is available from the lead contact upon request.

ACKNOWLEDGMENTS

We thank Edward Barbieri, Zarin Tabassum, Zhuoyi Chen, and Sabrina Lin for feedback on the manuscript. This work was supported by an Alzheimer's Association Research Fellowship, a Warren Alpert Foundation Distinguished Scholars Fellowship, a Research Excellence and Resilience Award and a Mildred Cohn Distinguished Postdoctoral Award (J.L.), a Blavatnik Family Foundation Fellowship (E.C.), and NIH grants: T32GM008076 (E.C.), R01GM110001 (D.R.S.), and R01GM099836 (J.S.).

AUTHOR CONTRIBUTIONS

Conceptualization, J.L., D.R.S., and J.S.; methodology, J.L., E.C., and J.S.; validation, J.L., P.J.C., C.W.G., and N.M.K.; formal analysis, J.L.; investigation, J.L., P.J.C., C.W.G., and N.M.K.; resources, J.L., P.J.C., C.W.G., N.M.K., E.C., S.N.G., A.L.Y., A.N.R., D.R.S., and J.S.; data curation, J.L.; writing – original draft, J.L. and J.S.; writing – review & editing, J.L., P.J.C., C.W.G., N.M.K., E.C., S.N.G., A.L.Y., A.N.R., D.R.S., and J.S.; visualization, J.L., D.R.S., and J.S.; supervision, J.L., D.R.S., and J.S.; project administration, J.L., D.R.S., and J.S.; funding acquisition, J.L., E.C., D.R.S., and J.S.

DECLARATION OF INTERESTS

The authors declare no competing interests.

STAR*METHODS

Detailed methods are provided in the online version of this paper and include the following:

- KEY RESOURCES TABLE
- EXPERIMENTAL MODEL AND STUDY PARTICIPANT DETAILS
- Yeast strains
 - HeLa and HEK293 cell maintenance
- METHOD DETAILS
 - Site-directed mutagenesis
 - Protein purification
 - $_{\odot}~$ ATPase assay
 - $\,\circ\,\,$ Luciferase disaggregation and reactivation assay
 - Luciferase refolding assay
 - $_{\odot}\,$ Yeast plasmids
 - Induced thermotolerance assay
 - Yeast transformation and spotting assays
 - Western blotting
 - Toxicity spotting assay
 - RepA₁₋₁₅-GFP unfoldase assay
 - o Codon-optimized Hsp104 plasmid for human cell expression
 - HeLa and HEK293 cell culture and transfections
 - Western blotting for HeLa and HEK293 cell experiments
 - Fluorescence microscopy
- QUANTIFICATION AND STATISTICAL ANALYSIS
 - Thermotolerance spotting assay quantification

SUPPLEMENTAL INFORMATION

Supplemental information can be found online at https://doi.org/10.1016/j.celrep.2024.115005.

Received: April 29, 2024 Revised: September 27, 2024 Accepted: November 6, 2024

REFERENCES

- Englander, S.W. (2023). HX and Me: Understanding Allostery, Folding, and Protein Machines. Annu. Rev. Biophys. 52, 1–18. https://doi.org/ 10.1146/annurev-biophys-062122-093517.
- Labbadia, J., and Morimoto, R.I. (2015). The biology of proteostasis in aging and disease. Annu. Rev. Biochem. 84, 435–464. https://doi.org/ 10.1146/annurev-biochem-060614-033955.

- López-Otin, C., Blasco, M.A., Partridge, L., Serrano, M., and Kroemer, G. (2013). The Hallmarks of Aging. Cell *153*, 1194–1217. https://doi.org/10. 1016/j.cell.2013.05.039.
- Eisele, Y.S., Monteiro, C., Fearns, C., Encalada, S.E., Wiseman, R.L., Powers, E.T., and Kelly, J.W. (2015). Targeting protein aggregation for the treatment of degenerative diseases. Nat. Rev. Drug Discov. 14, 759–780. https://doi.org/10.1038/nrd4593.
- Fare, C.M., and Shorter, J. (2021). (Dis)Solving the problem of aberrant protein states. Dis. Model. Mech. 14, 048983. https://doi.org/10. 1242/dmm.
- Balch, W.E., Morimoto, R.I., Dillin, A., and Kelly, J.W. (2008). Adapting proteostasis for disease intervention. Science 319, 916–919. https:// doi.org/10.1126/science.1141448.
- Chuang, E., Hori, A.M., Hesketh, C.D., and Shorter, J. (2018). Amyloid assembly and disassembly. J. Cell Sci. 131, jcs189928. https://doi.org/10. 1242/jcs.189928.
- Scheres, S.H.W., Ryskeldi-Falcon, B., and Goedert, M. (2023). Molecular pathology of neurodegenerative diseases by cryo-EM of amyloids. Nature 621, 701–710. https://doi.org/10.1038/s41586-023-06437-2.
- Huang, E.J., Zhang, J., Geser, F., Trojanowski, J.Q., Strober, J.B., Dickson, D.W., Brown, R.H., Jr., Shapiro, B.E., and Lomen-Hoerth, C. (2010). Extensive FUS-immunoreactive pathology in juvenile amyotrophic lateral sclerosis with basophilic inclusions. Brain Pathol. 20, 1069–1076. https://doi.org/10.1111/j.1750-3639.2010.00413.x.
- Portz, B., Lee, B.L., and Shorter, J. (2021). FUS and TDP-43 Phases in Health and Disease. Trends Biochem. Sci. 46, 550–563. https://doi.org/ 10.1016/j.tibs.2020.12.005.
- Wobst, H.J., Mack, K.L., Brown, D.G., Brandon, N.J., and Shorter, J. (2020). The clinical trial landscape in amyotrophic lateral sclerosis-Past, present, and future. Med. Res. Rev. 40, 1352–1384. https://doi. org/10.1002/med.21661.
- Guo, L., and Shorter, J. (2017). Biology and Pathobiology of TDP-43 and Emergent Therapeutic Strategies. Cold Spring Harb. Perspect. Med. 7, a024554. https://doi.org/10.1101/cshperspect.a024554.
- Shorter, J. (2008). Hsp104: a weapon to combat diverse neurodegenerative disorders. Neurosignals 16, 63–74. https://doi.org/10.1159/ 000109760.
- Darling, A.L., and Shorter, J. (2021). Combating deleterious phase transitions in neurodegenerative disease. Biochim. Biophys. Acta. Mol. Cell Res. 1868, 118984. https://doi.org/10.1016/j.bbamcr.2021.118984.
- Shorter, J. (2016). Engineering therapeutic protein disaggregases. Mol. Biol. Cell 27, 1556–1560. https://doi.org/10.1091/mbc.E15-10-0693.
- Shorter, J. (2017). Designer protein disaggregases to counter neurodegenerative disease. Curr. Opin. Genet. Dev. 44, 1–8. https://doi.org/10. 1016/j.gde.2017.01.008.
- Erjavec, N., Larsson, L., Grantham, J., and Nyström, T. (2007). Accelerated aging and failure to segregate damaged proteins in Sir2 mutants can be suppressed by overproducing the protein aggregation-remodeling factor Hsp104p. Genes Dev. 21, 2410–2421. https://doi.org/10. 1101/gad.439307.
- Shorter, J., and Southworth, D.R. (2019). Spiraling in Control: Structures and Mechanisms of the Hsp104 Disaggregase. Cold Spring Harb. Perspect. Biol. 11, a034033. https://doi.org/10.1101/cshperspect.a034033.
- Lin, J., Shorter, J., and Lucius, A.L. (2022). AAA+ proteins: one motor, multiple ways to work. Biochem. Soc. Trans. 50, 895–906. https://doi. org/10.1042/BST20200350.
- DeSantis, M.E., Leung, E.H., Sweeny, E.A., Jackrel, M.E., Cushman-Nick, M., Neuhaus-Follini, A., Vashist, S., Sochor, M.A., Knight, M.N., and Shorter, J. (2012). Operational plasticity enables hsp104 to disaggregate diverse amyloid and nonamyloid clients. Cell *151*, 778–793. https:// doi.org/10.1016/j.cell.2012.09.038.



- 21. Glover, J.R., and Lindquist, S. (1998). Hsp104, Hsp70, and Hsp40: a novel chaperone system that rescues previously aggregated proteins. Cell *94*, 73–82. S0092-8674(00)81223-4 [pii].
- Lo Bianco, C., Shorter, J., Régulier, E., Lashuel, H., Iwatsubo, T., Lindquist, S., and Aebischer, P. (2008). Hsp104 antagonizes alpha-synuclein aggregation and reduces dopaminergic degeneration in a rat model of Parkinson disease. J. Clin. Invest. *118*, 3087–3097. https://doi.org/10. 1172/JCI35781.
- Shorter, J., and Lindquist, S. (2004). Hsp104 catalyzes formation and elimination of self-replicating Sup35 prion conformers. Science 304, 1793–1797. https://doi.org/10.1126/science.1098007.
- Yoo, H., Bard, J.A.M., Pilipenko, E.V., and Drummond, D.A. (2022). Chaperones directly and efficiently disperse stress-triggered biomolecular condensates. Mol. Cell 82, 741–755.e11. https://doi.org/10.1016/ j.molcel.2022.01.005.
- Tomaszewski, A., Wang, R., Sandoval, E., Zhu, J., Liu, J., and Li, R. (2023). Solid-to-liquid phase transition in the dissolution of cytosolic misfolded-protein aggregates. iScience 26, 108334. https://doi.org/10. 1016/j.isci.2023.108334.
- Huang, L., Agrawal, T., Zhu, G., Yu, S., Tao, L., Lin, J., Marmorstein, R., Shorter, J., and Yang, X. (2021). DAXX represents a new type of proteinfolding enabler. Nature 597, 132–137. https://doi.org/10.1038/s41586-021-03824-5.
- Zhu, G., Harischandra, D.S., Ghaisas, S., Zhang, P., Prall, W., Huang, L., Maghames, C., Guo, L., Luna, E., Mack, K.L., et al. (2020). TRIM11 Prevents and Reverses Protein Aggregation and Rescues a Mouse Model of Parkinson's Disease. Cell Rep. 33, 108418. https://doi.org/10.1016/j.celrep.2020.108418.
- DeSantis, M.E., and Shorter, J. (2012). Hsp104 drives "protein-only" positive selection of Sup35 prion strains encoding strong [PSI(+)]. Chem. Biol. 19, 1400–1410. https://doi.org/10.1016/j.chembiol.2012. 09.013.
- Buchholz, H.E., Dorweiler, J.E., Guereca, S., Wisniewski, B.T., Shorter, J., and Manogaran, A.L. (2024). The middle domain of Hsp104 can ensure substrates are functional after processing. PLoS Genet. 20, e1011424. https://doi.org/10.1371/journal.pgen.1011424.
- Vashist, S., Cushman, M., and Shorter, J. (2010). Applying Hsp104 to protein-misfolding disorders. Biochem. Cell. Biol. 88, 1–13. https://doi. org/10.1139/o09-121.
- Erives, A.J., and Fassler, J.S. (2015). Metabolic and chaperone gene loss marks the origin of animals: evidence for Hsp104 and Hsp78 chaperones sharing mitochondrial enzymes as clients. PLoS One 10, e0117192. https://doi.org/10.1371/journal.pone.0117192.
- Cupo, R.R., Rizo, A.N., Braun, G.A., Tse, E., Chuang, E., Gupta, K., Southworth, D.R., and Shorter, J. (2022). Unique structural features govern the activity of a human mitochondrial AAA+ disaggregase. Cell Rep. 40, 111408. https://doi.org/10.1016/j.celrep.2022.111408.
- Cupo, R.R., and Shorter, J. (2020). Skd3 (human ClpB) is a potent mitochondrial protein disaggregase that is inactivated by 3-methylglutaconic aciduria-linked mutations. Elife 9, e55279. https://doi.org/10.7554/eLife. 55279.
- Warren, J.T., Cupo, R.R., Wattanasirakul, P., Spencer, D.H., Locke, A.E., Makaryan, V., Bolyard, A.A., Kelley, M.L., Kingston, N.L., Shorter, J., et al. (2022). Heterozygous variants of CLPB are a cause of severe congenital neutropenia. Blood *139*, 779–791. https://doi.org/10.1182/blood. 2021010762.
- Cupo, R.R., and Shorter, J. (2024). Decoding Skd3 (Human CLPB): a Mitochondrial Protein Disaggregase Critical for Human Health. Isr. J. Chem, e202300153. https://doi.org/10.1002/ijch.202300153.
- Gupta, A., Lentzsch, A.M., Siegel, A., Yu, Z., Chio, U.S., Cheng, Y., and Shan, S.O. (2023). Dodecamer assembly of a metazoan AAA(+) chaperone couples substrate extraction to refolding. Sci. Adv. 9, eadf5336. https://doi.org/10.1126/sciadv.adf5336.



- Lee, S., Lee, S.B., Sung, N., Xu, W.W., Chang, C., Kim, H.E., Catic, A., and Tsai, F.T.F. (2023). Structural basis of impaired disaggregase function in the oxidation-sensitive SKD3 mutant causing 3-methylglutaconic aciduria. Nat. Commun. 14, 2028. https://doi.org/10.1038/s41467-023-37657-9.
- Wu, D., Liu, Y., Dai, Y., Wang, G., Lu, G., Chen, Y., Li, N., Lin, J., and Gao, N. (2023). Comprehensive structural characterization of the human AAA+ disaggregase CLPB in the apo- and substrate-bound states reveals a unique mode of action driven by oligomerization. PLoS Biol. 21, e3001987. https://doi.org/10.1371/journal.pbio.3001987.
- Darwich, N.F., Phan, J.M., Kim, B., Suh, E., Papatriantafyllou, J.D., Changolkar, L., Nguyen, A.T., O'Rourke, C.M., He, Z., Porta, S., et al. (2020). Autosomal dominant VCP hypomorph mutation impairs disaggregation of PHF-tau. Science 370, eaay8826. https://doi.org/10.1126/science. aay8826.
- Phan, J.M., Creekmore, B.C., Nguyen, A.T., Bershadskaya, D.D., Darwich, N.F., Mann, C.N., and Lee, E.B. (2024). VCP activator reverses nuclear proteostasis defects and enhances TDP-43 aggregate clearance in multisystem proteinopathy models. J. Clin. Invest. *134*, e169039. https:// doi.org/10.1172/jci169039.
- Cushman-Nick, M., Bonini, N.M., and Shorter, J. (2013). Hsp104 suppresses polyglutamine-induced degeneration post onset in a Drosophila MJD/SCA3 model. PLoS Genet. 9, e1003781. https://doi.org/10.1371/ journal.pgen.1003781.
- Jackrel, M.E., DeSantis, M.E., Martinez, B.A., Castellano, L.M., Stewart, R.M., Caldwell, K.A., Caldwell, G.A., and Shorter, J. (2014). Potentiated Hsp104 variants antagonize diverse proteotoxic misfolding events. Cell 156, 170–182. https://doi.org/10.1016/j.cell.2013.11.047.
- Mack, K.L., Kim, H., Barbieri, E.M., Lin, J., Braganza, S., Jackrel, M.E., DeNizio, J.E., Yan, X., Chuang, E., Tariq, A., et al. (2023). Tuning Hsp104 specificity to selectively detoxify alpha-synuclein. Mol. Cell 83, 3314–3332.e9. https://doi.org/10.1016/j.molcel.2023.07.029.
- March, Z.M., Sweeney, K., Kim, H., Yan, X., Castellano, L.M., Jackrel, M.E., Lin, J., Chuang, E., Gomes, E., Willicott, C.W., et al. (2020). Therapeutic genetic variation revealed in diverse Hsp104 homologs. Elife 9, e57457. https://doi.org/10.7554/eLife.57457.
- Perrin, V., Régulier, E., Abbas-Terki, T., Hassig, R., Brouillet, E., Aebischer, P., Luthi-Carter, R., and Déglon, N. (2007). Neuroprotection by Hsp104 and Hsp27 in lentiviral-based rat models of Huntington's disease. Mol. Ther. *15*, 903–911. https://doi.org/10.1038/mt.sj.6300141.
- Bao, Y.P., Cook, L.J., O'Donovan, D., Uyama, E., and Rubinsztein, D.C. (2002). Mammalian, yeast, bacterial, and chemical chaperones reduce aggregate formation and death in a cell model of oculopharyngeal muscular dystrophy. J. Biol. Chem. 277, 12263–12269. https://doi.org/ 10.1074/jbc.M109633200.
- Carmichael, J., Chatellier, J., Woolfson, A., Milstein, C., Fersht, A.R., and Rubinsztein, D.C. (2000). Bacterial and yeast chaperones reduce both aggregate formation and cell death in mammalian cell models of Huntington's disease. Proc. Natl. Acad. Sci. USA 97, 9701–9705. https://doi.org/ 10.1073/pnas.170280697.
- Vacher, C., Garcia-Oroz, L., and Rubinsztein, D.C. (2005). Overexpression of yeast hsp104 reduces polyglutamine aggregation and prolongs survival of a transgenic mouse model of Huntington's disease. Hum. Mol. Genet. 14, 3425–3433. https://doi.org/10.1093/hmg/ddi372.
- Jackrel, M.E., and Shorter, J. (2015). Engineering enhanced protein disaggregases for neurodegenerative disease. Prion 9, 90–109. https://doi. org/10.1080/19336896.2015.1020277.
- Jackrel, M.E., and Shorter, J. (2014). Potentiated Hsp104 variants suppress toxicity of diverse neurodegenerative disease-linked proteins. Dis. Model. Mech. 7, 1175–1184. https://doi.org/10.1242/dmm.016113.
- Jackrel, M.E., and Shorter, J. (2014). Reversing deleterious protein aggregation with re-engineered protein disaggregases. Cell Cycle 13, 1379–1383. https://doi.org/10.4161/cc.28709.



- Jackrel, M.E., Tariq, A., Yee, K., Weitzman, R., and Shorter, J. (2014). Isolating potentiated Hsp104 variants using yeast proteinopathy models. J. Vis. Exp. e52089. https://doi.org/10.3791/52089.
- Ryan, J.J., Bao, A., Bell, B., Ling, C., and Jackrel, M.E. (2021). Drivers of Hsp104 potentiation revealed by scanning mutagenesis of the middle domain. Protein Sci. 30, 1667–1685. https://doi.org/10.1002/pro.4126.
- Ye, X., Lin, J., Mayne, L., Shorter, J., and Englander, S.W. (2020). Structural and kinetic basis for the regulation and potentiation of Hsp104 function. Proc. Natl. Acad. Sci. USA *117*, 9384–9392. https://doi.org/10. 1073/pnas.1921968117.
- Heuck, A., Schitter-Sollner, S., Suskiewicz, M.J., Kurzbauer, R., Kley, J., Schleiffer, A., Rombaut, P., Herzog, F., and Clausen, T. (2016). Structural basis for the disaggregase activity and regulation of Hsp104. Elife 5, e21516. https://doi.org/10.7554/eLife.21516.
- Shorter, J., and Lindquist, S. (2008). Hsp104, Hsp70 and Hsp40 interplay regulates formation, growth and elimination of Sup35 prions. EMBO J. 27, 2712–2724. https://doi.org/10.1038/emboj.2008.194.
- 57. Shorter, J. (2011). The mammalian disaggregase machinery: Hsp110 synergizes with Hsp70 and Hsp40 to catalyze protein disaggregation and reactivation in a cell-free system. PLoS One 6, e26319. https://doi.org/10.1371/journal.pone.0026319.
- Sweeny, E.A., and Shorter, J. (2008). Prion proteostasis: Hsp104 meets its supporting cast. Prion 2, 135–140. https://doi.org/10.4161/pri.2. 4.7952.
- Duennwald, M.L., Echeverria, A., and Shorter, J. (2012). Small heat shock proteins potentiate amyloid dissolution by protein disaggregases from yeast and humans. PLoS Biol. *10*, e1001346. https://doi.org/10.1371/ journal.pbio.1001346.
- Daugaard, M., Rohde, M., and Jäättelä, M. (2007). The heat shock protein 70 family: Highly homologous proteins with overlapping and distinct functions. FEBS Lett. 581, 3702–3710. https://doi.org/10.1016/j.febslet. 2007.05.039.
- Ahmad, A., Bhattacharya, A., McDonald, R.A., Cordes, M., Ellington, B., Bertelsen, E.B., and Zuiderweg, E.R.P. (2011). Heat shock protein 70 kDa chaperone/DnaJ cochaperone complex employs an unusual dynamic interface. Proc. Natl. Acad. Sci. USA *108*, 18966–18971. https://doi. org/10.1073/pnas.1111220108.
- Cuellar, J., Perales-Calvo, J., Muga, A., Valpuesta, J.M., and Moro, F. (2013). Structural insights into the chaperone activity of the 40-kDa heat shock protein DnaJ: binding and remodeling of a native substrate. J. Biol. Chem. 288, 15065–15074. https://doi.org/10.1074/jbc.M112. 430595.
- Kampinga, H.H., and Craig, E.A. (2010). The HSP70 chaperone machinery: J proteins as drivers of functional specificity. Nat. Rev. Mol. Cell Biol. 11, 579–592. https://doi.org/10.1038/nrm2941.
- Lee, J., Kim, J.H., Biter, A.B., Sielaff, B., Lee, S., and Tsai, F.T.F. (2013). Heat shock protein (Hsp) 70 is an activator of the Hsp104 motor. Proc. Natl. Acad. Sci. USA *110*, 8513–8518. https://doi.org/10.1073/pnas. 1217988110.
- DeSantis, M.E., Sweeny, E.A., Snead, D., Leung, E.H., Go, M.S., Gupta, K., Wendler, P., and Shorter, J. (2014). Conserved distal loop residues in the Hsp104 and ClpB middle domain contact nucleotide-binding domain 2 and enable Hsp70-dependent protein disaggregation. J. Biol. Chem. 289, 848–867. https://doi.org/10.1074/jbc.M113.520759.
- Sweeny, E.A., Tariq, A., Gurpinar, E., Go, M.S., Sochor, M.A., Kan, Z.Y., Mayne, L., Englander, S.W., and Shorter, J. (2020). Structural and mechanistic insights into Hsp104 function revealed by synchrotron X-ray footprinting. J. Biol. Chem. 295, 1517–1538. https://doi.org/10.1074/jbc. RA119.011577.
- Rosenzweig, R., Moradi, S., Zarrine-Afsar, A., Glover, J.R., and Kay, L.E. (2013). Unraveling the mechanism of protein disaggregation through a ClpB-DnaK interaction. Science 339, 1080–1083. https://doi.org/10. 1126/science.1233066.



- Carroni, M., Kummer, E., Oguchi, Y., Wendler, P., Clare, D.K., Sinning, I., Kopp, J., Mogk, A., Bukau, B., and Saibil, H.R. (2014). Head-to-tail interactions of the coiled-coil domains regulate ClpB activity and cooperation with Hsp70 in protein disaggregation. Elife 3, e02481. https://doi.org/10. 7554/eLife.02481.
- Oguchi, Y., Kummer, E., Seyffer, F., Berynskyy, M., Anstett, B., Zahn, R., Wade, R.C., Mogk, A., and Bukau, B. (2012). A tightly regulated molecular toggle controls AAA+ disaggregase. Nat. Struct. Mol. Biol. 19, 1338– 1346. https://doi.org/10.1038/nsmb.2441.
- Sweeny, E.A., and Shorter, J. (2016). Mechanistic and Structural Insights into the Prion-Disaggregase Activity of Hsp104. J. Mol. Biol. 428, 1870– 1885. https://doi.org/10.1016/j.jmb.2015.11.016.
- Jackrel, M.E., Yee, K., Tariq, A., Chen, A.I., and Shorter, J. (2015). Disparate Mutations Confer Therapeutic Gain of Hsp104 Function. ACS Chem. Biol. 10, 2672–2679. https://doi.org/10.1021/acschembio.5b00765.
- Gates, S.N., Yokom, A.L., Lin, J., Jackrel, M.E., Rizo, A.N., Kendsersky, N.M., Buell, C.E., Sweeny, E.A., Mack, K.L., Chuang, E., et al. (2017). Ratchet-like polypeptide translocation mechanism of the AAA+ disaggregase Hsp104. Science 357, 273–279. https://doi.org/10.1126/science.aan1052.
- Rizo, A.N., Lin, J., Gates, S.N., Tse, E., Bart, S.M., Castellano, L.M., Di-Maio, F., Shorter, J., and Southworth, D.R. (2019). Structural basis for substrate gripping and translocation by the ClpB AAA+ disaggregase. Nat. Commun. 10, 2393. https://doi.org/10.1038/s41467-019-10150-y.
- Yu, H., Lupoli, T.J., Kovach, A., Meng, X., Zhao, G., Nathan, C.F., and Li, H. (2018). ATP hydrolysis-coupled peptide translocation mechanism of Mycobacterium tuberculosis ClpB. Proc. Natl. Acad. Sci. USA *115*, E9560–E9569. https://doi.org/10.1073/pnas.1810648115.
- Sweeny, E.A., Jackrel, M.E., Go, M.S., Sochor, M.A., Razzo, B.M., De-Santis, M.E., Gupta, K., and Shorter, J. (2015). The Hsp104 N-terminal domain enables disaggregase plasticity and potentiation. Mol. Cell 57, 836–849. https://doi.org/10.1016/j.molcel.2014.12.021.
- Tariq, A., Lin, J., Jackrel, M.E., Hesketh, C.D., Carman, P.J., Mack, K.L., Weitzman, R., Gambogi, C., Hernandez Murillo, O.A., Sweeny, E.A., et al. (2019). Mining Disaggregase Sequence Space to Safely Counter TDP-43, FUS, and alpha-Synuclein Proteotoxicity. Cell Rep. 28, 2080– 2095.e6. https://doi.org/10.1016/j.celrep.2019.07.069.
- Tariq, A., Lin, J., Noll, M.M., Torrente, M.P., Mack, K.L., Murillo, O.H., Jackrel, M.E., and Shorter, J. (2018). Potentiating Hsp104 activity via phosphomimetic mutations in the middle domain. FEMS Yeast Res. 18, foy042. https://doi.org/10.1093/femsyr/foy042.
- Torrente, M.P., Chuang, E., Noll, M.M., Jackrel, M.E., Go, M.S., and Shorter, J. (2016). Mechanistic Insights into Hsp104 Potentiation. J. Biol. Chem. 291, 5101–5115. https://doi.org/10.1074/jbc.M115. 707976.
- Chamera, T., Kłosowska, A., Janta, A., Wyszkowski, H., Obuchowski, I., Gumowski, K., and Liberek, K. (2019). Selective Hsp70-Dependent Docking of Hsp104 to Protein Aggregates Protects the Cell from the Toxicity of the Disaggregase. J. Mol. Biol. 431, 2180–2196. https://doi. org/10.1016/j.jmb.2019.04.014.
- DeSantis, M.E., and Shorter, J. (2012). The elusive middle domain of Hsp104 and ClpB: location and function. Biochim. Biophys. Acta *1823*, 29–39. https://doi.org/10.1016/j.bbamcr.2011.07.014.
- Cashikar, A.G., Schirmer, E.C., Hattendorf, D.A., Glover, J.R., Ramakrishnan, M.S., Ware, D.M., and Lindquist, S.L. (2002). Defining a pathway of communication from the C-terminal peptide binding domain to the N-terminal ATPase domain in a AAA protein. Mol. Cell 9, 751–760. https://doi.org/10.1016/s1097-2765(02)00499-9.



- Schirmer, E.C., Homann, O.R., Kowal, A.S., and Lindquist, S. (2004). Dominant gain-of-function mutations in Hsp104p reveal crucial roles for the middle region. Mol. Biol. Cell *15*, 2061–2072. https://doi.org/10. 1091/mbc.e02-08-0502.
- Yokom, A.L., Gates, S.N., Jackrel, M.E., Mack, K.L., Su, M., Shorter, J., and Southworth, D.R. (2016). Spiral architecture of the Hsp104 disaggregase reveals the basis for polypeptide translocation. Nat. Struct. Mol. Biol. 23, 830–837. https://doi.org/10.1038/nsmb.3277.
- Doyle, S.M., Shorter, J., Zolkiewski, M., Hoskins, J.R., Lindquist, S., and Wickner, S. (2007). Asymmetric deceleration of ClpB or Hsp104 ATPase activity unleashes protein-remodeling activity. Nat. Struct. Mol. Biol. 14, 114–122. https://doi.org/10.1038/nsmb1198.
- Sanchez, Y., and Lindquist, S.L. (1990). HSP104 required for induced thermotolerance. Science 248, 1112–1115. https://doi.org/10.1126/science.2188365.
- Sanchez, Y., Parsell, D.A., Taulien, J., Vogel, J.L., Craig, E.A., and Lindquist, S. (1993). Genetic evidence for a functional relationship between Hsp104 and Hsp70. J. Bacteriol. 175, 6484–6491. https://doi.org/10. 1128/jb.175.20.6484-6491.1993.
- Moreau, K., Coen, M., Zhang, A.X., Pachl, F., Castaldi, M.P., Dahl, G., Boyd, H., Scott, C., and Newham, P. (2020). Proteolysis-targeting chimeras in drug development: A safety perspective. Br. J. Pharmacol. *177*, 1709–1718. https://doi.org/10.1111/bph.15014.
- Jiang, Y., Rossi, P., and Kalodimos, C.G. (2019). Structural basis for client recognition and activity of Hsp40 chaperones. Science 365, 1313–1319. https://doi.org/10.1126/science.aax1280.
- Caplan, A.J., Tsai, J., Casey, P.J., and Douglas, M.G. (1992). Farnesylation of YDJ1p is required for function at elevated growth temperatures in Saccharomyces cerevisiae. J. Biol. Chem. 267, 18890–18895. https:// doi.org/10.1016/S0021-9258(19)37044-9.
- Hildebrandt, E.R., Cheng, M., Zhao, P., Kim, J.H., Wells, L., and Schmidt, W.K. (2016). A shunt pathway limits the CaaX processing of Hsp40 Ydj1p and regulates Ydj1p-dependent phenotypes. Elife 5, e15899. https://doi. org/10.7554/eLife.15899.
- Wyszkowski, H., Janta, A., Sztangierska, W., Obuchowski, I., Chamera, T., Kłosowska, A., and Liberek, K. (2021). Class-specific interactions between Sis1 J-domain protein and Hsp70 chaperone potentiate disaggregation of misfolded proteins. Proc. Natl. Acad. Sci. USA *118*, e2108163118. https://doi.org/10.1073/pnas.2108163118.
- Lum, R., Niggemann, M., and Glover, J.R. (2008). Peptide and protein binding in the axial channel of Hsp104. Insights into the mechanism of protein unfolding. J. Biol. Chem. 283, 30139–30150. https://doi.org/10. 1074/jbc.M804849200.
- Lopez, K.E., Rizo, A.N., Tse, E., Lin, J., Scull, N.W., Thwin, A.C., Lucius, A.L., Shorter, J., and Southworth, D.R. (2020). Conformational plasticity of the ClpAP AAA+ protease couples protein unfolding and proteolysis. Nat. Struct. Mol. Biol. 27, 406–416. https://doi.org/10.1038/s41594-020-0409-5.
- Fare, C.M., Rhine, K., Lam, A., Myong, S., and Shorter, J. (2023). A minimal construct of nuclear-import receptor Karyopherin-beta2 defines the regions critical for chaperone and disaggregation activity. J. Biol. Chem. 299, 102806. https://doi.org/10.1016/j.jbc.2022.102806.
- Sabatelli, M., Moncada, A., Conte, A., Lattante, S., Marangi, G., Luigetti, M., Lucchini, M., Mirabella, M., Romano, A., Del Grande, A., et al. (2013). Mutations in the 3' untranslated region of FUS causing FUS overexpression are associated with amyotrophic lateral sclerosis. Hum. Mol. Genet. 22, 4748–4755. https://doi.org/10.1093/hmg/ddt328.
- Taylor, J.P., Brown, R.H., Jr., and Cleveland, D.W. (2016). Decoding ALS: from genes to mechanism. Nature 539, 197–206. https://doi.org/10. 1038/nature20413.
- Nelson, P.T., Dickson, D.W., Trojanowski, J.Q., Jack, C.R., Boyle, P.A., Arfanakis, K., Rademakers, R., Alafuzoff, I., Attems, J., Brayne, C., et al. (2019). Limbic-predominant age-related TDP-43 encephalopathy

(LATE): consensus working group report. Brain 142, 1503–1527. https://doi.org/10.1093/brain/awz099.

- Ling, S.C., Polymenidou, M., and Cleveland, D.W. (2013). Converging mechanisms in ALS and FTD: disrupted RNA and protein homeostasis. Neuron 79, 416–438. https://doi.org/10.1016/j.neuron.2013.07.033.
- van Es, M.A., Hardiman, O., Chio, A., Al-Chalabi, A., Pasterkamp, R.J., Veldink, J.H., and van den Berg, L.H. (2017). Amyotrophic lateral sclerosis. Lancet 390, 2084–2098. https://doi.org/10.1016/S0140-6736(17) 31287-4.
- Selkoe, D.J., and Hardy, J. (2016). The amyloid hypothesis of Alzheimer's disease at 25 years. EMBO Mol. Med. 8, 595–608. https://doi.org/10. 15252/emmm.201606210.
- 102. Karran, E., and De Strooper, B. (2022). The amyloid hypothesis in Alzheimer disease: new insights from new therapeutics. Nat. Rev. Drug Discov. 21, 306–318. https://doi.org/10.1038/s41573-022-00391-w.
- 103. McKee, A.C., Gavett, B.E., Stern, R.A., Nowinski, C.J., Cantu, R.C., Kowall, N.W., Perl, D.P., Hedley-Whyte, E.T., Price, B., Sullivan, C., et al. (2010). TDP-43 proteinopathy and motor neuron disease in chronic traumatic encephalopathy. J. Neuropathol. Exp. Neurol. 69, 918–929. https:// doi.org/10.1097/NEN.0b013e3181ee7d85.
- 104. McKee, A.C., Stein, T.D., Kiernan, P.T., and Alvarez, V.E. (2015). The neuropathology of chronic traumatic encephalopathy. Brain Pathol. 25, 350–364. https://doi.org/10.1111/bpa.12248.
- 105. Cushman, M., Johnson, B.S., King, O.D., Gitler, A.D., and Shorter, J. (2010). Prion-like disorders: blurring the divide between transmissibility and infectivity. J. Cell Sci. *123*, 1191–1201. https://doi.org/10.1242/jcs. 051672.
- 106. King, O.D., Gitler, A.D., and Shorter, J. (2012). The tip of the iceberg: RNA-binding proteins with prion-like domains in neurodegenerative disease. Brain Res. *1462*, 61–80. https://doi.org/10.1016/j.brainres.2012. 01.016.
- Li, Y.R., King, O.D., Shorter, J., and Gitler, A.D. (2013). Stress granules as crucibles of ALS pathogenesis. J. Cell Biol. 201, 361–372. https://doi.org/ 10.1083/jcb.201302044.
- March, Z.M., King, O.D., and Shorter, J. (2016). Prion-like domains as epigenetic regulators, scaffolds for subcellular organization, and drivers of neurodegenerative disease. Brain Res. *1647*, 9–18. https://doi.org/10. 1016/j.brainres.2016.02.037.
- 109. Neumann, M., Sampathu, D.M., Kwong, L.K., Truax, A.C., Micsenyi, M.C., Chou, T.T., Bruce, J., Schuck, T., Grossman, M., Clark, C.M., et al. (2006). Ubiquitinated TDP-43 in frontotemporal lobar degeneration and amyotrophic lateral sclerosis. Science 314, 130–133. https://doi.org/ 10.1126/science.1134108.
- 110. Arseni, D., Chen, R., Murzin, A.G., Peak-Chew, S.Y., Garringer, H.J., Newell, K.L., Kametani, F., Robinson, A.C., Vidal, R., Ghetti, B., et al. (2023). TDP-43 forms amyloid filaments with a distinct fold in type A FTLD-TDP. Nature 620, 898–903. https://doi.org/10.1038/s41586-023-06405-w.
- 111. Arseni, D., Hasegawa, M., Murzin, A.G., Kametani, F., Arai, M., Yoshida, M., and Ryskeldi-Falcon, B. (2022). Structure of pathological TDP-43 filaments from ALS with FTLD. Nature 601, 139–143. https://doi.org/10. 1038/s41586-021-04199-3.
- Gitler, A.D., and Shorter, J. (2011). RNA-binding proteins with prion-like domains. Prion 5, 179–187. https://doi.org/10.4161/pri.5.3.17230.
- Arseni, D., Nonaka, T., Jacobsen, M.H., Murzin, A.G., Cracco, L., Peak-Chew, S.Y., Garringer, H.J., Kawakami, I., Suzuki, H., Onaya, M., et al. (2024). Heteromeric amyloid filaments of ANXA11 and TDP-43 in FTLD-TDP Type C. Nature 634, 662–668. https://doi.org/10.1038/s41586-024-08024-5.
- Winton, M.J., Igaz, L.M., Wong, M.M., Kwong, L.K., Trojanowski, J.Q., and Lee, V.M.Y. (2008). Disturbance of nuclear and cytoplasmic TAR DNA-binding protein (TDP-43) induces disease-like redistribution,

sequestration, and aggregate formation. J. Biol. Chem. 283, 13302-13309. https://doi.org/10.1074/jbc.M800342200.

- 115. Gitcho, M.A., Bigio, E.H., Mishra, M., Johnson, N., Weintraub, S., Mesulam, M., Rademakers, R., Chakraverty, S., Cruchaga, C., Morris, J.C., et al. (2009). TARDBP 3'-UTR variant in autopsy-confirmed frontotemporal lobar degeneration with TDP-43 proteinopathy. Acta Neuropathol. *118*, 633–645. https://doi.org/10.1007/s00401-009-0571-7.
- 116. Gasset-Rosa, F., Lu, S., Yu, H., Chen, C., Melamed, Z., Guo, L., Shorter, J., Da Cruz, S., and Cleveland, D.W. (2019). Cytoplasmic TDP-43 Demixing Independent of Stress Granules Drives Inhibition of Nuclear Import, Loss of Nuclear TDP-43, and Cell Death. Neuron *102*, 339– 357.e7. https://doi.org/10.1016/j.neuron.2019.02.038.
- 117. Polymenidou, M., Lagier-Tourenne, C., Hutt, K.R., Huelga, S.C., Moran, J., Liang, T.Y., Ling, S.C., Sun, E., Wancewicz, E., Mazur, C., et al. (2011). Long pre-mRNA depletion and RNA missplicing contribute to neuronal vulnerability from loss of TDP-43. Nat. Neurosci. *14*, 459–468. https://doi.org/10.1038/nn.2779.
- 118. Ye, X., Lin, J., Mayne, L., Shorter, J., and Englander, S.W. (2019). Hydrogen exchange reveals Hsp104 architecture, structural dynamics, and energetics in physiological solution. Proc. Natl. Acad. Sci. USA 116, 7333–7342. https://doi.org/10.1073/pnas.1816184116.
- Rohner, E., Yang, R., Foo, K.S., Goedel, A., and Chien, K.R. (2022). Unlocking the promise of mRNA therapeutics. Nat. Biotechnol. 40, 1586–1600. https://doi.org/10.1038/s41587-022-01491-z.
- 120. Han, E.L., Padilla, M.S., Palanki, R., Kim, D., Mrksich, K., Li, J.J., Tang, S., Yoon, I.C., and Mitchell, M.J. (2024). Predictive High-Throughput Platform for Dual Screening of mRNA Lipid Nanoparticle Blood-Brain Barrier Transfection and Crossing. Nano Lett. 24, 1477–1486. https://doi.org/10. 1021/acs.nanolett.3c03509.
- 121. Guo, L., Mann, J.R., Mauna, J.C., Copley, K.E., Wang, H., Rubien, J.D., Odeh, H.M., Lin, J., Lee, B.L., Ganser, L., et al. (2023). Defining RNA oligonucleotides that reverse deleterious phase transitions of RNA-binding proteins with prion-like domains. bioRxiv, 2023.09.04.555754. https:// doi.org/10.1101/2023.09.04.555754.
- 122. Mann, J.R., Gleixner, A.M., Mauna, J.C., Gomes, E., DeChellis-Marks, M.R., Needham, P.G., Copley, K.E., Hurtle, B., Portz, B., Pyles, N.J., et al. (2019). RNA Binding Antagonizes Neurotoxic Phase Transitions of TDP-43. Neuron *102*, 321–338.e8. https://doi.org/10.1016/j.neuron. 2019.01.048.
- Hurtle, B., Donnelly, C.J., Zhang, X., and Thathiah, A. (2024). Live-cell visualization of tau aggregation in human neurons. Commun. Biol. 7, 1143. https://doi.org/10.1038/s42003-024-06840-z.
- 124. Lam, I., Ndayisaba, A., Lewis, A.J., Fu, Y., Sagredo, G.T., Kuzkina, A., Zaccagnini, L., Celikag, M., Sandoe, J., Sanz, R.L., et al. (2024). Rapid iPSC inclusionopathy models shed light on formation, consequence, and molecular subtype of alpha-synuclein inclusions. Neuron *112*, 2886–2909.e16. https://doi.org/10.1016/j.neuron.2024.06.002.
- Amado, D.A., and Davidson, B.L. (2021). Gene therapy for ALS: A review. Mol. Ther. 29, 3345–3358. https://doi.org/10.1016/j.ymthe.2021.04.008.
- 126. Amado, D.A., Robbins, A.B., Smith, A.R., Whiteman, K.R., Chillon Bosch, G., Chen, Y., Fuller, J.A., Izda, A., Nelson, S., Dichter, A.I., et al. (2024). AAV-based delivery of RNAi targeting Ataxin-2 improves survival, strength, and pathology in mouse models of rapidly and slowly progressive sporadic ALS. Preprint at: bioRxiv 2024, 2024.01.31.578314. https:// doi.org/10.1101/2024.01.31.578314
- 127. Parhiz, H., Atochina-Vasserman, E.N., and Weissman, D. (2024). mRNAbased therapeutics: looking beyond COVID-19 vaccines. Lancet 403, 1192–1204. https://doi.org/10.1016/s0140-6736(23)02444-3.
- Wilkins, O.G., Chien, M.Z.Y.J., Wlaschin, J.J., Barattucci, S., Harley, P., Mattedi, F., Mehta, P.R., Pisliakova, M., Ryadnov, E., Keuss, M.J., et al. (2024). Creation of de novo cryptic splicing for ALS and FTD precision medicine. Science 386, 61–69. https://doi.org/10.1126/science. adk2539.



- 129. Zeng, Y., and Gitler, A.D. (2024). Regulators, mount up. Science 386, 24–25. https://doi.org/10.1126/science.ads5951.
- Kreitz, J., Friedrich, M.J., Guru, A., Lash, B., Saito, M., Macrae, R.K., and Zhang, F. (2023). Programmable protein delivery with a bacterial contractile injection system. Nature 616, 357–364. https://doi.org/10.1038/ s41586-023-05870-7.
- Tervo, D.G.R., Hwang, B.Y., Viswanathan, S., Gaj, T., Lavzin, M., Ritola, K.D., Lindo, S., Michael, S., Kuleshova, E., Ojala, D., et al. (2016). A Designer AAV Variant Permits Efficient Retrograde Access to Projection Neurons. Neuron *92*, 372–382. https://doi.org/10.1016/j.neuron.2016. 09.021.
- Challis, R.C., Ravindra Kumar, S., Chen, X., Goertsen, D., Coughlin, G.M., Hori, A.M., Chuapoco, M.R., Otis, T.S., Miles, T.F., and Gradinaru, V. (2022). Adeno-Associated Virus Toolkit to Target Diverse Brain Cells. Annu. Rev. Neurosci. 45, 447–469. https://doi.org/10.1146/annurevneuro-111020-100834.
- 133. Huang, Q., Chan, K.Y., Wu, J., Botticello-Romero, N.R., Zheng, Q., Lou, S., Keyes, C., Svanbergsson, A., Johnston, J., Mills, A., et al. (2024). An AAV capsid reprogrammed to bind human transferrin receptor mediates brain-wide gene delivery. Science 384, 1220–1227. https://doi.org/10. 1126/science.adm8386.
- Cupo, R.R., and Shorter, J. (2020). Expression and Purification of Recombinant Skd3 (Human ClpB) Protein and Tobacco Etch Virus (TEV)

Protease from Escherichia coli. Bio. Protoc. 10, e3858. https://doi.org/ 10.21769/BioProtoc.3858.

- 135. Michalska, K., Zhang, K., March, Z.M., Hatzos-Skintges, C., Pintilie, G., Bigelow, L., Castellano, L.M., Miles, L.J., Jackrel, M.E., Chuang, E., et al. (2019). Structure of Calcarisporiella thermophila Hsp104 Disaggregase that Antagonizes Diverse Proteotoxic Misfolding Events. Structure 27, 449–463.e7. https://doi.org/10.1016/j.str.2018.11.001.
- Elden, A.C., Kim, H.J., Hart, M.P., Chen-Plotkin, A.S., Johnson, B.S., Fang, X., Armakola, M., Geser, F., Greene, R., Lu, M.M., et al. (2010). Ataxin-2 intermediate-length polyglutamine expansions are associated with increased risk for ALS. Nature 466, 1069–1075. https://doi.org/10. 1038/nature09320.
- 137. Rueden, C.T., Schindelin, J., Hiner, M.C., DeZonia, B.E., Walter, A.E., Arena, E.T., and Eliceiri, K.W. (2017). ImageJ2: ImageJ for the next generation of scientific image data. BMC Bioinf. 18, 529. https://doi.org/10. 1186/s12859-017-1934-z.
- Braig, K., Otwinowski, Z., Hegde, R., Boisvert, D.C., Joachimiak, A., Horwich, A.L., and Sigler, P.B. (1994). The crystal structure of the bacterial chaperonin GroEL at 2.8 A. Nature *371*, 578–586. https://doi.org/10. 1038/371578a0.
- Gietz, R.D., and Schiestl, R.H. (2007). High-efficiency yeast transformation using the LiAc/SS carrier DNA/PEG method. Nat. Protoc. 2, 31–34. https://doi.org/10.1038/nprot.2007.13.





STAR*METHODS

KEY RESOURCES TABLE

Babbit anti-Hsp104 polyclonal Enzo Life Sciences Cat# AD0-SPA-1040-F; RRID: AB_203920 Babbit anti-FUS polyclonal Bethyl Laboratories Cat# AD0-SPA-1040-F; RRID: AB_2039445 Babbit anti-FUS polyclonal Proteintech Cat# aD1630-24, RRID: AB_305445 Babbit anti-GFP polyclonal Sigma-Aldrich Cat# aD160, RD12, AB_90900 Babbit monoclonal anti-alpha tubulin antibody Abcam Cat# aD160, RD253281 Mease anti-FeXt monoclonal Thomo Fisher Cat# aD167, SD253281 Mouse anti-FeXt monoclonal Thomo Fisher Cat# s0250, RRID: AB_205216 RD9e 800CW Goat anti-Rabbit IgG secondary antibody LI-COR Cat# 928-82210, RRID: AB_103666 RD9e 800CW Goat anti-Rabbit IgG secondary Antibody LI-COR Cat# 928-92210, RRID: AB_10360166 RD9e 800CW Goat anti-Rabit IgG Secondary Antibody LI-COR Cat# 928-92210, RRID: AB_1036025 Bacterial and virus strains Secondary Antibody LI-COR Cat# 928-9071; RRID: AB_180025 Bacterial and virus strains Thermo Fisher Cat# 18286017 Cat# 928-92119; RRID: AB_180025 Bacterial and virus strains Thermo Fisher Cat# 18286017 Cat# 928-92119; RRID: AB_180001 Bacterial and vir	REAGENT or RESOURCE	SOURCE	IDENTIFIER
Babbit arti-FUS polyclonalBethyl LaboratoriesCatt 1078-2-xP, RRID: AB_309445Babbit arti-TDP-43 polyclonalSigma-AldrichCatt 1078-2-xP, RRID: AB_515042Babbit monoclonal anti-sipha tubulin antibodyAbcamCatt 405141, RRID: AB_305328Adouse anti-PGK1 monoclonalThermo FisherCatt 495205, RRID: AB_251820Inti-mCherry polyclonal antibodyAbcamCatt 495205, RRID: AB_251820RDye 800CW Goat anti-Babbit IgG secondary antibodyLI-CORCatt 926-80211; RRID: AB_15605166BDye 680RD Goat anti-Rat IgG secondary antibodyLI-CORCatt 926-80211; RRID: AB_16805166BDye 800CW Goat anti-Rat IgG secondary antibodyLI-CORCatt 926-82210; RRID: AB_16805166BDye 800CW Goat anti-Rat IgG secondary antibodyLI-CORCatt 926-82219; RRID: AB_1680025Bacterial and virus strainsLI-CORCatt 926-42219; RRID: AB_1680025Bacterial and virus atrainsThermo FisherCatt 12820545Catt Catt DI-Sc competent cellsThermo FisherCatt 610410Chatt Catt DI-Sc competent cellsNocheCatt 1021722001Chatt Catt DI-Sc Competent Escherichia coliInvitrogenCatt 1021722001Chattors Sc FighthatRocheCatt 1178013Chattors Sc FighthatNocheCatt 1178013Cattery PI Conse II Enzyme MixInvitrogenCatt 810785Stateway LR Conse II Enzyme MixInvitrogenCatt 469315001Sigma-AldrichCatt 11791019Catt 11791019LEBulder HFI DNA Assembly Master MixNEBCatt 469315001Sigma-Aldrich<	Antibodies		
labbit anti-TDP-43 polycionalProteintechCat# 10782-2-AP; RRID: AB_615042labbit anti-GPP polycional anti-liqba tubulin antibodyAbcamCat# 459160; RRID: AB_95328labbit moncional anti-liqba tubulin antibodyAbcamCat# 459250; RRID: AB_2571870RDye 800CW Goat anti-Mouse IgG secondary antibodyLI-CORCat# 956-32210; RRID: AB_2571870RDye 800CW Goat anti-Raubit IgG secondary antibodyLI-CORCat# 926-32210; RRID: AB_21042RDye 800CW Goat anti-Raubit IgG secondary antibodyLI-CORCat# 926-8071; RRID: AB_21042RDye 800CW Goat anti-Rau IgG Secondary antibodyLI-CORCat# 926-8071; 	Rabbit anti-Hsp104 polyclonal	Enzo Life Sciences	Cat# ADI-SPA-1040-F; RRID: AB_2039208
kabbit anti-GFP polyconalSigma-AldrichCat# d5154t; RRID: AB_439690Abbit monoclonal anti-lapha tubulin antibodyAbcamCat# 45050; RRD: AB_2552255Auses anti-PGKT monoclonalThermo FisherCat# 45250; RRD: AB_2552255knit-mCherry polyclonal antibodyAbcamCat# 45250; RRD: AB_2552210; RRID: AB_621442RDye 800CW Goat anti-Rabbit IgG secondary antibodyLI-CORCat# 926-68071; RRID: AB_621642RDye 680RD Goat anti-Rabbit IgG secondary AntibodyLI-CORCat# 926-68071; RRID: AB_10560166RDye 800CW Goat anti-Rat IgG Secondary AntibodyLI-CORCat# 926-68071; RRID: AB_10560025Sacharichia coli DI-Sacharichia coliInvitrogenCat# 1225017Sacharichia coli DI-Sacharichia coliInvitrogenCat# 1225017Sacharichia coli DI-Sacharichia coliInvitrogenCat# 926-88071; RRID: AB_2722001Cheate polysphyteRocheCat# 10621722001Cheate polysphyteRocheCat# 10621722001Cheate polysphyteNocheCat# 11789013Cheate polysphyteNocheCat# 11789013Cheate polysphyteNocheCat# 11789013Cheate polysphiteRoche	Rabbit anti-FUS polyclonal	Bethyl Laboratories	Cat# A300-302A; RRID: AB_309445
kabbit monoclonal anti-alpha tubulin antibodyAbcamCat# ab6160; RRID: AB_305328Adouse anti-PGK1 monoclonalThermo FisherCat# ab6160; RRID: AB_2532235Multim-Cherry polyclonal antibodyAbcamCat# ab61763; RRID: AB_2571870RDye 800CW Goat anti-Mouse IgG secondary antibodyLI-CORCat# 926-32210; RRID: AB_058166BDye 680RD Goat anti-Rat IgG Secondary antibodyLI-CORCat# 926-32219; RRID: AB_10565166BDye 800CW Goat anti-Rat IgG Secondary AntibodyLI-CORCat# 926-32219; RRID: AB_10565166Cat# 926-32219; Scherrichia col // BL21-CodonPlus (DE3)AgilentCat# 12625017Scherrichia col // BL21-CodonPlus (DE3)AgilentCat# 230245Scherrichia col // BL21-CodonPlus (DE3)AgilentCat# 10621722001Scherrichia col // BL21-CodonPlus (DE3)AgilentCat# 10621722001Chennically, poptides, and recombinant proteinsCat# 10621722001Chennically, competent cellsNocheCat# 1162306001Chennically, Competent Escherichia coliInvitrogenCat# 1178013Zherway DF Clonase II Enzyme MixInvitrogenCat# 1178013Zherway DF Clonase II Enzyme MixInvitrogenCat# 1178013Zherway DF Clonase II Enzyme MixInvitrogenCat# 10127566001Zherway DF Clonase II Enzyme MixInvitrogenCat# 46821SCompetent Min, InvitrogenCat# 10127566001Zherway DF Clonase II Enzyme MixNCHCat# 10127566001Zherway DF Clonase II Enzyme MixNCHCat# 10127566001Zherway DF Clonase II Enzyme MixNCH	Rabbit anti-TDP-43 polyclonal	Proteintech	Cat# 10782-2-AP; RRID: AB_615042
Abuse anti-PGK1 monoclonal Thermo Fisher Cat# 459250; RRID: AB_2532235 Nuti-mCherry polycional antibody Abcam Cat# 459250; RRID: AB_2571870 RDye 800CW Goat anti-Mouse IgG secondary antibody LI-COR Cat# 926-82210; RRID: AB_10596166 RDye 800CW Goat anti-Rabbit IgG secondary antibody LI-COR Cat# 926-8071; RRID: AB_10596166 RDye 800CW Goat anti-Rabbit IgG secondary Antibody LI-COR Cat# 926-8071; RRID: AB_10596166 Bacterial and virus strains LI-COR Cat# 926-8071; RRID: AB_10596166 Sacherichia coli DH5x competent cells Thermo Fisher Cat# 926027 Sacherichia coli DL12-CodonPlus (DE3) Agilent Cat# 202045 Inc competent cells Invitrogen Cat# 0421722001 Pastine phosphate Roche Cat# 1182306010 Charles posphate NEB Cat# 11789013 Conse II Enzyme Mix Invitrogen Cat# 11789013 Sateway LR Clonase II Enzyme Mix Invitrogen Cat# 11789013 Cat# VIP Coses Sigma-Aldrich Cat# 493159001 Case Influersecein isothicozyanate from Sigma-Aldrich Cat# 11789013 Corone II Enzyme Mix	Rabbit anti-GFP polyclonal	Sigma-Aldrich	Cat# G1544; RRID: AB_439690
Abcam Cat# ab167453; RRID: AB_2571870 RDye 800CW Goat anti-Mouse IgG secondary antibody LI-COR Cat# sp26-32210; RRID:AB_221842 RDye 680RD Goat anti-Rabbit IgG secondary antibody LI-COR Cat# sp26-32210; RRID:AB_221842 RDye 680RD Goat anti-Rabbit IgG secondary antibody LI-COR Cat# sp26-68271; RRID: AB_10956166 Stepse 800CW Goat anti-Rabbit IgG secondary Antibody LI-COR Cat# sp26-82219; RRID: AB_1850025 Scherichia coli DL21-CodonPlus (DE3) Aglent Cat# sp26-52219; RRID: AB_1850025 Scherichia coli BL21-CodonPlus (DE3) Aglent Cat# cat# cat# cat# cat# cat# cat# cat# c	Rabbit monoclonal anti-alpha tubulin antibody	Abcam	Cat# ab6160; RRID: AB_305328
RDye 800CW Goat anti-Ausse IgG secondary antibody LI-COR Catt 926-62210; RRID:AB_621842 Catt 926-68071; RRID:AB_621842 RDye 650RD Goat anti-Rabbit IgG secondary Antibody LI-COR Catt 926-68071; RRID:AB_6166 Catt 926-68219; RRID:AB_6166 RDye 800CW Goat anti-Rat IgG Secondary Antibody LI-COR Catt 926-63219; RRID:AB_1650: competent cells Thermo Fisher Catt 926-63219; Scherichia coli BL1-CodonPlus (DES) Agilent Catt 2420245 Scherichia coli BL1-CodonPlus (DES) Agilent Catt C404010 Dens Shot TOP10 Chemically Competent Escherichia coli Invitrogen Catt 0401722001 One Shot TOP10 Chemically Competent Escherichia coli Invitrogen Catt 101821722001 One Shot TOP10 Chemically Competent Escherichia coli Invitrogen Catt 40102 Dens Shot TOP10 Chemically Porteins Roche Catt 1118206001 Stateway BP Cionase II Enzyme Mix Invitrogen Catt 1118206001 Stateway BP Cionase II Enzyme Mix Invitrogen Catt 403159001 Stateway BP Cionase II Enzyme Mix Invitrogen Catt 40276 Stateway BP Cionase II Enzyme Mix Invitrogen Catt 40315901 <td>Mouse anti-PGK1 monoclonal</td> <td>Thermo Fisher</td> <td>Cat# 459250; RRID: AB_2532235</td>	Mouse anti-PGK1 monoclonal	Thermo Fisher	Cat# 459250; RRID: AB_2532235
RDye 800CW Goat anti-Ausse IgG secondary antibody LI-COR Catt 926-62210; RRID:AB_621842 Catt 926-68071; RRID:AB_621842 RDye 650RD Goat anti-Rabbit IgG secondary Antibody LI-COR Catt 926-68071; RRID:AB_6166 Catt 926-68219; RRID:AB_6166 RDye 800CW Goat anti-Rat IgG Secondary Antibody LI-COR Catt 926-63219; RRID:AB_1650: competent cells Thermo Fisher Catt 926-63219; Scherichia coli BL1-CodonPlus (DES) Agilent Catt 2420245 Scherichia coli BL1-CodonPlus (DES) Agilent Catt C404010 Dens Shot TOP10 Chemically Competent Escherichia coli Invitrogen Catt 0401722001 One Shot TOP10 Chemically Competent Escherichia coli Invitrogen Catt 101821722001 One Shot TOP10 Chemically Competent Escherichia coli Invitrogen Catt 40102 Dens Shot TOP10 Chemically Porteins Roche Catt 1118206001 Stateway BP Cionase II Enzyme Mix Invitrogen Catt 1118206001 Stateway BP Cionase II Enzyme Mix Invitrogen Catt 403159001 Stateway BP Cionase II Enzyme Mix Invitrogen Catt 40276 Stateway BP Cionase II Enzyme Mix Invitrogen Catt 40315901 <td>Anti-mCherry polyclonal antibody</td> <td>Abcam</td> <td>Cat# ab167453; RRID: AB_2571870</td>	Anti-mCherry polyclonal antibody	Abcam	Cat# ab167453; RRID: AB_2571870
RID: AB_10856166 RDye 800CW Goat anti-Rat IgG Secondary Antibody LI-COR Cat#926-32219; RRID: AB_1085025 Sacterial and virus strains Escherichia coli DH5x competent cells Thermo Fisher Cat# 18265017 Sacherichia coli DH5x competent cells Thermo Fisher Cat# 230245 Sicherichia coli DH5x competent fescherichia coli Invitrogen Cat# 2404010 Dne Shot TOP10 Chemically Competent Escherichia coli Invitrogen Cat# 10621722001 Shemicals, paptides, and recombinant proteins Foche Cat# 10621722001 Chemicals, paptides, and recombinant proteins Foche Cat# 10621722001 Shemicals, paptides, and recombinant proteins Foche Cat# 10621722001 Chemicals, paptides, and recombinant proteins Foche Cat# 10621722001 Steway BP Cionase II Enzyme Mix Roche Cat# 11791019 Veldenosine 5'-triphosphate tetraitihium salt Roche Cat# 11791019 Veldenosine B'-trihorsphate Invitrogen Cat# 4080150001 Sateway LP Cionase II Enzyme Mix Invitrogen Cat# 4080150001 Sateway LP Cionase II Enzyme Mix NEB Cat# 1027566001 Sateway LP Cionase II Enzyme Mix NEB Cat# 10127566001 Sateway LP Cionase II Enzyme Mix NEB Cat# 10127566001 Sateway LP Cionase II Enzyme Mix	RDye 800CW Goat anti-Mouse IgG secondary antibody	LI-COR	Cat# 926-32210;
RRID: AB_1850025 Bacterial and virus strains Scherichia coll DH5x competent cells Thermo Fisher Cat# 18265017 Scherichia coll DL21-CodonPlus (DE3) Agllent Cat# 230245 Scherichia coll DL21-CodonPlus (DE3) Invitrogen Cat# 2404010 Den Shot TOP10 Chemically Competent Escherichia col Invitrogen Cat# 10621722001 Scherichia cols and recombinant proteins Sigma-Aldrich Cat# 10621722001 Scherichia cols Juptote tetralithium salt Roche Cat# 11162306001 Scherichia cols Juptote tetralithium salt Roche Cat# 11789013 Sateway BP Clonase II Enzyme Mix Invitrogen Cat# 11799013 Sateway LR Clonase II Enzyme Mix Invitrogen Cat# 4693159001 Sateway LR Clonase II Enzyme Mix NEB Cat# 2621S Completer, Mini, EDTA-free Protease Inhibitor Cocktail Sigma-Aldrich Cat# 4693159001 Sateway LR Clonase II Enzyme Mix NEB Cat# 10127566001 Sorine mik (FITC-Casein) Sigma-Aldrich Cat# 4693159001 Sorine mik (FITC-Casein) Sigma-Aldrich Cat# 10127566001	RDye 680RD Goat anti-Rabbit IgG secondary antibody	LI-COR	
Eacherichia coli DH5x competent cells Thermo Fisher Cat# 18265017 Scherichia coli BL21-CodonPlus (DE3) Agilent Cat# 230245 RIL competent cells Invitrogen Cat# C404010 Die Shot TOP10 Chemically Competent Escherichia coli Invitrogen Cat# 10821722001 Chemicals, peptides, and recombinant proteins Exercised and the combinant proteins Cat# A3377 Zreatine phosphate Roche Cat# 110820001 Adenosine 5'-fry-thiol triphosphate tetralithium salt Roche Cat# 111789013 April NEB Cat# 11789013 Sateway BP Clonase II Enzyme Mix Invitrogen Cat# 11791019 VEBuilder HiFi DNA Assembly Master Mix NEB Cat# 22621S Complete, Mini, EDTA-free Protease Inhibitor Cocktail Sigma-Aldrich Cat# 4693159001 Casein fluorescein isothiocyanate from Sigma-Aldrich Cat# 10127566001 Cariefy Luciferase Sigma-Aldrich Cat# L6876 vysozyme Sigma-Aldrich Cat# L6876 vysozyme Sigma-Aldrich Cat# L6876 vysozyme Sigma-Aldrich Cat# L6876 vysozyme Sigma-Aldrich Cat# L6876 <td< td=""><td>RDye 800CW Goat anti-Rat IgG Secondary Antibody</td><td>LI-COR</td><td></td></td<>	RDye 800CW Goat anti-Rat IgG Secondary Antibody	LI-COR	
Eacherichia coli BL21-CodonPlus (DE3) RL competent cellsAglientCat# 230245BRL competent cellsInvitrogenCat# C404010Chemicals, peptides, and recombinant proteinsSigma-AldrichCat# 10621722001Chemicals, peptides, and recombinant proteinsSigma-AldrichCat# A3377Creatine phosphateRocheCat# 11162306001Adenosine 5'-fry-thio] triphosphate tetralithium saltRocheCat# 1178013Adenosine 5'-fry-thio] triphosphate tetralithium saltRocheCat# 1178013DoplNEBCat# 2621SSateway BP Clonase II Enzyme MixInvitrogenCat# 2621SAlteway LP Clonase II Enzyme MixInvitrogenCat# 493159001AEdway LP Clonase II Enzyme MixNEBCat# 2621SSomplere, Mini, EDTA-free Protease Inhibitor CocktailSigma-AldrichCat# 0127566001Casein fluorescein isothiocyanate from ovine milk (FTC-Casein)Sigma-AldrichCat# 1178570Creatine kinaseRocheCat# 10127566001Creatine kinaseSigma-AldrichCat# 11870Creatine kinaseSigma-AldrichCat# 11870Creatine kinaseNocheCat# 1168027Creatine kinaseGigma-AldrichCat# 118570Creatine kinaseGigma-AldrichCat# 1168027Creatine 2000 Transfection ReagentInvitrogenCat# 1195065Lipofectarnine 2000 Transfection ReagentInvitrogenCat# 1195005Lipofectarnine 2000 Transfection ReagentInvitrogenCat# 110122Patal bovine serumGibcoCat# 1109003 </td <td>Bacterial and virus strains</td> <td></td> <td></td>	Bacterial and virus strains		
RilL competent cells Invitrogen Cat# C404010 Chemically Competent Escherichia coli Invitrogen Cat# C404010 Chemicals, peptides, and recombinant proteins Roche Cat# 10621722001 Vadenosine 5'-trjhosphate disodium salt hydrate (ATP) Sigma-Aldrich Cat# A3377 Vadenosine 5'-try-thio] triphosphate tetralithium salt Roche Cat# 11162306001 Oppl NEB Cat# 11789013 Sateway BP Clonase II Enzyme Mix Invitrogen Cat# 117191019 VEB Cat# 11789013 Cat# 117191019 Vadenosine 5'-trjn-chroip triphosphate tetralithium salt Nitrogen Cat# 117191019 Vateway BP Clonase II Enzyme Mix Invitrogen Cat# 117191019 Vateway LP Clonase II Enzyme Mix NEB Cat# 2621S Somplete, Mini, EDTA-free Protease Inhibitor Cocktail Sigma-Aldrich Cat# 1027566001 Vaseini (FITC-Casein) Sigma-Aldrich Cat# 10127566001 Oreatine Kinase Roche Cat# 10127566001 Vaseini (FITC-Casein) Sigma-Aldrich Cat# 113570 Vaterini (Vitogen Cat# 1158027 Cat# 1148027 Vaterini (Vitogen Cat# 1158027 Cat# 1148027 Vasormine 2000 Transfection Reagent Invitrogen Cat# 1168027 Vapofetamine 2000 Transfection Reagent	Escherichia coli DH5α competent cells	Thermo Fisher	Cat# 18265017
Demicals, peptides, and recombinant proteins Dreatine phosphate Roche Cat# 10621722001 Valenceine 5'-triphosphate disodium salt hydrate (ATP) Sigma-Aldrich Cat# 43377 Adenosine 5'-triphosphate identify and the second secon	Escherichia coli BL21-CodonPlus (DE3) RIL competent cells	Agilent	Cat# 230245
Dreatine phosphateRocheCat# 10621722001Adenosine 5'-triphosphate disodium salt hydrate (ATP)Sigma-AldrichCat# A3377Adenosine 5'-[thio] triphosphate tetralithium saltRocheCat# 11162306001OpnlNEBCat# R0176SSateway BP Clonase II Enzyme MixInvitrogenCat# 11789013Sateway LR Clonase II Enzyme MixInvitrogenCat# 11791019NEBCat# E2621SSomplete, Mini, EDTA-free Protease Inhibitor CocktailSigma-AldrichCat# 4693159001Sateway LR Clonase II Enzyme MixNEBCat# C0528Somplete, Mini, EDTA-free Protease Inhibitor CocktailSigma-AldrichCat# 10127566001Sigma-AldrichCat# 10127566001Cirefty luciferaseSyozymeSigma-AldrichCat# 10506Veatine kinaseRocheCat# 10127566001Cirefty luciferaseSigma-AldrichCat# 10506Lipofectamine 2000 Transfection ReagentInvitrogenCat# 10427Lipofectamine 3000 Transfection ReagentInvitrogenCat# 11985085Vector LaboratoriesCat# 11985085Cat# 11985085Fetal bovine serumCytivaCat# 11995085Penicillin-streptomycinGibcoCat# 1194010.03Penicillin-streptomycinGibcoCat# 1194010.03Penicillin-streptomycinGibcoCat# 11982085Fetal bovine serumCytivaCat# 1194010.03Penicillin-streptomycinGibcoCat# 1198010.03Penicillin-streptomycinGibcoCat# 1198092.Fetal bovine serumCyti	One Shot TOP10 Chemically Competent Escherichia coli	Invitrogen	Cat# C404010
Adenosine 5'-triphosphate disodium salt hydrate (ATP)Sigma-AldrichCat# A3377Adenosine 5'-fy-thioj triphosphate tetralithium saltRocheCat# 11162306001DpnlNEBCat# R0176SSateway BP Clonase II Enzyme MixInvitrogenCat# 11789013Sateway LR Clonase II Enzyme MixInvitrogenCat# 11791019VEBuilder HiFi DNA Assembly Master MixNEBCat# 22621SComplete, Mini, EDTA-free Protease Inhibitor CocktailSigma-AldrichCat# 4693159001Sateway LR CoraseSigma-AldrichCat# C0528Somine milk (FITC-Casein)Sigma-AldrichCat# 2656001Creatine kinaseRocheCat# L0506SysycymeSigma-AldrichCat# L0506Jordectamine 2000 Transfection ReagentInvitrogenCat# L0506Jordectamine 3000 Transfection ReagentInvitrogenCat# L030001VECTASHIELD Antifade Mounting Medium with DAPIVector LaboratoriesCat# 11995065Cett H 1200-10GibcoCat# 11995065Tetal bovine serumCytivaCat# 11995065Fells InsertingGibcoCat# 1100-0276Poly-D-LysineGibcoCat# 1100-276Fells Tety proteaseSigmaCupo and Shorter ¹³⁴ V/Atsp104Jackrel et al. ⁴² N/A	Chemicals, peptides, and recombinant proteins		
Adenosine 5'-{ry-thio] triphosphate tetralithium saitRocheCat# 11162306001OpnlNEBCat# R0176SSateway BP Clonase II Enzyme MixInvitrogenCat# 11789013Sateway LR Clonase II Enzyme MixInvitrogenCat# 11791019NEBCat# 11791019Sigma-AldrichCat# 2621SSomplete, Mini, EDTA-free Protease Inhibitor CocktailSigma-AldrichCat# 4693159001Satein fluorescein isothiocyanate from oovine milk (FITC-Casein)Sigma-AldrichCat# 2621SCreatine kinaseRocheCat# 10127566001Sirrefly luciferaseSigma-AldrichCat# L6876Joeckst 33342 stainInvitrogenCat# L6876Joeckst 33342 stainInvitrogenCat# 1168027Jipofectamine 3000 Transfection ReagentInvitrogenCat# 1168027Jipofectamine 3000 Transfection ReagentInvitrogenCat# 11995065Cett# L676Cat# L1995065Cat# 11995065Eeta bovine serumCytivaCat# 5140122Poly-D-LysineGibcoCat# 11995065FeSR Plus mediumSTEMCELL TechnologiesCat# 1100-276Poly-D-LysineGibcoCat# 149892GibcoCat# 43890401Gat# 43890401GliSigmaCat# H9892Gibc1SigmaCat# H9892Heart HeartCupo and Shorter ¹³⁴ N/AKeart HeartCupo and Shorter ¹³⁴ N/A	Creatine phosphate	Roche	Cat# 10621722001
AppelNEBCat# R0176SBateway BP Clonase II Enzyme MixInvitrogenCat# 11789013Bateway LR Clonase II Enzyme MixInvitrogenCat# 11791019VEBuilder HiFi DNA Assembly Master MixNEBCat# E2621SCOmplete, Mini, EDTA-free Protease Inhibitor CocktailSigma-AldrichCat# 4693159001Cates II furgerSigma-AldrichCat# 0528Complete, Minise EDTA-free Protease Inhibitor CocktailSigma-AldrichCat# 10127566001Cates RobeCat# 10127566001Cat# L8506Correctine kinaseSigma-AldrichCat# L8576Corectine kinaseSigma-AldrichCat# L8576Corectine kinaseSigma-AldrichCat# L8576Corectine kinaseInvitrogenCat# L8576Corectine 2000 Transfection ReagentInvitrogenCat# 11668027Lipofectamine 3000 Transfection ReagentInvitrogenCat# 1100-10MEM, high glucose, pyruvateGibcoCat# H1995065Cetta H19500Cat# 11995065Cat# 11995065Fetal bovine serumCytivaCat# 830910.03Penicillin-streptomycinGibcoCat# 1190-0276Poly-D-LysineGibcoCat# A8309401ClSigmaCat# P3809Kert LEV proteaseCupo and Shorter ¹³⁴ N/AKert LEV proteaseCupo and Shorter ¹³⁴ N/A	Adenosine 5'-triphosphate disodium salt hydrate (ATP)	Sigma-Aldrich	Cat# A3377
ActionCat# 1789013Cateway BP Clonase II Enzyme MixInvitrogenCat# 11791019Sateway LR Clonase II Enzyme MixNEBCat# 2621SSomplete, Mini, EDTA-free Protease Inhibitor CocktailSigma-AldrichCat# 4693159001Casein fluorescein isothiocyanate from sovine milk (FITC-Casein)Sigma-AldrichCat# 10127566001Creatine kinaseRocheCat# 10127566001Creatine kinaseSigma-AldrichCat# 19506VerorymeSigma-AldrichCat# 16876VoorgenSigma-AldrichCat# 1168027VoorgenSigma-AldrichCat# 11668027VoorgenInvitrogenCat# 11668027Vipofectamine 2000 Transfection ReagentInvitrogenCat# 11095065Lipofectamine 3000 Transfection ReagentInvitrogenCat# 11995065Veror LaboratoriesCat# 11995065Cat# 11995065Fetal bovine serumCytivaCat# 5H3091.03Penicillin-streptomycinGibcoCat# 15H40122FeSR Plus mediumSTEMCELL TechnologiesCat# 43890401ClSigmaCut# 43890401ClSigmaCat# H9892Hot PorteaseCupo and Shorter ¹⁵⁴ N/A	Adenosine 5'-[γ -thio] triphosphate tetralithium salt	Roche	Cat# 11162306001
Bateway LR Clonase II Enzyme MixInvitrogenCat# 11791019NEBuilder HiFi DNA Assembly Master MixNEBCat# E2621SComplete, Mini, EDTA-free Protease Inhibitor CocktailSigma-AldrichCat# 4693159001Casein fluorescein isothiocyanate from povine milk (FITC-Casein)Sigma-AldrichCat# C0528Creatine kinaseRocheCat# 10127566001Creatine kinaseSigma-AldrichCat# L9506CysozymeSigma-AldrichCat# L6876toechst 33342 stainInvitrogenCat# 11688027Lipofectamine 2000 Transfection ReagentInvitrogenCat# 11688027Lipofectamine 3000 Transfection ReagentInvitrogenCat# 11995065VECTASHIELD Antifade Mounting Medium with DAPIVector LaboratoriesCat# 11995065Vetal bovine serumCytivaCat# 11995065Penicillin-streptomycinGibcoCat# 11022eSR Plus mediumSTEMCELL TechnologiesCat# 100-0276Poly-D-LysineGibcoCat# 438904014C1SigmaCat# H98924tis-TEV proteaseCupo and Shorter ¹³⁴ N/A	Dpnl	NEB	Cat# R0176S
LEBuilder HiFi DNA Assembly Master MixNEBCat# E2621SComplete, Mini, EDTA-free Protease Inhibitor CocktailSigma-AldrichCat# 4693159001Casein fluorescein isothiocyanate from povine milk (FITC-Casein)Sigma-AldrichCat# C0528Creatine kinaseRocheCat# 10127566001Creatine kinaseSigma-AldrichCat# L9506Creatine kinaseSigma-AldrichCat# L9506Creatine kinaseSigma-AldrichCat# L6876Lochest 33342 stainInvitrogenCat# H3570Lipofectamine 2000 Transfection ReagentInvitrogenCat# L300001Lipofectamine 3000 Transfection ReagentInvitrogenCat# L300001//ECTASHIELD Antifade Mounting Medium with DAPIVector LaboratoriesCat# 11995065Cat# 11995065GibcoCat# 11995065Cat# 100-0276GibcoCat# 110122Penicillin-streptomycinGibcoCat# 100-0276Poly-D-LysineGibcoCat# 48890401HCISigmaCup and Shorter ¹³⁴ N/AHsp104Jackrel et al. ⁴² N/A	Gateway BP Clonase II Enzyme Mix	Invitrogen	Cat# 11789013
Complete, Mini, EDTA-free Protesse Inhibitor CocktailSigma-AldrichCat# 4693159001Casein fluorescein isothiocyanate from oovine milk (FITC-Casein)Sigma-AldrichCat# C0528Creatine kinaseRocheCat# 10127566001Creatine kinaseSigma-AldrichCat# L9506Creatine kinaseSigma-AldrichCat# L9506Creatine kinaseSigma-AldrichCat# L6876Creatine kinaseInvitrogenCat# L6876Lipofectamine 2000 Transfection ReagentInvitrogenCat# L3000001Lipofectamine 3000 Transfection ReagentInvitrogenCat# L3000001VECTASHIELD Antifade Mounting Medium with DAPIVector LaboratoriesCat# H1200-10DMEM, high glucose, pyruvateGibcoCat# 11995065Fetal bovine serumCytivaCat# SH30910.03Penicillin-streptomycinGibcoCat# 100-0276Poly-D-LysineGibcoCat# 100-0276AldrichSigmaCat# H9892His-TEV proteaseCupo and Shorter ¹³⁴ N/AHyp104Jackrel et al. ⁴² N/A	Gateway LR Clonase II Enzyme Mix	Invitrogen	Cat# 11791019
Case in fluorescein isothiocyanate from bovine milk (FITC-Casein)Sigma-AldrichCat# C0528Creatine kinaseRocheCat# 10127566001Creatine kinaseSigma-AldrichCat# L9506Creatine kinaseSigma-AldrichCat# L9506CysozymeSigma-AldrichCat# L6876Hoechst 33342 stainInvitrogenCat# 11668027Lipofectamine 2000 Transfection ReagentInvitrogenCat# L3000001Lipofectamine 3000 Transfection ReagentInvitrogenCat# L3000001VECTASHIELD Antifade Mounting Medium with DAPIVector LaboratoriesCat# 11995065Cat# 11995065Cat# 11995065Cat# 11995065Fetal bovine serumGibcoCat# SH30910.03Penicillin-streptomycinGibcoCat# 15140122FeSR Plus mediumSTEMCELL TechnologiesCat# 100-0276Poly-D-LysineGibcoCat# H98924ClSigmaCupo and Shorter ¹³⁴ N/A4tsp104Jackrel et al. ⁴² N/A	NEBuilder HiFi DNA Assembly Master Mix	NEB	Cat# E2621S
bovine milk (FITC-Casein)Creatine kinaseRocheCat# 10127566001Creatine kinaseSigma-AldrichCat# L9506LysozymeSigma-AldrichCat# L6876Hoechst 33342 stainInvitrogenCat# H3570Lipofectamine 2000 Transfection ReagentInvitrogenCat# L300001Lipofectamine 3000 Transfection ReagentInvitrogenCat# L300001VECTASHIELD Antifade Mounting Medium with DAPIVector LaboratoriesCat# H1200-10DMEM, high glucose, pyruvateGibcoCat# H1995065Fetal bovine serumCytivaCat# SH30910.03Penicillin-streptomycinGibcoCat# 1104022FeSR Plus mediumSTEMCELL TechnologiesCat# 100-0276Poly-D-LysineGibcoCat# 43890401HCISigmaCat# H9892His-TEV proteaseCupo and Shorter ¹³⁴ N/AHsp104Jackrel et al. ⁴² N/A	COmplete, Mini, EDTA-free Protease Inhibitor Cocktail	Sigma-Aldrich	Cat# 4693159001
Firefly luciferaseSigma-AldrichCat# L9506LysozymeSigma-AldrichCat# L6876Hoechst 33342 stainInvitrogenCat# H3570Lipofectamine 2000 Transfection ReagentInvitrogenCat# L300001Lipofectamine 3000 Transfection ReagentInvitrogenCat# L300001//ECTASHIELD Antifade Mounting Medium with DAPIVector LaboratoriesCat# H-1200-10DMEM, high glucose, pyruvateGibcoCat# 11995065Fetal bovine serumCytivaCat# SH30910.03Penicillin-streptomycinGibcoCat# 15140122Poly-D-LysineGibcoCat# 100-0276Holy-DLysineSigmaCat# H9892His-TEV proteaseCupo and Shorter ¹³⁴ N/A	Casein fluorescein isothiocyanate from povine milk (FITC-Casein)	Sigma-Aldrich	Cat# C0528
JysozymeSigma-AldrichCat# L6876Hoechst 33342 stainInvitrogenCat# H3570Lipofectamine 2000 Transfection ReagentInvitrogenCat# 11668027Lipofectamine 3000 Transfection ReagentInvitrogenCat# L300001//ECTASHIELD Antifade Mounting Medium with DAPIVector LaboratoriesCat# H-1200-10DMEM, high glucose, pyruvateGibcoCat# 11995065Fetal bovine serumCytivaCat# SH30910.03Penicillin-streptomycinGibcoCat# 15140122Penicyllin-streptomycinGibcoCat# 100-0276Poly-D-LysineGibcoCat# 43890401HCISigmaCat# H9892His-TEV proteaseCupo and Shorter ¹³⁴ N/A	Creatine kinase	Roche	Cat# 10127566001
Hoechst 33342 stainInvitrogenCat# H3570Lipofectamine 2000 Transfection ReagentInvitrogenCat# 11668027Lipofectamine 3000 Transfection ReagentInvitrogenCat# L300001/ECTASHIELD Antifade Mounting Medium with DAPIVector LaboratoriesCat# H-1200-10DMEM, high glucose, pyruvateGibcoCat# SH30910.03Cetal bovine serumCytivaCat# 15140122Penicillin-streptomycinGibcoCat# 100-0276Poly-D-LysineGibcoCat# 43890401HCISigmaCat# H9892His-TEV proteaseCupo and Shorter ¹³⁴ N/A	Firefly luciferase	Sigma-Aldrich	Cat# L9506
InvitrogenCat# 11668027Lipofectamine 3000 Transfection ReagentInvitrogenCat# L300001Lipofectamine 3000 Transfection ReagentInvitrogenCat# L300001/ECTASHIELD Antifade Mounting Medium with DAPIVector LaboratoriesCat# H-1200-10DMEM, high glucose, pyruvateGibcoCat# 11995065Fetal bovine serumCytivaCat# SH30910.03Penicillin-streptomycinGibcoCat# 15140122FeSR Plus mediumSTEMCELL TechnologiesCat# 100-0276Poly-D-LysineGibcoCat# A3890401HCISigmaCat# H9892His-TEV proteaseCupo and Shorter ¹³⁴ N/AHsp104Jackrel et al. ⁴² N/A	_ysozyme	Sigma-Aldrich	Cat# L6876
Lipofectamine 3000 Transfection ReagentInvitrogenCat# L3000001/ECTASHIELD Antifade Mounting Medium with DAPIVector LaboratoriesCat# H-1200-10DMEM, high glucose, pyruvateGibcoCat# 11995065Fetal bovine serumCytivaCat# SH30910.03Pencicillin-streptomycinGibcoCat# 15140122FeSR Plus mediumSTEMCELL TechnologiesCat# 100-0276Poly-D-LysineGibcoCat# A3890401HCISigmaCat# H9892His-TEV proteaseCupo and Shorter ¹³⁴ N/AHsp104Jackrel et al. ⁴² N/A	Hoechst 33342 stain	Invitrogen	Cat# H3570
VECTASHIELD Antifade Mounting Medium with DAPIVector LaboratoriesCat# H-1200-10VMEM, high glucose, pyruvateGibcoCat# 11995065Cetal bovine serumCytivaCat# SH30910.03Pencicillin-streptomycinGibcoCat# 15140122TeSR Plus mediumSTEMCELL TechnologiesCat# 100-0276Poly-D-LysineGibcoCat# A3890401His-TEV proteaseCupo and Shorter ¹³⁴ N/AHisp104Jackrel et al. ⁴² N/A	ipofectamine 2000 Transfection Reagent	Invitrogen	Cat# 11668027
OMEM, high glucose, pyruvateGibcoCat# 11995065Fetal bovine serumCytivaCat# SH30910.03Penicillin-streptomycinGibcoCat# 15140122FeSR Plus mediumSTEMCELL TechnologiesCat# 100-0276Poly-D-LysineGibcoCat# A3890401HGISigmaCat# H9892His-TEV proteaseCupo and Shorter ¹³⁴ N/AHsp104Jackrel et al. ⁴² N/A	ipofectamine 3000 Transfection Reagent	Invitrogen	Cat# L3000001
Fetal bovine serumCytivaCat# SH30910.03Pencicillin-streptomycinGibcoCat# 15140122reSR Plus mediumSTEMCELL TechnologiesCat# 100-0276Poly-D-LysineGibcoCat# A38904014ClSigmaCat# H9892His-TEV proteaseCupo and Shorter ¹³⁴ N/AHsp104Jackrel et al. ⁴² N/A	/ECTASHIELD Antifade Mounting Medium with DAPI	Vector Laboratories	Cat# H-1200-10
Penicillin-streptomycinGibcoCat# 15140122TeSR Plus mediumSTEMCELL TechnologiesCat# 100-0276Poly-D-LysineGibcoCat# A3890401HCISigmaCat# H9892His-TEV proteaseCupo and Shorter ¹³⁴ N/AHsp104Jackrel et al. ⁴² N/A	DMEM, high glucose, pyruvate	Gibco	Cat# 11995065
TeSR Plus medium STEMCELL Technologies Cat# 100-0276 Poly-D-Lysine Gibco Cat# A3890401 HCl Sigma Cat# H9892 His-TEV protease Cupo and Shorter ¹³⁴ N/A Hsp104 Jackrel et al. ⁴² N/A	Fetal bovine serum	Cytiva	Cat# SH30910.03
Poly-D-Lysine Gibco Cat# A3890401 ICI Sigma Cat# H9892 His-TEV protease Cupo and Shorter ¹³⁴ N/A Isp104 Jackrel et al. ⁴² N/A	Penicillin-streptomycin	Gibco	Cat# 15140122
ACI Sigma Cat# H9892 His-TEV protease Cupo and Shorter ¹³⁴ N/A Hsp104 Jackrel et al. ⁴² N/A	TeSR Plus medium	STEMCELL Technologies	Cat# 100-0276
dis-TEV protease Cupo and Shorter ¹³⁴ N/A Hsp104 Jackrel et al. ⁴² N/A	Poly-D-Lysine	-	Cat# A3890401
Hsp104 Jackrel et al. ⁴² N/A	HCI	Sigma	Cat# H9892
Hsp104 Jackrel et al. ⁴² N/A	His-TEV protease	Cupo and Shorter ¹³⁴	N/A
	Hsp104		
	Hsp104 ^{A503S}	Jackrel et al. ⁴²	N/A



Continued			
REAGENT or RESOURCE	SOURCE	IDENTIFIER	
Hsp104 ^{R179D/V}	This paper	N/A	
Hsp104 ^{I187F}	Tariq et al. ⁷⁷	N/A	
Hsp104 ^{E190R/K}	This paper	N/A	
Hsp104 ^{E190R/K:R419E}	This paper	N/A	
Hsp104 ^{E191R:R419E}	This paper	N/A	
Hsp104 ^{E192R:R419E}	This paper	N/A	
Hsp104 ^{E190R:E191R:R419E}	This paper	N/A	
Hsp104 ^{E190R:E192R:R419E}	This paper	N/A	
Hsp104 ^{R194E}	Gates et al. ⁷³	N/A	
Hsp104 ^{E412K}	Gates et al. ⁷³	N/A	
Hsp104 ^{R194E:E412K}	This paper	N/A	
Hsp104 ^{R353E}	Gates et al. ⁷³	N/A	
Hsp104 ^{E427K}	Gates et al. ⁷³	N/A	
Hsp104 ^{R353E:E427K}	This paper	N/A	
Hsp104 ^{R366E}	Gates et al. ⁷³	N/A	
Hsp104 ^{D434K}	Gates et al. ⁷³	N/A	
Hsp104 ^{R366E:D434K}	This paper	N/A	
Hsp104 ^{D231R}	This paper	N/A	
Hsp104 ^{D232V/R}	This paper	N/A	
Hsp104 ^{D233R}		N/A	
Hsp104 ^{K358D}	This paper		
Hsp104 ^{E360R}	Mack et al. ⁴³	N/A	
Hsp104 ^{I361K}	Tariq et al. ⁷⁷	N/A	
Hsp104 ^{D408K/V}	This paper	N/A	
Hsp104 ^{K410E/L/V}	This paper	N/A	
Hsp104 ^{D492R}	This paper	N/A	
Hsp104 ^{R495D/E/N/M}	This paper	N/A	
Hsp104	Tariq et al. ⁷⁷	N/A	
Hsp104 ^{R496D}	This paper	N/A	
Hsp104 ^{R496V}	Ryan et al. ⁵³	N/A	
Hsp104 ^{D484K}	Mack et al. ⁴³	N/A	
Hsp104 ^{K480E}	Tariq et al. ⁷⁷	N/A	
Hsp104 ^{K480C/L}	This paper	N/A	
Hsp104 ^{K481C/E/L}	This paper	N/A	
Hsp104 ^{Y466C/K}	This paper	N/A	
Hsp104 ^{E521R/V}	This paper	N/A	
Hsp104 ^{M536K}	This paper	N/A	
Hsp104 ^{I537A/R}	This paper	N/A	
Hsp104 ^{H473F}	This paper	N/A	
Hsp104 ^{A531V}	This paper	N/A	
Hsp104 ^{R407E}	This paper	N/A	
Hsp104 ^{K470D/V}	This paper	N/A	
Hsp104 ^{K470Q}	Jackrel et al. ⁷²	N/A	
нарания и пределение и п Пределение и пределение и пределени	This paper	N/A	
Hsp104 ^{L414K}	This paper	N/A	
Hsp104 ^{N539L/E/D/G/K}	Jackrel et al. ⁴²	N/A	
Hsp104 ^{P411H}	This paper	N/A	
Hsp104 ^{E412K}	This paper	N/A	
Hsp104 ^{R419E}	Gates et al. ⁷³	N/A	
GroEL _{trap}	Jackrel et al. ⁴²	N/A	
		(Continued on n	

(Continued on next page)

CellPress OPEN ACCESS

Continued		
REAGENT or RESOURCE	SOURCE	IDENTIFIER
RepA _{1–15} -GFP	This paper	N/A
Hsc70	Enzo Life Sciences	Cat#ADI-SPP-751-F
DnaJA1	Enzo Life Sciences	Cat#ADI-SPP-405-F
bE-His ₆ -SUMO-Ssa1	Michalska et al. ¹³⁵	N/A
bE-His ₆ -SUMO-Sis1	Michalska et al. ¹³⁵	N/A
bE-His ₆ -SUMO-Ydj1	Michalska et al. ¹³⁵	N/A
FGET19-Ulp1	Addgene	Plasmid #64697
uciferase Assay Reagent	Promega	Cat# E1483
TPase Activity Kit (Colorimetric)	Innova Bioscieces	Cat# 601–0120
QuikChange Site-Directed Mutagenesis Kit	Agilent	Cat# 200518
xperimental models: Organisms/strains		
S. cerevisiae: W303a∆hsp104 (MATa, can1-100, nis3-11, 15, leu2-3, 112, trp1-1, ura3-1, ade2-1, hsp104:KanMX)	Jackrel et al. ⁴²	N/A
S. cerevisiae: W303a⊿hsp104-pAG303GAL- κ-syn-YFP-pAG304GAL-α-syn-YFP	Jackrel et al. ⁴²	N/A
S. cerevisiae: W303a⊿hsp104-pAG303GAL-FUS	Jackrel et al.42	N/A
S. cerevisiae: W303a⊿hsp104-pAG303GAL-TDP-43	Jackrel et al.42	N/A
Cell line:	-	-
luman: HeLa	ATCC	Cat#CCL-2; RRID:CVCL_0030
luman: HEK293	ATCC	Cat# CRL-1573; RRID:CVCL_0045
Recombinant DNA		
AG416GAL-CCDB	_	-
AG416GAL-Hsp104	Jackrel et al. ⁴²	N/A
AG416GAL-Hsp104 ^{A503S}	Jackrel et al. ⁴²	N/A
AG416GAL-Hsp104 ^{R179D/V}	This paper	N/A
AG416GAL-Hsp104 ^{I187F}	Tariq et al. ⁷⁷	N/A
AG416GAL-Hsp104 ^{E190R/K}	This paper	N/A
AG416GAL-Hsp104 ^{E190R/K:R419E}	This paper	N/A
AG416GAL-Hsp104 ^{E191R:R419E}	This paper	N/A
AG416GAL-Hsp104 ^{E192R:R419E}	This paper	N/A
AG416GAL-Hsp104 ^{E190R:E191R:R419E}	This paper	N/A
AG416GAL-Hsp104 ^{E190R:E192R:R419E}	This paper	N/A
AG416GAL-Hsp104 ^{E190R:E191R:E192R:R419E}	This paper	N/A
AG416GAL-Hsp104 ^{R194E}	Gates et al. ⁷³	N/A
AG416GAL-Hsp104 ^{E412K}	Gates et al. ⁷³	N/A
AG416GAL-Hsp104	This paper	N/A
AG416GAL-Hsp104 AG416GAL-Hsp104 ^{R353E}	Gates et al. ⁷³	N/A N/A
0AG416GAL-Hsp104 0AG416GAL-Hsp104 ^{E427K}	Gates et al. ⁷³	N/A
AG416GAL-Hsp104 AG416GAL-Hsp104 ^{R353E:E427K}	This paper	N/A N/A
AG416GAL-Hsp104 AG416GAL-Hsp104 ^{R366E}	Gates et al. ⁷³	N/A
AG416GAL-Hsp104 AG416GAL-Hsp104 ^{D434K}	Gates et al. ⁷³	N/A N/A
AG416GAL-Hsp104 AG416GAL-Hsp104 ^{R366E:D434K}		
	This paper	N/A
AG416GAL-Hsp104 ^{D231R}	This paper	N/A
AG416GAL-Hsp104 ^{D232V/R}	This paper	N/A
AG416GAL-Hsp104 ^{D233R}	This paper	N/A
AG416GAL-Hsp104 ^{K358D}	Mack et al. ⁴³	N/A
AG416GAL-Hsp104 ^{E360R}	Tariq et al. ⁷⁷	N/A
AG416GAL-Hsp104 ^{I361K}	This paper	N/A



Continued			
REAGENT or RESOURCE	SOURCE	IDENTIFIER	
pAG416GAL-Hsp104 ^{D408K/V}	This paper	N/A	
pAG416GAL-Hsp104 ^{K410E/L/V}	This paper	N/A	
pAG416GAL-Hsp104 ^{D492R}	This paper	N/A	
pAG416GAL-Hsp104 ^{R495D/E/N/M}	Tariq et al. ⁷⁷	N/A	
pAG416GAL-Hsp104 ^{R496D/V}	This paper	N/A	
pAG416GAL-Hsp104 ^{D484K}	Mack et al. ⁴³	N/A	
pAG416GAL-Hsp104 ^{K480E}	Tariq et al. ⁷⁷	N/A	
pAG416GAL-Hsp104 ^{K48C/L}	This paper	N/A	
pAG416GAL-Hsp104 ^{K481C/E/L}	This paper	N/A	
pAG416GAL-Hsp104 ^{Y466C/K}	This paper	N/A	
pAG416GAL-Hsp104 ^{E521R/V}	This paper	N/A	
pAG416GAL-Hsp104 ^{M536K}	This paper	N/A	
pAG416GAL-Hsp104 ^{I537A/R}	This paper	N/A	
pAG416GAL-Hsp104 ^{H473F}	This paper	N/A	
pAG416GAL-Hsp104 ^{A531V}	This paper	N/A	
pAG416GAL-Hsp104 ^{R407E}	This paper	N/A	
pAG416GAL-Hsp104 ^{K470D/V}	This paper	N/A	
pAG416GAL-Hsp104 ^{K470Q}	Jackrel et al. ⁷²	N/A	
pAG416GAL-Hsp104 ^{D408K/V}	This paper	N/A	
pAG416GAL-Hsp104 ^{L414K}	This paper	N/A	
pAG416GAL-Hsp104 ^{N539L/E/D/G/K}	Jackrel et al. ⁴²	N/A	
pAG416GAL-Hsp104 ^{P411H}	This paper	N/A	
pAG416GAL-Hsp104 ^{E412K}	This paper	N/A	
pAG416GAL-Hsp104 ^{R419E}	Gates et al. ⁷³	N/A	
pNOTAG-Hsp104	Jackrel et al. ⁴²	N/A	
pNOTAG-Hsp104 ^{A503S}	Jackrel et al. ⁴²	N/A	
pNOTAG-Hsp104 ^{R194E}	Gates et al. ⁷³	N/A	
pNOTAG-Hsp104 ^{E412K}	Gates et al. ⁷³	N/A	
pNOTAG-Hsp104 ^{R194E:E412K}	This paper	N/A	
pNOTAG-Hsp104 ^{R353E}	Gates et al. ⁷³	N/A	
pNOTAG-Hsp104 ^{E427K}	Gates et al. ⁷³	N/A	
pNOTAG-Hsp104 ^{R353E:E427K/R}	This paper	N/A	
pNOTAG-Hsp104 ^{R366E}	Gates et al. ⁷³	N/A	
pNOTAG-Hsp104 ^{D434K}	Gates et al. ⁷³	N/A	
pNOTAG-Hsp104 ^{R366E:D434K/R}	This paper	N/A	
pNOTAG-Hsp104 ^{E360R}	Tariq et al. ⁷⁷	N/A	
pNOTAG-Hsp104 ^{S535E}	Tariq et al. ⁷⁸	N/A	
pRS313HSE-ccdB	Gates et al. ⁷³	N/A	
pRS313HSE-Hsp104 ^{WT}	Gates et al. ⁷³	N/A	
pRS313HSE-Hsp104 ^{E190K}	This paper	N/A	
pRS313HSE-Hsp104 ^{R419E}	This paper	N/A	
pRS313HSE -Hsp104 ^{R194E:E412K/R}	This paper	N/A	
pRS313HSE -Hsp104 ^{R353E:E427K/R}	This paper	N/A	
pRS313HSE -Hsp104 ^{R366E:D434K/R}	This paper	N/A	
pTrc99A-GroEL _{trap}	Jackrel et al. ⁴²	N/A	
pBAD-RepA ₁₋₁₅ -GFP	Lopez et al. ⁹⁴	N/A	
pE-SUMO-Hsp72	This study	N/A	
pHis-TEV	Cupo and Shorter ¹³⁴	N/A	

(Continued on next page)

CellPress OPEN ACCESS

Continued		
REAGENT or RESOURCE	SOURCE	IDENTIFIER
pEGFP-FUS ^{WT}	Fare et al. ⁹⁵	N/A
pcDNA3.2 TDP-43 ^{∆NLS} -YFP	Elden et al. ¹³⁶	AddgeneCat#84912
mCherry2-N1	N/A	AddgeneCat#54563
PMV-Hsp104-mCherry	This study	N/A
PMV- Hsp104 ^{A503S} -mCherry	This study	N/A
PMV- Hsp104 ^{E191R:R419E} -mCherry	This study	N/A
PMV- Hsp104 ^{E360R} -mCherry	This study	N/A
PMV- Hsp104 ^{K481E} -mCherry	This study	N/A
PMV- Hsp104 ^{E535R} -mCherry	This study	N/A
Software and algorithms		
Prism 9	GraphPad	-
ImageJ	Rueden et al. ¹³⁷	N/A
PyMOL 4.6.0	Schrodinger, LLC	N/A
Discovery Studio Visualizer	Dassault Systemes Biovia Corp	N/A

EXPERIMENTAL MODEL AND STUDY PARTICIPANT DETAILS

Yeast strains

Yeast strains used were wild-type W303a (*MATa*, *can1-100*, *his3-11*, *15*, *leu2-3*, *112*, *trp1-1*, *ura3-1*, *ade2-1*) or the isogenic strain W303a Δ hsp104.⁴² The yeast strains W303a Δ hsp104-pAG303GAL- α -syn-YFP-pAG304GAL- α -syn-YFP, W303a Δ hsp104-pAG303GAL-FUS, and W303a Δ hsp104-pAG303GAL-TDP-43, have been described previously.^{42,50,52} Yeast were grown in rich medium (YPD) or in synthetic media without amino acids used for selection. 2% sugar (dextrose, raffinose, or galactose) was added to synthetic media.

HeLa and HEK293 cell maintenance

Once thawed, HeLa (female) or HEK293 (female) cells were maintained in Dulbecco's modified Eagle's medium (DMEM) containing high glucose, supplied by Gibco. This medium was enriched with 10% fetal bovine serum (FBS) from HyClone and 1% penicillinstreptomycin solution from Gibco. The cells were incubated in a humidified incubator at 37°C with 5% (v/v) CO₂. Cells that pass passage number 20 were discarded.

METHOD DETAILS

Site-directed mutagenesis

Mutations were introduced into Hsp104 through QuikChange site-directed mutagenesis (Agilent) and confirmed by DNA sequencing.

Protein purification

Hsp104

Hsp104 proteins were purified as previously described with the following modifications.⁴² Eluate from Affi-Gel Blue Gel was equilibrated to a low-salt buffer Q (\sim 100mM NaCl, 20mM Tris-HCl pH 8.0, 5mM MgCl₂, 0.5mM EDTA and 10% glycerol) and purified via ResourceQ anion exchange chromatography. Buffer Q (20mM TRIS-HCl pH 8.0, 50mM NaCl, 5mM MgCl₂, 0.5mM EDTA, and 10% glycerol) was used as running buffer, and the protein was eluted with a linear gradient of buffer Q+ (20mM Tris-HCl pH 8.0, 1M NaCl, 5mM MgCl₂, 0.5mM EDTA, and 10% glycerol). The eluted protein was buffer-exchanged into high-salt storage buffer (40mM HEPES-KOH pH 7.4, 500mM KCl, 20mM MgCl₂) plus 50% glycerol and 1mM DTT and snap-frozen.

GroELtrap

pTrc99A-GroEL_{trap} was transformed into DH5 α competent *E. coli* cells (Thermo Fisher). Cells were grown in 2xYT medium with appropriate antibiotics at 37°C with shaking until OD₆₀₀ reached ~0.4–0.6. Protein overexpression was induced with 1mM IPTG, and cells were grown at 37°C until OD₆₀₀~2.0. Cells were harvested by spinning (4,658g, 4°C, 15min) and pellet was resuspended in 50mM sodium phosphate buffer and centrifuged (4,658g, 4°C, 15min). The pellet fraction was resuspended in low-salt buffer (50mM Tris-HCl pH 7.5, 1mM EDTA, 1mM DTT, 50mM NaCl) and 10mg lysozyme per g cell pellet. Sample was stirred gently for 5min, lysed through sonication, and centrifuged (30,996g, 4°C, 30min). Clarified lysate was loaded onto HiTrap Q HP column (GE Healthcare) and eluted through salt gradient using low-salt buffer (as described above) and high-salt buffer (50mM Tris-HCl pH 7.5, 100mM NaCl).¹³⁸ Collected fractions were exchanged into the following TKME-100 buffer: 20mM Tris-HCl pH 7.5, 100mM KCl, 10mM MgCl₂, 0.1mM EDTA, 5mM DTT, 10% glycerol, and 0.005% Triton X-100, and snap-frozen.



RepA₁₋₁₅-GFP

pBAD-RepA1-15-GFP was transformed into BL21 (DE3)-RIL cells. Cells were inoculated in 2xYT medium with appropriate antibiotics at 37°C with shaking until OD₆₀₀ reached ~0.6–0.8. Protein overexpression was induced with 1mM IPTG, and cells were grown at 30°C for 4h. Cells were harvested by spinning (4,658g, 4°C, 25min) and pellet was resuspended in 40mM HEPES-KOH pH 7.4 plus 2mM 2-Mercaptoethanol (BME) and EDTA-free protease inhibitors. Cells were lysed using a sonicator and centrifuged (30,996g, 4°C, 20min). The resulting pellet was washed twice with HM buffer (40mM HEPES-KOH pH 7.4, 20mM MgCl₂) plus 2mM BME. After each wash, cells were centrifuged (30,996g, 4°C, 20min). The pellet fraction was then resuspended in buffer containing 8M urea, 40mM Tris-HCl pH 6.8, 500mM NaCl, 10% glycerol (v/v) and agitated slowly overnight at 25°C. The solubilized pellet was then centrifuged (30,996g, 25°C, 20min) and the supernatant was collected. The supernatant fraction was incubated with Ni-NTA beads (HisPur Ni-NTA Resin, Thermo Scientific) pre-equilibrated in buffer containing 8M urea, 40mM Tris pH 6.8, 500mM NaCl, 10% glycerol (v/v) for 2h on a spinning wheel at 25 °C at the lowest speed. The Ni-NTA beads were then washed 5 times with buffer containing 8M urea, 40mM Tris-HCl pH 6.8, 500mM NaCl, 20mM imidazole, 10% glycerol (v/v) and then washed 5 times with buffer containing 8M urea, 40mM Tris-HCl pH 6.8, 500mM NaCl, 40mM imidazole, 10% glycerol (v/v). The Ni-NTA beads were then eluted with buffer containing 8M urea, 40mM Tris-HCl pH 6.8, 500mM NaCl, 500mM imidazole, 10% glycerol (v/v). The eluate was dialyzed overnight into buffer containing 40mM HEPES-KOH pH 7.4, 20mM imidazole, 150mM KCl, 2mM BME, 10% glycerol (v/v) at 4°C and reloaded onto a Ni-NTA column (HisTrap HP, GE Healthcare). An imidazole gradient was applied (from 20mM to 500mM) over 20CV in buffer containing 40mM HEPES-KOH pH 7.4, 20mM imidazole, 150mM KCl, 2mM BME, 10% glycerol (v/v). The purity of eluted fractions was assessed using SDS-PAGE. Collected fractions were buffer-exchanged into HKM-150 buffer (40mM HEPES-KOH pH 7.4, 150mM KCl, 20mM MgCl₂) plus 2 mM BME and 10% glycerol (v/v) and snap-frozen.

Hsp70 and Hsp40

Hsc70 and DnaJA1 were from Enzo Life Sciences. Ssa1, Ydj1 and Sis1 were purified as described.¹³⁵

ATPase assay

 0.25μ M (monomeric) Hsp104 was incubated with ATP (1mM) for 5 min at 25°C in luciferase-refolding buffer (LRB150: 25mM HEPES-KOH pH 7.4, 150mM KAOc, 10mM MgAOc, 2 mM 2- Mercaptoethanol). The final reaction buffer contained <0.3% of HKM-500 buffer (stock of Hsp104 is > 100 μ M). ATPase activity was evaluated by the release of inorganic phosphate, which was measured using a malachite green phosphate detection kit (Innova Biosciences). Background hydrolysis at time zero was subtracted.

Luciferase disaggregation and reactivation assay

Aggregated luciferase (100nM, monomer concentration) was incubated with Hsp104 or Hsp104 variants (1µM monomer), ATP (5mM), and an ATP regeneration system (10mM creatine phosphate, 0.25µM creatine kinase) in the presence or absence of additional chaperones Hsp70 (Hsc70 or Ssa1, various concentrations as indicated in the figure) and Hsp40 (Ydj1, DnaJA1, or Sis1), for 90 min at 25°C in LRB. The final reaction buffer contained less than 1% of HKM-500 buffer. After 90min, luciferase activity was measured with a luciferase assay reagent (Promega). Recovered luminescence was measured using a Tecan Infinite M1000 or Spark plate reader.

Luciferase refolding assay

Native luciferase (10μ M) in 6M urea was incubated on ice for 5 min. The sample was then diluted to a final luciferase concentration of 1, 2, 10 or 20 nM into LRB150 with an ATP regeneration system (10mM creatine phosphate, 0.25 μ M creatine kinase), at the indicated Hsp40 (Ydj1 or Sis1) concentration. The sample was then incubated for 90 min at 25°C. After 90min, luciferase activity was measured with a luciferase assay reagent (Promega). Recovered luminescence was measured using a Tecan Infinite M1000 or Spark plate reader.

To check luciferase spontaneous refolding, native luciferase $(10\mu M)$ in 6M urea was incubated on ice for 5 min. The sample was then diluted to a final luciferase concentration of 1, 2, 10, or 20 nM into LRB150 with ARS. The activity of luciferase was measured at time of dilution (0 min) and after incubated for 90 min at 25°C as described above.

Yeast plasmids

Hsp104 variants were under control of a galactose-inducible promoter on pAG416GAL plasmids. In thermotolerance assays, Hsp104 expression was induced by 30min incubation in 37°C through a heat inducible HSE promoter on pRS313HSE plasmids.

Induced thermotolerance assay

Hsp104 variants under the HSE promoter were transformed into W303a Δ hsp104 yeast. Yeast cultures were grown to saturation overnight at 30°C in glucose dropout media. Cultures were normalized to OD₆₀₀ = 0.3 and grown in glucose dropout media at 30°C for at least 4h, after which the equivalent of 6 mL culture with an OD₆₀₀ = 0.6 was grown at 37°C for 30 min (if assessing Hsp104 expression, samples would be harvested at this stage for western blot as described above). Cultures were then heat-shocked at 50°C in 1.5mL Eppendorf tubes in an Eppendorf Thermomixer for 30min and incubated on ice for 2min. Cultures were diluted appropriately, plated





on glucose dropout media, and incubated at 30°C. After 2–3 days, colonies were counted using an aCOLyte colony counter and software (Synbiosis). Spotting result presented in Figure 3B was quantified using ImageJ as described in the quantification and statistical analysis section.

Yeast transformation and spotting assays

Plasmids containing Hsp104 variants were transformed into yeast using a standard lithium acetate and polyethylene glycol procedure.¹³⁹ For spotting assays, yeast cultures were grown to saturation overnight at 30°C in dropout media containing raffinose. Raffinose cultures were then normalized to an $OD_{600} = 2$. 5-fold serial dilution was performed on sterile 96-well plates and spotted onto glucose and galactose plates using a 96-bolt replicator tool. Plates were grown at 30°C for 3 days and imaged at both day 2 and day 3.

Western blotting

For yeast Western blotting, Hsp104 variants transformed into appropriate yeast strains were grown to saturation overnight at 30° C in dropout media containing raffinose. Cultures were normalized to $OD_{600} = 0.3$ and grown in galactose dropout media at 30° C to induce Hsp104 and disease substrate expression (TDP-43 and FUS cultures induced for 5h). Galactose cultures were then normalized according to OD_{600} and the equivalent of 6mL culture with an $OD_{600} = 0.6$ were harvested by centrifugation. Media was aspirated, and the cell pellets were resuspended in 0.1M NaOH and incubated at room temperature for 5min. Cells were pelleted again by centrifugation, supernatant removed, and pellet was resuspended in 100μ L 1X SDS sample buffer and boiled for 4-5min. Samples were separated via SDS-PAGE (4–20% gradient, Bio-Rad) and transferred to a PVDF membrane (Millipore) using a Trans-Blot SD Semi-Dry Transfer Cell (Bio-Rad). Membranes were blocked for at least 1h at room temperature and then incubated with primary antibodies (rabbit anti-Hsp104 polyclonal (Enzo Life Sciences); rabbit anti-FUS polyclonal (Bethyl Laboratories); rabbit anti-TDP-43 polyclonal (Proteintech); rabbit anti-GFP polyclonal (Sigma-Aldrich); mouse anti-PGK1 monoclonal (Thermo Fisher) at 4°C overnight. Membranes were washed multiple times with PBS-T, incubated with secondary antibodies (goat anti-mouse and goat anti-rabbit, LI-COR) for 1h at room temperature, and washed again multiple times with PBS-T (final wash with PBS). Membranes were imaged using an LI-COR Odyssey FC Imaging system.

Toxicity spotting assay

pAG416GAL plasmids containing Hsp104 variants were transformed into W303a Δ hsp104 yeast. Yeast cultures were grown to saturation overnight at 30°C in dropout media containing raffinose. Raffinose cultures were then normalized according to OD₆₀₀ and 5-fold serial diluted. The cultures were spotted onto two sets of glucose and galactose plates using a 96-bolt replicator tool. One set of plates was grown at 30°C, and the other at 37°C, for three days and imaged subsequently at day 2 and day 3.

RepA₁₋₁₅-GFP unfoldase assay

RepA₁₋₁₅-GFP (0.7 μ M) was incubated with Hsp104 or Hsp104 variants (6 μ M, monomeric), ATP (4mM), ARS (20mM creatine phosphate, 0.06 μ g/ μ L creatine kinase). GroEL_{trap} (2.5 μ M tetradecamer) was included to prevent refolding of unfolded RepA₁₋₁₅-GFP. Hsp104 variants were buffer-exchanged into TKME-100 buffer at 25°C. Reactions were assembled on ice in TKME-100 buffer plus 20 μ g/ml BSA. RepA₁₋₁₅-GFP unfolding was measured by fluorescence (excitation 395nm, emission 510nm) using a Tecan Safire,² which was heated to 30°C prior to reading.

Codon-optimized Hsp104 plasmid for human cell expression

The codon optimized Hsp104 plasmid for human cell expression were purchased through Twist by two fragments with 20nt overhangs to insert into mCherry2-N1 plasmid using Gibson Assembly. The mCherry-N1 plasmid was linearized using Agel restriction enzyme. For mCherry-tagged Hsp104 variants, mCherry is located at the C-terminal end of Hsp104. The following Hsp104 sequence was inserted on the N-terminal site of mCherry separated by a glycine-serine linker (Gly-Gly-Ser-Gly-Gly-Gly-Ser-Gly-Gly).



TAGACATAAGTTGTGCGGGCGTGGCAGTTGCAAGAGACTCCAAACCTGAAGAATTGGACTCCAAAGAGCGACAACTCCAACTGA TCCAGGTCGAGATTAAAGCGTTGGAGCGCGACGAAGACGCGGACTCTACTACTAAGGACCGGCTTAAACTTGCTCGACAGAAGG AAGCGTCCCTCCAGGAGGAACTCGAGCCTTTGAGGCAGCGATACAACGAGGAAAAACACGGGACATGAGGAACTGACCCAAGCT TTGCTATCCCTGATATTAAGAAACAGATCGAAAAAGCTGGAGGATCAGGTTGCTGAAGAAGAAGAAGACGAGCCGGAGCGAATTCAAT GATACAGAACGTCGTTGATAGTGATACGATATCCGAAACAGCCGCGCGACTTACTGGAATACCGGTTAAAAAGCTCTCAGAGTCT GAGAATGAAAAACTCATTCACATGGAACGCGATCTCAGTTCAGAAGTTGTCGGTCAGATGGACGCCATTAAGGCAGTATCCAACG AGAACTGGCTAAGAAGGTTGCAGGGTTTCTGTTTAACGATGAAGATATGATGATTAGAGTAGACTGCTCTGAACTGTCCGAGAAAT ACGCCGTGAGTAAATTGCTCGGAACCACTGCCGGATATGTTGGATATGACGAAGGCGGATTCCTCACAAATCAGCTGCAGTACAA ACCATACAGCGTCCTTTTGTTCGATGAAGTCGAGAAGGCTCACCCAGACGTTCTGACTGTTATGCTCCAGATGCTTGATGATGGGA GGATTACTTCTGGTCAAGGAAAGACCATCGATTGCAGCAACTGTATTGTAATCATGACCAGTAATTTGGGTGCTGAATTCATCAACA GTCAGCAGGGTTCAAAAATCCAAGAATCCACTAAAAACCTGGTTATGGGGGCAGTTCGGCAACACTTTCGCCCTGAATTTCTTAAT CGAATCTCATCCATCGTGATATTCAACAAGCTCAGTCGCAAGGCAATCCATAAAATTGTGGACATAAGACTCAAAGAGATAGAAGA AAGGTTTGAACAGAACGATAAGCATTACAAGCTTAATCTGACACAGGAGGCAAAGGACTTCCTCGCGAAGTACGGGTATAGCGAC GACATGGGTGCTAGACCGCTTAATCGCTTGATTCAAAATGAGATCCTCAACAAGCTGGCTCTTAGGATACTGAAAAACGAGATCAA GGACAAAGAGACTGTGAATGTAGTGTTGAAAAAGGGAAAATCCCCGAGATGAAAATGTACCGGAAGAGGCCCGAGGAATGCCTTGAA GTACTTCCAAACCATGAGGCAACCATCGGTGCTGATACCCTCGGTGATGATGATAACGAAGATTCAATGGAAAATCGACGACGACC TCGAC.

HeLa and HEK293 cell culture and transfections

HeLa cells were cultured in Dulbecco's Modified Eagle Medium (DMEM) with high glucose, supplied by Gibco, which was enriched with 10% fetal bovine serum (FBS) from HyClone and 1% penicillin-streptomycin solution from Gibco. The cells were seeded into 6-well plates at a density of $2-2.5 \times 10^5$ cells per plate, 24h prior to the transfection. The transfection was carried out with 1.5μ g of total DNA mixed with 4.5μ L of Lipofectamine 2000 reagent (Invitrogen). Four hours post-transfection, the medium was replaced with the standard growth medium to continue cell maintenance. 24h after the transfection, the cells were collected for analysis by microscopy or Western blotting.

HEK293 cells were cultured in Dulbecco's Modified Eagle Medium (DMEM) with high gluucose, supplied by Gibco, which was enriched with 10% fetal bovine serum (FBS) from HyClone and 1% penicillin-streptomycin solution from Gibco. The cells were seeded into 24-well poly-D-lysine coated plates at a density of 1×10^5 cells per plate for microscopy experiments and 6-well poly-D-lysine coated plates at a density of 1×10^5 cells per plate for microscopy experiments and 6-well poly-D-lysine coated plates at a density of 1×10^5 cells per plate for Western blotting experiments 24h prior to the transfection. The transfection was carried out with $1\mu g$ of total DNA mixed with $0.375\mu L$ of Lipofectamine 3000 and $2\mu L$ P3000 reagent (Invitrogen) for the 24-well plates, and $5\mu g$ of total DNA mixed with $3.75\mu L$ of Lipofectamine 3000 and $10\mu L$ P3000 reagent (Invitrogen) the 6-well plates. Four hours post-transfection, the medium was replaced with the standard growth medium to continue cell maintenance. 24h after the transfection, the cells were collected for analysis by microscopy or Western blotting.

In the microscopy experiments, the colocalization of proteins was assessed manually. At least 500 cells per experiment sample were analyzed across 3-6 separate trials. The statistical analysis was conducted using a one-way ANOVA with Dunnett's test, with the calculations performed using GraphPad Prism Software.

Western blotting for HeLa and HEK293 cell experiments

For HeLa cells, \sim 2-2.5 × 10⁵ cells were seeded and transfected with GFP-tagged FUS and either mCherry-tagged Hsp104 variants or an empty vector expressing mCherry. After 24h, cells were washed once with PBS, then resuspended in RIPA lysis buffer (150 mM NaCl, 1% Triton X-100, 1% sodium deoxycholate, 0.1% SDS, 25mM Tris–HCl pH 7.6) supplemented with protease inhibitors and 1 mM PMSF. Cells were then sonicated and centrifuged at 4°C for 10 min at 10,000g, and the cell lysate was mixed with 1× SDS-PAGE sample buffer.

For HEK293 cells, $\sim 1 \times 10^6$ cells were seeded and transfected with Δ NLS-TDP-43-YFP and either mCherry-tagged Hsp104 variants or an empty vector expressing mCherry. After 24h, cells were washed once with PBS, then resuspended in RIPA lysis buffer (150mM NaCl, 1% Triton X-100, 1% sodium deoxycholate, 0.1% SDS, 25mM Tris–HCl pH 7.6) supplemented with protease inhibitors and 1 mM PMSF. Cells were then sonicated and centrifuged at 4°C for 10 min at 10,000g, and the cell lysate was mixed with 1× SDS-PAGE sample buffer. The samples were then boiled and separated by SDS-PAGE (4–20% gradient, Bio-Rad) and transferred to a PVDF membrane. The following primary antibodies were used: rabbit anti-GFP polyclonal (Sigma-Aldrich) for induced GFP-FUS expression, anti-TDP-43 (proteintech) for TDP-43^{Δ NLS-}YFP expression, anti-alpha Tubulin monoclonal (ab6160 for human cells), and anti-mCherry polyclonal (Abcam). Three fluorescently labeled secondary antibodies were used: anti-rabbit (Li-Cor), anti-rat (Li-Cor), and anti-mouse (Li-Cor). Blots were imaged using an LI-COR Odyssey FC Imaging system.

Fluorescence microscopy

For HeLa and HEK293 cell microscopy, transfected HeLa or HEK293 cells were fixed with 2% formaldehyde for 30 min at room temperature, followed by treatment with Triton X-100 for 6 min to permeabilize cells. Coverslips were then assembled using





VECTASHIELD Antifade Mounting Medium with DAPI (Vector Laboratories) and sealed before imaging. Images were taken at 100 × magnification using the EVOS M5000 Imaging System (ThermoFisher) and processed using ImageJ. At least 100 cells were counted for each condition across three to six independent trials.

QUANTIFICATION AND STATISTICAL ANALYSIS

The Absolute IC_{50} model in GraphPad was used to fit the dose-dependent luciferase reactivation isotherms as a function of Ssa1 or Sis1 concentrations.

Fifty=(Top+Baseline)/2

Y= Bottom + (Top-Bottom)/(1+((Top-Bottom)/(Fifty-Bottom)-1)*(AbsoluteIC₅₀/X)^HillSlope)

The Bell-shaped dose-response model in GraphPad was used to fit the dose-dependent luciferase reactivation isotherms as a function of Ydj1 concentrations.

Span1 = Plateau1-Dip

Span2 = Plateau2-Dip

Section1 = Span1/(1+(EC₅₀ $1/X)^nH1)$

Section2 = Span2/(1+(X/EC₅₀_2)^nH2)

Y = Dip+Section1+Section2

Here, X is Ssa1, Sis1 or Ydj1 concentration, and Y is the level of reactivated Luciferase in an arbitrary unit.

Quantification is as described in the figure legends. Statistical analyses were performed using the GraphPad Prism (GraphPad Software, Inc.; La Jolla, CA, USA) as described in figure legends.

Thermotolerance spotting assay quantification

The spotting images were opened in ImageJ. The image type was changed to 8-bit, and applied background subtraction by choosing 'subtract background' under the 'Process' tab. The image was then converted to binary images by choosing 'Binary' under the 'Process' tab. The density of each spot was then quantified, as D_1 for the first spot, and D_2 for the second spot, etc. For each sample, only the first four spots (5-fold dilution serial) are included for this analysis. The dilution factor was corrected to account for sum of the density (D_{Sum}) for each sample as shown below:

$$D_{Sum} = D_1 + 5^*D_2 + 25^*D_3 + 125^*D_4$$

The D_{Sum} of each Hsp104 variant was then normalized to D_{Sum} of Hsp104 for each replicate.

Cell Reports, Volume 43

Supplemental information

Design principles to tailor Hsp104 therapeutics

JiaBei Lin, Peter J. Carman, Craig W. Gambogi, Nathan M. Kendsersky, Edward Chuang, Stephanie N. Gates, Adam L. Yokom, Alexandrea N. Rizo, Daniel R. Southworth, and James Shorter




Figure S1. Hsp104 variants bind a model, disordered substrate, β-casein, with the same affinity as Hsp104 (**A**) FITC-casein (30nM) was incubated with the indicated concentration of Hsp104 (x-axis) in the presence of ATPγS (2mM). Binding was assessed by fluorescence polarization. Values represent means±SEM (n=2). The data were fitted using a one-site binding curve in Graphpad, and the apparent K_D of the Hsp104 variants tested are similar to WT Hsp104 (0.2±0.1µM). (**B**) Bar graph of the data presented in Figure 2E for luciferase disaggregation and reactivation by Hsp104 or Hsp104^{A503S} (1µM, monomeric), plus Ssa1 (0.167µM) and the three lowest Ydj1 concentrations or in the absence of Ydj1. Bars represent means±SEM (n=2); each data point represents an independent replicate.

Related to Figure 1 and 2.




Figure S2. Ydj1 but not Sis1 can dissociate substrate from Hsp104 and inhibit the spontaneous refolding of unfolded luciferase. (A, B) Fluorescence polarization experiments measuring substrate binding competition between Hsp104 and Hsp40. Hsp104 (5µM hexameric) and the model substrate, FITC-casein (30 nM), were incubated with ATPyS (2mM) for 30min. The complex was then titrated with Ydj1 (A) or Sis1(B) at the indicated concentrations (x-axis, log scale) in the presence of ATPyS (2mM). Fluorescence polarization of FITC-casein (y-axis) was measured. Results from a representative experiment are shown. (C) Spontaneous refolding of soluble unfolded luciferase in buffer was measured at time of unfolding (0 min) and after 90 min. Luciferase (10µM) in 6M urea was incubated on ice for 5min and then diluted into solutions to a final concentration of 1, 2, 10 or 20nM as indicated in the figure. Luciferase activity was measured right after the unfolding reaction or after 90min in buffer. Bars represent means±SEM (n=4), each replicate is shown as a dot. (D, E) Luciferase (10µM) in 6M urea was incubated on ice for 5 min and then diluted into solutions containing various concentrations of Ydj1 (panel D x-axis, log scale) or Sis1 (panel E x-axis, log scale) to a final concentration of 1, 2, 10 or 20nM as indicated. Luciferase activity was measured after 90min. Values represent means±SEM (n=2). The IC₅₀ of Ydj1 inhibition was determined using the dose-dependent fitting model for absolute IC₅₀.

Related to Figure 2 and Table S1.




Figure S3. Rebuilding of the NBD1:MD salt bridges alters the ATPase activity of Hsp104. (A) ATPase activity of the indicated Hsp104 variants (0.25µM, monomeric) in ATP (1mM) after 5min at 25°C. Bars represent means±SEM (n=4), individual replicates are shown as dots. Dunnett's multiple comparisons were performed to compare the ATP hydrolysis rate of NBD1-MD variants to WT. **** P≤0.0001, ***P≤0.001, **P≤0.01. (B) Western blots to evaluate Hsp104 expression level of yeast in the thermotolerance assay (Figure 3B). Hsp104 variants were expressed for 30min at 37°C in $\Delta hsp104$ yeast. Yeast were then lysed, and the lysates were processed for Western blot. PGK1 serves as a loading control.

Related to Figure 3.




Figure S4. Hsp104 variant off-target toxicity and expression level in yeast. (A) The offtarget toxicity of Hsp104 variants that perturb the intraprotomer NBD1:MD contacts of the ADP state is evaluated at 37°C using yeast spotting assay. $\Delta hsp104$ yeast were transformed with galactose-inducible Hsp104 variants or an empty vector, WT Hs104 or Hsp104^{A503S} serve as controls. The yeast were spotted onto galactose (induction on) media in a five-fold serial dilution and incubated at 30°C (left) or 37°C (right). The potentiated variants revealed in Figure 4 are highlighted in red, and the toxic variants are underlined. (B) Western blots were performed to evaluate Hsp104 expression. $\Delta hsp104$ yeast from Figure 4 harboring the indicated Hsp104 variants or empty vector control were induced in galactose media for 5 hours at 30°C. Yeast were lysed and the lysates were visualized via Western blot. PGK1 serves as a loading control.

Related to Figure 4.




Figure S5. Western blots confirm Hsp104 variants and disease proteins are expressed at similar levels. Integrated $\Delta hsp104$ yeast strains from Figure 6C (left) and 6D (right) were induced for 5 hours in galactose media. Yeast were lysed and processed for western blot. PGK1 serves as a loading control.

Related to Figure 6.




Figure S6. Western blots confirm Hsp104 variants and disease proteins are expressed in human cells. (A) Western blot of lysates of HeLa cells transfected with GFP-FUS and either mCherry alone or mCherry-tagged Hsp104. Probing with anti-GFP and anti-mCherry shows FUS-GFP and Hsp104-mCherry expression levels, respectively. α -tubulin is used as a loading control. (B) Western blot of lysates of HEK293 cells transfected with TDP-43^{Δ NLS}-YFP and either mCherry alone or mCherry-tagged Hsp104. Probing with anti-GFP and anti-mCherry shows TDP-43^{Δ NLS}-YFP and either mCherry alone or mCherry-tagged Hsp104. Probing with anti-GFP and anti-mCherry shows TDP-43^{Δ NLS}-YFP and Hsp104-mCherry expression levels, respectively. α -tubulin is used as a loading control.

Related to Figure 7.

	1. Ssa1 EC ₅₀ (Figure 2B)	2. Sis1 EC ₅₀ (Figure 2D, F)	3. Ydj1 EC ₅₀ (Figure 2C, E)	4. Ydj1 IC ₅₀ (Figure 2C, E)	5. Ydj1 IC₅ ₀ (Figure S2A)
Hsp104	~5µM	~2µM	~0.4µM	~14µM	~40µM
Hsp104 ^{R366E}	~6µM	~1.9µM	~0.047µM	~0.63µM	~20µM
Hsp104 ^{R419E}	~5µM	~3µM	~0.08µM	~1.3µM	~30µM
Hsp104 ^{A503S}	ND	~2µM	~0.21µM	~6µM	ND

Table S1. Summary of EC₅₀ and IC₅₀ values. From left to right: 1. EC₅₀ of Ssa1 for stimulation of luciferase disaggregation and reactivation by Hsp104 variants in the absence of Hsp40 (Figure 2B). 2. EC₅₀ of Sis1 for stimulation of luciferase disaggregation and reactivation by Hsp104 variants in the presence of Ssa1 (Figure 2D, F). 3. EC₅₀ of Ydj1 for stimulation of luciferase disaggregation and reactivation by Hsp104 variants in the presence of Ssa1 (Figure 2D, F). 4. IC₅₀ of Ydj1 for stimulation of luciferase disaggregation and reactivation by Hsp104 variants in the presence of Ssa1 (Figure 2C, E). 4. IC₅₀ of Ydj1 for stimulation of luciferase disaggregation and reactivation by Hsp104 variants in the presence of Ssa1 (Figure 2C, E). 5. IC₅₀ of Ydj1 for dissociating β -casein from Hsp104 variants (Figure S2A).